Register your product and get support at
www.philips.com/welcome

6000 series Smart LED TV

42PFL6008
42PFL6158
42PFL6178
42PFL6188
42PFL6198
47PFL6008
47PFL6158
47PFL6188
47PFL6198
47PFL6678
55PFL6008
55PFL6158
55PFL6188
55PFL6198
55PFL6678
60PFL6008

User manual

PHILIPS

Contents

1 Tour 3
1.1 Smart TV 3
1.2 App gallery 3
1.3 Rental videos 3
1.4 Social networks 3
1.5 Skype 3
1.6 Smartphones and tablets 4
1.7 Pause TV and recordings 4
1.8 Gaming 4
1.9 EasyLink 4

2 Setting up 6
2.1 TV stand and wall mounting 6
2.2 Tips on placement 6
2.3 Power cable 6
2.4 Antenna 6
2.5 Satellite dish 7
2.6 Network 7
2.7 Connect devices 9
2.8 Setup menu 17
2.9 Safety and care 18

3 TV 20
3.1 Switch on 20
3.2 Remote control 20
3.3 TV channels 24
3.4 TV guide 32
3.5 Switch to devices 33
3.6 Subtitles and languages 33
3.7 Timers and clock 35
3.8 Picture settings 35
3.9 Sound settings 38
3.10 Ambilight settings 40
3.11 Universal access 41

4 Satellite channels 43
4.1 Watching satellite channels 43
4.2 Satellite channel list 43
4.3 Favourite satellite channels 43
4.4 Lock satellite channels 44
4.5 Satellite installation 45

5 3D 50
5.1 What you need 50
5.2 Your passive 3D glasses 50
5.3 Watch 3D 50
5.4 Optimal 3D viewing 50
5.5 Health warning 50
5.6 Care of the 3D glasses 51

6 Smart TV 52
6.1 Home menu 52
6.2 Smart TV Apps 52
6.3 Videos, photos or music 54
6.4 Pause TV 57
6.5 Recording 58
6.6 MyRemote App 59

7 Skype 64
7.1 What is Skype? 64
7.2 Start Skype 64
7.3 Contacts 65
7.4 Calling on Skype 66
7.5 Skype Credit 67
7.6 Skype settings 67
7.7 Sign out 68
7.8 Terms of Use 68

8 Games 69
8.1 Play a game 69
8.2 Two-player games 69

9 TV Specifications 70
9.1 Environmental 70
9.2 Power 71
9.3 Reception 71
9.4 Display 71
9.5 Sound 71
9.6 Multimedia 71
9.7 Connectivity 72
9.8 Dimensions and weights 72

10 TV Software 73
10.1 Software version 73
10.2 Software update 73
10.3 Open source software 73
10.4 Open source license 73

11 Support 74
11.1 Register 74
11.2 Using help and search 74
11.3 Online help 74
11.4 Consumer Care 74

12 Copyrights and licences 75
12.1 HDMI 75
12.2 Dolby 75
12.3 Skype 75
12.4 DivX 75
12.5 Microsoft 75
12.6 Wi-Fi Alliance 75
12.7 Other trademarks 75

Index 76

1

Tour

1.1 Smart TV

Connect this **Philips Smart LED TV** to the Internet and discover a new world of television. You can make a wired connection to your router or you can link up wirelessly with Wi-Fi.



With the TV connected to your home network, a smartphone can show a photo on TV, you can play videos stored on your computer or control the TV with your tablet.

With your TV connected to the Internet, you can watch a rental video from an online video store, read the online TV guide or record your favourite TV show on a USB Hard Drive. The Smart TV Apps add to the fun with all sorts of entertainment and convenient services.

In **Help**, press **List** and look up **Smart TV** for more information.

1.2 App gallery

Open the **App gallery** in Smart TV to browse the Apps, the collection of tailored websites for TV.

Find the App for YouTube videos, a national newspaper, an online photo album, Facebook, Twitter, etc. There are Apps to rent a video from an online video store and Apps for watching programmes you missed. If the App gallery does not hold what you are looking for, try the World Wide Web and surf the Internet on TV.

In **Help**, press **List** and look up **App gallery** for more information.

1.3 Rental videos

To watch a **rental video**, you don't need to leave your home. Simply rent the latest movie from your regional online video store.



Start Smart TV and add the video store App to the Smart TV start page.
Open the video store App, create your personal account, select the movie and press play.
No fuss with downloading, you can watch the movie immediately*.

In **Help**, press **List** and look up **Rental videos** for more information.

* Depending on the video streaming service of the selected video store.

1.4 Social networks

No need to get up to check your friend's messages on your computer. Open Smart TV, select your **social network** page and send a message back from your couch.

Smart TV supports the popular social networks Facebook and Twitter.

In **Help**, press **List** and look up **App gallery** for more information.

1.5

Skype

With **Skype™** you can make video calls on your TV for free.

You can call and see your friends from anywhere in the world. To make a video call, you need a camera with a built-in microphone and a good connection to the Internet. Some Philips TVs have a camera and microphone built in.

In **Help**, press **List** and look up **Skype** for more information.

1.6

Smartphones and tablets

To use your smartphone or tablet as a TV remote control or as your media controller, download the **Philips MyRemote** app from your smartphone or tablet app store.

Operate your TV from your smartphone or tablet, switch channels or change the volume. With the MyRemote app, you can use your phone or tablet to send photos, music or videos from your computer to your TV. And with MyRemote app on a tablet, you can call up the TV guide, read about the programmes and switch the TV to a channel with a simple tap of your finger. The MyRemote app is available for iOS and Android.

In **Help**, press **List** and look up **MyRemote app** for more information.

1.7

Pause TV and recordings

If you connect a USB Hard Drive, you can **pause and record a broadcast** from a digital TV channel.

Pause your TV and answer that urgent phone call or simply take a break during a sports match, while the TV stores the broadcast on the USB Hard Drive. You can start watching again later.
With a USB Hard Drive connected, you can also record digital broadcasts. You can record while you are watching a program or schedule a recording of an upcoming programme.

In **Help**, press **List** and look up **Pause TV** or **Recording** for more information.

1.8

Gaming

If you select your **game console** in the Home menu, the TV switches to the settings ideal for gaming automatically.

If you play a multi-player game with split screens, you can set the TV to show each screen as a full screen simultaneously. Each player can focus on his own game to play.



The TV uses 3D technology to show both screens. To play a two-player game with two different full screen pictures, you need a pair of 3D glasses for each player.

In **Help**, press **List** and look up **Game console** or **Two-player games** for more information.

1.9

EasyLink

With **EasyLink** you can operate a connected device, like a Blu-ray Disc player, with the remote control of the TV.

EasyLink uses HDMI CEC to communicate with the connected devices.



In **Help**, press **List** and look up **EasyLink** for more information.

2

Setting up

2.1

TV stand and wall mounting

TV Stand

You can find the mounting instructions of the TV stand in the Quick Start Guide that came with the TV. In case you lost this guide, you can download it from **www.philips.com**.
Use the product type number of the TV to look for the Quick Start Guide to download.

Wall mounting

Your TV is also prepared for a VESA-compliant wall mount bracket (sold separately).
Use the following VESA code when purchasing the wall mount . . .

VESA MIS-F 400x400,M6

To fix the bracket securely, use a screw length as shown in the drawing.



Caution
Wall mounting the TV requires special skills and should only be performed by qualified personnel. The TV wall mounting should meet safety standards according to the TV's weight. Also read the safety precautions before positioning the TV. TP Vision Netherlands B.V. bears no responsibility for improper mounting or any mounting that results in accident or injury.

2.2

Tips on placement

• Position the TV where light does not shine directly on the screen.
• Dim lighting conditions in the room for best Ambilight effect.
• Position the TV up to 25 cm away from the wall.
• The ideal distance to watch TV from is three times its diagonal screen size. When seated, your eyes should be level with the centre of the screen.

2.3

Power cable

Insert the power cable into the **POWER** socket of the TV.
Make sure the power cable is securely inserted into the TV.
Make sure that the power plug in the wall socket is accessible at all times.
When disconnecting the power cable, always pull the plug, never the cable.



Although this TV has a very low standby power consumption, unplug the power cable to save energy if you do not use the TV for a long period of time.

In **Help**, press **List** and look up **Standby** for more information on switching the TV on and off.

2.4

Antenna

Locate the antenna connection at the back of the TV. Insert the antenna cable securely into the **Antenna** socket.

You can connect your own antenna or connect to an antenna signal from an antenna distribution system (common in certain regions). Use an IEC Coax 75 Ohm RF antenna connector.

Use this antenna connection for DVB-T and DVB-C input signals.



2.5

Satellite dish

Locate the F-type satellite connection at the back of the TV. Attach the cable from your satellite dish - or Unicable splitter - to this connection.



2.6

Network

Wireless connection

What you need

To connect the TV wirelessly to the Internet, you need a **wireless router**. Use a high-speed (broadband) connection to the Internet.

File sharing

The TV can find and open files on other devices in your wireless network, like your computer or NAS device. You can use a computer with a Microsoft Windows XP, Vista or Windows 7, Mac OSX or Linux-based operating system.

Media server software

With media server software on your computer, you can open your photos, music and videos stored on your computer on your TV screen.
Use a recent version of media server software like Windows Media Player 11, Twonky™ or similar*.
Install the software on your computer and set it up to share your media files with the TV. Read the manual of the media server software for more information.
To open your files on the TV, the media server software must be running on your computer.

* In **Help**, press **List** and look up **Media server software, supported** for an overview of supported media server software.

Make the connection

Follow steps **1** to **5**.

Step 1 - Make sure that the router of your wireless network is switched on.
Step 2 - Press ⌂ and select ⚙ **Setup** and press **OK**.
Step 3 - Select **Connect to network** and press **OK**.
Step 4 - Select **Wireless** and press **OK**.
Step 5 - Select **Scan** to scan for your wireless network. If you have a router with WPS (Wi-Fi Protected Setup), you can select **WPS**. Select your choice and press **OK**.

- **Scan**
Select **Scan** to scan for your wireless network (your wireless router). The TV might find several wireless networks in your proximity.

- **WPS**
If your router has WPS, you can directly connect to the router without scanning. Go to the router, press the **WPS** button and return to the TV within 2 minutes. Then press **Connect** to make the connection.
If you have devices in your wireless network that use the WEP security encryption system, you cannot use WPS.
If you must use the **WPS pin code** to connect, select **Scan** instead of WPS.

Step 6 - In the list of networks found, select your wireless network and press **OK**.
If your network is not in the list because the network name is hidden (you switched off the SSID broadcast of the router), select **Manual entry** to enter the network name yourself.

Step 7 - Depending on the type of router, you can now enter your encryption key (WEP, WPA or WPA2). If you entered the encryption key for this network before, you can select **Next** to make the connection immediately.
If your router supports WPS or WPS pin, you can select **WPS**, **WPS pin** or **Standard**. Select your choice and press **OK**.

- **Standard**
Select **Standard** to enter the encryption key (password, passphrase or security key) manually. You can use the keyboard on the RC to enter the encryption key. Once you have entered the key, press **Connect**.

- **WPS pin**

To make a secured WPS connection with a PIN code, select **WPS pin** and press **OK**. Write down the 8-digit PIN code shown and enter it in the router software on your PC. Return to the TV and press **Connect**. Consult the router manual on where to enter the PIN code in the router software.

Step 8 - A message will be shown when the connection is successful.

Network configuration

If the connection fails, you can check the DHCP setting of the router. DHCP should be set to **On**.
Alternatively, if you are an advanced user and want to install your network with static IP addressing, set the TV to Static IP. To set the TV to Static IP, press ⌂ and select ⚙ **Setup** and press **OK**. Select **Network settings** > **Network configuration** > **Static IP**. With Static IP selected in the menu, you can set the IP address and other necessary settings in **Static IP configuration** in the same menu.

Network problems

Wireless network not found or distorted

• Microwave ovens, DECT phones or other Wi-Fi 802.11b/g/n devices in your proximity might disturb the wireless network.
• Make sure that the firewalls in your network allow access to the TV's wireless connection.
• If the wireless network does not work properly in your home, try the wired network installation.

Internet does not work

• If the connection to the router is OK, check the router connection to the Internet.

The PC and Internet connection are slow

• Look in your wireless router's user manual for information on indoor range, transfer rate and other factors of signal quality.
• Use a high-speed (broadband) Internet connection for your router.

Wired connection

What you need

You need a network **router** to connect the TV to the Internet. Use a router with a high-speed (broadband) connection to the Internet.



Installation

Follow steps **1** to **5**.
1 - Connect the router to the TV with a network cable (Ethernet cable**).
2 - Make sure that the router is switched on.
3 - Press ⌂ and select ⚙ **Setup** and press **OK**.
4 - Select **Connect to network** and press **OK**.
5 - Select **Wired** and press **OK**.
The TV constantly searches for the network connection. A message will be shown when the connection is successful.

Network configuration

If the connection fails, you can check the DHCP setting of the router. DHCP should be set to On.
Alternatively, if you are an advanced user and want to install your network with static IP addressing, set the TV to Static IP. To set the TV to Static IP, press ⌂ and select ⚙ **Setup** and press **OK**.
Select **Network settings** > **Network configuration** > **Static IP**. With Static IP selected in the menu, you can set the IP address and other necessary settings in **Static IP configuration** in the same menu.

File sharing

The TV can find and open files on other devices in your network, like your computer. You can use a computer with a Microsoft Windows XP, Vista or Windows 7, Mac OSX or Linux operating system.

Media server software

With media server software on your computer, you can open your photos, music and videos stored on your computer on your TV screen.
Use a recent version of media server software like Windows Media Player 11, Twonky™ or similar*.
Install the software on your computer and set it up to share your media files with the TV. Read the manual of the media server software for more information.
To open your files on TV, the media server software must be running on your computer.

* In **Help**, press ▬ **List** and look up **Media server software, supported** for an overview of supported media server software.

**To fulfill EMC regulations, use a shielded FTP Cat. 5E Ethernet cable.

Network settings

To open the Network settings, press ⌂ and select ⚙ **Setup** and press **OK**.
Select **Network settings** and press **OK.**

View network settings

All current network settings are shown here. The IP and MAC address, signal strength, speed, encryption method, etc.

Network type

Sets the network to Wired or Wireless.

Network configuration

Sets the network configuration to DHCP & Auto IP or Static IP.

Static IP configuration

If Static IP is set, you can set all necessary static IP settings here.

Digital Media Renderer - DMR

To receive multimedia files from smartphones or tablets, set the DMR to **On**.

Wi-Fi Miracast
For more information on Wi-Fi Miracast, press **List** and look up **Wi-Fi Miracast™**.

Wi-Fi Miracast connections
For more information on Wi-Fi Miracast, press **List** and look up **Wi-Fi Miracast™**.

Wi-Fi smart screen
For more information on Wi-Fi smart screen, press **List** and look up **MyRemote App, WiFi smart screen**.

TV network name
If you have more than one TV in your network, you can rename the TVs here.

Clear Internet memory
With Clear Internet memory you clear all Internet files stored on your TV. You clear your Philips Smart TV registration and parental rating setting, your video store app logins, all Smart TV app favourites, Internet bookmarks and history. Interactive MHEG applications can also save so-called 'cookies', on your TV. These files will also be cleared.

2.7
Connect devices

Tips on connections

Connectivity guide

Always connect a device to the TV with the **highest quality connection available**. Also, use good quality cables to ensure a good transfer of picture and sound.

If you need help to connect several devices to the TV, you can visit the **Philips TV connectivity guide**. The guide offers information on how to connect and which cables to use.

Go to **www.connectivityguide.philips.com**

Antenna

If you have a Set-top box (a digital receiver) or Recorder, connect the antenna cables to run the **antenna signal** through the Set-top box and/or Recorder first before it enters the TV. In this way, the antenna and the Set-top box can send possible additional channels to the Recorder to record.



HDMI

HDMI CEC

An **HDMI** connection has the best picture and sound quality. One HDMI cable combines video and audio signals. Use an HDMI cable for High Definition (HD) TV signals. For best signal quality transfer, do not use an HDMI cable longer than 5 m.

EasyLink HDMI CEC
If your devices are connected with HDMI and have EasyLink, you can operate them with the TV remote control. EasyLink HDMI CEC must be switched on on the TV and the connected device.
In **Help**, press **List** and look up **EasyLink HDMI CEC** for more information on using EasyLink.

DVI to HDMI
Use a DVI to HDMI adapter if your device only has a DVI connection. Use one of the HDMI connections and add an Audio L/R cable (mini-jack 3.5 mm) to Audio In VGA/DVI for sound, on the back of the TV.

Copy protection
DVI and HDMI cables support HDCP (High-bandwidth Digital Content Protection). HDCP is a copy protection signal that prevents copying content from a DVD disc or Blu-ray Disc. Also referred to as DRM (Digital Rights Management).

HDMI ARC

All of the HDMI connections on the TV have **HDMI ARC** (Audio Return Channel).
If the device, typically a Home Theatre System (HTS), also has the HDMI ARC connection, connect it to any of the HDMI connections on this TV. With the HDMI ARC connection, you do not need to connect the extra audio cable that sends the sound of the TV picture to the HTS. The HDMI ARC connection combines both signals.

You can use any HDMI connection on this TV to connect the HTS but ARC is only available for 1 device/connection at a time.

In case you prefer to switch off ARC on the HDMI connections, press ⌂ and select ⚙ **Setup** and press **OK**. Select **TV settings** > **Sound** > **Advanced** > **HDMI ARC**.

Y Pb Pr

Component Video YPbPr is a high quality connection. The YPbPr connection can be used for High Definition (HD) TV signals. Next to the Y, Pb and Pr signals add the Audio Left and Right signals for sound.



Use the supplied YPbPr adapter cable to connect your device. Match the YPbPr (green, blue, red) connector colours with the cable plugs when you connect.
Use an Audio L/R cinch to mini-jack (3.5mm) adapter cable (not supplied) if your device also has sound.

SCART

SCART is a good quality connection. The SCART connection can be used for CVBS and RGB video signals but cannot be used for High Definition (HD) TV signals. The SCART connection combines video and audio signals.



Use the supplied SCART adapter cable to connect your device.

Audio Out - Optical

Audio Out - Optical is a high quality sound connection. This optical connection can carry 5.1 audio channels. If your audio device, typically a Home Theatre System (HTS), has no HDMI ARC connection, you can connect this sound cable to an Audio In - Optical connection on the HTS. This Audio cable will send the sound of the TV to the HTS.

You can set the type of the audio out signal to fit the audio capabilities of your Home Theatre System.
In **Help**, press ▬ **List** and look up **Audio Out settings** for more information.

If the sound does not match the video on screen, you can adjust the audio to video synchronization.
In **Help**, press ▬ **List** and look up **Audio to video sync** for more information.

EasyLink HDMI CEC

EasyLink

With **EasyLink** you can operate a connected device with the TV remote control. EasyLink uses HDMI CEC* to communicate with the connected devices. Devices must support HDMI CEC and must be connected with an HDMI connection.
** Consumer Electronics Control*

EasyLink setup

The TV comes with EasyLink switched on. Make sure that all HDMI CEC settings are properly set up on the connected EasyLink devices. EasyLink might not work with devices from other brands.

HDMI CEC on other brands

The HDMI CEC functionality has different names on different brands. Some examples are: Anynet, Aquos Link, Bravia Theatre Sync, Kuro Link, Simplink and Viera Link. Not all brands are fully compatible with EasyLink.

Example HDMI CEC branding names are property of their respective owners.

Operate devices

To operate a device connected to HDMI and set up with EasyLink, select the device -or its activity- in the list of TV connections. Press **SOURCE**, select a device connected to an HDMI connection and press **OK**.

Once the device is selected, the TV remote control can control the device. However the (Home) and **OPTIONS** keys and some other typical TV keys, like **Ambilight**, are not forwarded to the device.
If the key you need is not on the TV remote control, you can select the key in the Options menu. Press **OPTIONS** and select **Controls** in the menu bar. Select the device key you need on screen and press **OK**.
Some very specific device keys might not be available in the Controls menu.

EasyLink settings

The TV comes with all EasyLink settings switched on. You can switch off any EasyLink setting independently.

EasyLink
To switch off EasyLink completely, press and select **Setup** and press **OK**.
Select **TV settings** > **General settings** > **EasyLink** > **EasyLink**.
Select **Off** and press **OK**.

EasyLink Remote Control
If you want devices to communicate but you don't want to operate them with the TV remote control, you can switch off EasyLink remote control separately.
In the EasyLink settings menu, select **EasyLink Remote Control** and select **Off**.

Pixel Plus link
Some devices, a DVD or Blu-ray Disc player, might have their own picture quality processing. To avoid bad picture quality caused by interference with the TV processing, the picture processing of these devices should be disabled. The TV comes with Pixel Plus link switched on and disables the picture quality processing of recent Philips devices connected to the TV.
To switch off Pixel Plus link, in the EasyLink settings menu, select **Pixel Plus link** and select **Off**.

Auto subtitle shift
If you play a DVD or Blu-ray Disc on a Philips disc player that supports subtitles, the TV can move the subtitles upwards. Subtitles will be visible whatever Picture format you select.
The TV comes with Auto subtitle shift switched on.
To switch off Auto subtitle shift, in the EasyLink settings menu, select **Auto subtitle shift** and select **Off**.

Common Interface CAM

CI+

This TV is ready for the CI+ Conditional Access.

With CI+ you can watch premium HD programmes, like movies and sports, offered by digital TV broadcasters in your region. These programmes are scrambled by the TV broadcaster and descrambled with a prepaid CI+ module. Digital TV broadcasters provide this CI+ module (Conditional Access Module - CAM) when you subscribe to their premium programmes. These programmes have a high level of copy protection.

Contact a digital TV broadcaster for more information on terms & conditions.

In **Help**, press **List** and look up **Common Interface CAM** for more information on connecting a CAM.

CAM

Insert a CAM module
Switch off the TV before inserting a CAM.
Look on the CAM for the correct method of insertion.
Incorrect insertion can damage the CAM and the TV.

Use the Common Interface slot on the left side of the TV to insert the CAM card*. Gently insert the CAM as far as it will go and leave it in the slot permanently. It may take a few minutes before the CAM is activated. Removing the CAM will deactivate the broadcast service on TV.

* The Common Interface slot accepts a PC card (PCMCIA) in which you insert a smart card. Both cards should be supplied by the TV broadcaster.

If a CAM is inserted and subscription fees have been paid, (connection methods can differ), you can watch the TV broadcast. The inserted CAM is exclusively for your TV.

CAM settings
To set passwords or PIN codes for the CAM TV broadcast, press and select **Setup** and press **OK**.
Select **Channel settings** > **Common Interface**.
Select the CAM TV broadcaster and press **OK**.

Set-top box STB

Use 2 antenna cables to connect the antenna to the Set-top box (a digital receiver) and the TV.



Next to the antenna connections, add an HDMI cable to connect the Set-top box to the TV. Alternatively, you can use a SCART cable if the Set-top box has no HDMI connection.



Switch off timer
Switch off this automatic timer, if you only use the remote control of the Set-top box. Do this to prevent the TV from switching off automatically after a 4 hour period without a key press on the remote control of the TV.

To switch off the Switch off timer, press ⌂ and select ⚙ **Setup** and press **OK**.
Select **TV settings** > **General settings** > **Switch off timer** and set the slider bar to **0**.

Satellite receiver

Connect the dish antenna cable to the Satellite receiver.



Next to the antenna connection, add an HDMI cable to connect the device to the TV. Alternatively, you can use a SCART cable if the device has no HDMI connection.



Switch off timer
Deactivate the Switch off timer, if you only use the remote control of the Satellite receiver. Do this to prevent the TV from switching off automatically after a 4 hour period without a key press on the remote control of the TV.

To deactivate, press ⌂ and select ⚙ **Setup** and press **OK**.
Select **TV settings** > **General settings** > **Switch off timer** and set the slider bar to **0**.

Home Theatre System (HTS)

Connect

Use an HDMI cable to connect a Home Theatre System (HTS) to the TV. You can connect a Philips Soundbar or an HTS with a built-in disc player.

Alternatively, you can use a SCART cable if the device has no HDMI connection.

HDMI ARC
If your Home Theatre System has an HDMI ARC connection, you can use any HDMI connection on the TV to connect. All HDMI connections on the TV can offer the Audio Return Channel (ARC) signal. But once you connected the Home Theatre System, the TV can only send the ARC signal to this HDMI connection.
With HDMI ARC, you do not need to connect the extra audio cable. The HDMI ARC connection combines both signals.



If the Home Theatre System has no HDMI ARC connection, add an optical audio cable to send the sound of the TV picture to the Home Theatre System.



Audio to video synchronisation (sync)
If the sound does not match the video on screen, you can set a delay on most DVD Home Theatre Systems to match the sound and video. A mismatch can be visible in scenes with people talking - when they finish sentences before their lips stop moving or just the opposite.
In **Help**, press **List** and look up **Audio to video sync** for more information.

Audio Out settings

Audio Out delay

With a Home Theatre System (HTS) connected to the TV, the picture on TV and the sound from the HTS should be synchronised. A mismatch can be visible in scenes with people talking - when they finish sentences before their lips stop moving or just the opposite.

Automatic audio to video sync
With recent Philips Home Theatre Systems, the audio to video sync is automatically synchronised and always correct.

Audio sync delay
For some Home Theatre Systems you might need to adjust the audio sync delay to synchronise the audio to video. On the HTS, increase the delay value until there is a match between picture and sound. A delay value of 180ms may be required. Read the user manual of the HTS. With a delay value set up on the HTS, you need to switch off Audio Out delay on the TV.

To switch off the Audio Out delay . . .
1 - Press ⌂ and select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Sound** > **Advanced** > **Audio Out delay**.
3 - Select **Off** and press **OK**.
4 - Press ↩, repeatedly if necessary, to close the menu.

Audio Out offset

If you cannot set a delay on the Home Theatre System, you can set the TV to sync the sound. You can set an offset that compensates the time necessary for the Home Theatre System to process the sound of the TV picture. You can set the value in steps of 5ms. Maximum setting is -60ms. The Audio Out delay setting should be switched on.

To synchronise the sound on the TV . . .
1 - Press ⌂ and select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Sound** > **Advanced** > **Audio Out offset**.
3 - Use the slider bar to set the sound offset and press **OK**.
4 - Press ↩, repeatedly if necessary, to close the menu.

Audio Out format

If you have a Home Theatre System (HTS) with multichannel sound processing capabilities like Dolby Digital, DTS® or similar, set the Audio out format to Multichannel. With Multichannel, the TV can send the compressed multichannel sound signal from a TV channel or connected player to the Home Theatre System. If you have a Home Theatre System without multichannel sound processing, select Stereo.

To set the Audio Out format . . .
1 - Press ⌂ and select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Sound** > **Advanced** > **Audio Out format**.
3 - Select **Multichannel** or **Stereo**.
4 - Press ↩, repeatedly if necessary, to close the menu.

Audio Out leveling

Use the Audio Out leveling setting to level the volume (loudness) of the TV and the Home Theatre System when you switch over from one to another. Volume differences can be caused by differences in sound processing.

To level the difference in volume . . .
1 - Press ⌂ and select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Sound** > **Advanced** > **Audio Out leveling**.
3 - If the volume difference is large, select **More**. If the volume difference is small, select **Less**.
4 - Press ↩, repeatedly if necessary, to close the menu.

Audio Out leveling affects both the Audio Out - Optical and HDMI-ARC sound signals.

Blu-ray Disc Player

Use an HDMI cable to connect the Blu-ray Disc player to the TV.



If the Blu-ray Disc player has EasyLink HDMI CEC, you can operate the player with the TV remote control.
In **Help**, press **List** and look up **EasyLink HDMI CEC** for more information.

DVD Player

Use an HDMI cable to connect the DVD player to the TV. Alternatively, you can use a SCART cable if the device has no HDMI connection.



If the DVD player is connected with HDMI and has EasyLink HDMI CEC, you can operate the player with the TV remote control.
In **Help**, press **List** and look up **EasyLink HDMI CEC** for more information.

Game

Connect a game console to the side or back of the TV.
You can use an HDMI, YPbPr or SCART connection. If your game console only has Video (CVBS) and Audio L/R output, use a Video Audio L/R to SCART adapter to connect to the SCART connection.



For best quality, use an HDMI cable to connect the game console to the side of the TV.
If the game console is connected with HDMI and has EasyLink HDMI CEC, you can operate the game console with the TV remote control.

Alternatively, use a SCART adapter (not supplied) to connect the game console to the TV.



USB Hard Drive

What you need

If you connect a USB Hard Drive, you can pause or record a TV broadcast. The TV broadcast must be a digital broadcast (DVB broadcast or similar).

To pause

To pause a broadcast, you need a USB 2.0 compatible Hard Drive with a minimum of 32GB Hard Drive space.

To record

To pause or record a broadcast, you need a Hard Drive with a minimum of 250GB Hard Drive space.



TV guide

Before you decide to buy a USB Hard Drive to record, you can check if you can record digital TV channels in your country.
Press **Guide** on the remote control. If there is a Record button on the TV guide page, you can record programmes from digital TV channels.

In **Help**, press **List** and look up **USB Hard Drive, Installation** to install a USB Hard Drive on this TV.

Installation

Before you can pause or record a broadcast, you must connect and format a USB Hard Drive. If you want to record a broadcast with TV guide data from the Internet, you need to have the Internet connection installed on your TV before you install the USB Hard Drive.

1 - Connect the USB Hard Drive to a **USB** connection on the side of the TV. Do not connect another USB device to the other USB ports when formatting.

2 - Switch on the USB Hard Drive and the TV.
3 - When the TV is tuned to a digital TV channel, press ❚❚ (Pause). Trying to pause will start the formatting. Formatting removes all files from the connected USB Hard Drive.
Follow the instructions on screen.
When the USB Hard Drive is formatted, leave it connected permanently.

Warning
The USB Hard Drive is formatted exclusively for this TV, you cannot use the stored recordings on another TV or PC. Do not copy or change recording files on the USB Hard Drive with any PC application. This will corrupt your recordings. When you format another USB Hard Drive, the content on the former will be lost. A USB Hard Drive installed on your TV will need reformatting for use with a computer.

In **Help**, press ■ **List** and look up **Pause TV** or **Recording** to pause or record TV channels.

USB keyboard or mouse

USB keyboard

Connect a USB keyboard (USB-HID type) to enter text on your TV.

You can connect a keyboard and a mouse to the TV.
Use the **USB** connection on the side of the TV to connect.

Install the keyboard
To install the USB keyboard, switch on the TV and connect the USB keyboard to one of the **USB** connections on the side of the TV. When the TV detects the keyboard for the first time, you can select your keyboard lay-out and test your selection.
If you select a Cyrillic or Greek keyboard lay-out first, you can select a secondary Latin keyboard lay-out.
To change the keyboard lay-out setting later on, press ⌂ and select ⚙ **Setup** and press **OK**.
Select **TV settings** > **General settings** > **USB mouse and keyboard** > **Keyboard settings** and press **OK**.

Keys for channel renaming
- Enter ↵ = OK
- Backspace ← = delete character before cursor
- Arrow keys = navigate within a text field
- To switch between keyboard lay-outs, if a secondary lay-out is set, press the **Alt + Shift** keys simultaneously.

Keys for Smart TV Apps and Internet pages
- **Tab** and **Shift Tab** = Next and Previous
- **Home** = scroll to the top of the page
- **End** = scroll to the bottom of the page
- **Page Up** = jump one page up
- **Page Down** = jump one page down
- **+** = zoom in one step
- **-** = zoom out one step
- * = fit to width

In **Help**, press ■ **List** and look up **USB mouse**, to connect a USB mouse.

USB mouse

Connect

You can connect a USB mouse (USB-HID type) to navigate pages on the Internet.
On an Internet page, you can select and click on links more easily.

Connect the mouse
Switch the TV on and connect the USB mouse to one of the **USB** connections on the side of the TV. You can also connect the USB mouse to a connected USB keyboard.

Mouse clicks
- **Left click** = OK
- **Right click** = Back ⮌
You can use the scroll wheel to scroll pages up and down.

In **Help**, press ■ **List** and look up **USB keyboard**, to connect a USB keyboard.

Speed

You can adjust the speed of the mouse, the speed of the mouse moving on screen.

To adjust the speed . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** and press **OK**.
3 - Select **General settings** > **Pointer and mouse speed** and press **OK**.

4 - Press the arrows ▲ (Up) or ▼ (Down) to increase or lower the speed.
5 - Press the arrow ▶ (Right) to test the speed you set.
6 - Press the arrow ◀ (Left) to return to the setting. You can adjust the setting again.
7 - Press **OK** to store and close the setting.
8 - Press ⮌, repeatedly if necessary, to close the menu.

USB flash drive

You can view photos or play your music and videos from a connected USB flash drive.

Insert a USB flash drive into the **USB** connection on the left-hand side of the TV while the TV is switched on.



The TV detects the flash drive and opens a list showing its content.
If the contents list does not appear automatically, press **SOURCE**, select **USB** and press **OK**.

To stop watching the USB flash drive content, press **TV** or select another activity.
To disconnect the USB flash drive, you can pull out the flash drive anytime.

In **Help**, press **List** and look up **Videos, photos and music**, to watch or listen to content from a USB flash drive.

Photo camera

To view photos stored on your digital photo camera, you can connect the camera directly to the TV.

Use the **USB** connection on the left side of the TV to connect. Switch on the camera after you made the connection.

If the contents list does not appear automatically, press **SOURCE**, select **USB** and press **OK**.

Your camera might need to be set to transfer its content with PTP (Picture Transfer Protocol). Read the user manual of the digital photo camera.

In **Help**, press **List** and look up **Videos, photos and music** for more information on viewing photos.

Camcorder

Connect a camcorder to the side or back of the TV. You can use an HDMI, YPbPr or SCART connection. If your camcorder only has Video (CVBS) and Audio L/R output, use a Video Audio L/R to SCART adapter to connect to the SCART connection.

For best quality, use an HDMI cable to connect the camcorder to the side of the TV.

Or use a SCART adapter to connect the camcorder to the TV.

Computer

You can connect your computer to the TV and use the TV as a PC monitor.

With HDMI
Use an HDMI cable to connect the computer to the TV.



With DVI to HDMI
Alternatively, you can use a DVI to HDMI adapter to connect the PC to **HDMI** and an audio L/R cable to **AUDIO IN L/R** on the back of the TV.



Ideal monitor setting
If your computer is added as a **Computer** type of device in the Source menu (list of connections), the TV is set to the ideal **Computer** setting automatically.

If you use your computer to watch movies or use it to play games, you might want to set the TV back to the ideal TV watching or gaming setting.

To set the TV to the ideal setting manually . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Picture** > **Game or computer** and press **OK**.
3 - Select **Game** (for gaming) or select **Off** (for watching a movie) and press **OK**.
4 - Press ↩, repeatedly if necessary, to close the menu.
Remember to set the Game or computer setting back to **Computer** when you stop playing the game.

Picture format - Unscaled
Additionally, you can also set the Picture format to Unscaled - an expert pixel for pixel display mode (black bars may appear).
1 - Press ⫶⫶ **OPTIONS** and select ⫶⫶ **Options** in the menu bar.
2 - Select **Picture format** > **Unscaled** and press **OK**.

In **Help**, press ▬ **List** and look up **Display resolutions**, for an overview of the supported PC resolutions.

Headphones

You can connect a set of headphones to the 🎧 connection on the side of the TV. The connection is a mini-jack 3.5mm. You can adjust the volume of the headphones separately.

To adjust the volume . . .
1 - Press ⫶⫶ **OPTIONS** and select **Picture and sound** in the menu bar.
2 - Press ▼ (down) and select **Headphones volume** and press **OK**.
3 - Press ▲ (up) or ▼ (down) to adjust the volume.
4 - Press ↩, repeatedly if necessary, to close the menu.

2.8
Setup menu

Quick picture settings

With Quick picture settings you can set your basic picture preferences in a few easy steps. The settings you made are stored under the Picture style - **Personal**. You can return to your picture preference if some settings were changed. You can set a preferred picture setting for every TV activity or connected device individually.

To return to your preferred picture setting, while watching a TV channel, press ⫶⫶ **OPTIONS**, select **Picture and sound** in the menu bar, select **Picture style** and select **Personal**.

To set a Quick picture setting . . .
1 - Press ⌂, select an activity or a connected device (or its connection) and press **OK**.
2 - Press ⌂ again, select ⚙ **Setup** and press **OK**.
3 - Select **Quick picture settings** and press **OK**. Go through the steps and finish. The activity or connection has your personal preferences.

In **Help**, press ▬ **List** and look up **Picture style**, for more information.

TV settings

In the **TV settings** menu you can set all **Picture**, **3D**, **Sound** and **Ambilight** settings. The item **General settings** in the menu holds a collection of settings like **Menu language**, **Sleep timer**, **Switch off timer**, **Universal access** and more.

In **Help**, press **List** and look up the topic or setting you need.

Search for channels

In **Help**, press **List** and look up **Channel, update** or **Channels, reinstall**, for more information.

Channel settings

Languages
In **Help**, press **List** and look up **Audio language** or **Subtitles** for more information.

Universal access
In **Help**, press **List** and look up **Universal access** for more information on setting up the TV for visually and hearing impaired users.

Channel installation
In **Help**, press **List** and look up **Automatic channel update** or **Channel update message**. Also look up **Manual installation** for installing analogue channels or **DVB** to switch the antenna connection.

Child lock
In **Help**, press **List** and look up **Child lock** for more information.

Search for satellite

In **Help**, press **List** and look up **Satellite, installation** for more information.

Satellite settings

Languages
In **Help**, press **List** and look up **Audio language** or **Subtitles** for more information.

Channel installation
In **Help**, press **List** and look up **Satellite, automatic channel update** or **Satellite, channel update message** or **Satellite, automatic update options** for more information.

Child lock
In **Help**, press **List** and look up **Satellite, channel lock** for more information.

Connect to network

In **Help**, press **List** and look up **Network, wireless** or **Network, wired**, for more information.

Network settings

In **Help**, press **List** and look up **Network, settings**, for more information.

Update software

In **Help**, press **List** and look up **Software, Internet update** or **Software, USB update**, for more information.

Software settings

In **Help**, press **List** and look up **Software, current version**, for more information.

Watch demos

With **Watch demos** in the **Setup** menu, you can watch some demonstration videos of some of the picture quality features of your TV.

Active control
The TV monitors the incoming picture quality, the level of motion in the picture, brighter or darker scenes and the light conditions in your room. With these values, the TV adjusts the picture for best performance.

2.9
Safety and care

Safety

Read me

Read and understand all safety instructions before you use the TV. If damage is caused by failure to follow instructions, the warranty does not apply.

Risk of electric shock or fire!

- Never expose the TV to rain or water. Never place liquid containers, such as vases, near the TV. If liquids are spilt on or into the TV, disconnect the TV from the power outlet immediately. Contact Consumer Care to have the TV checked before use.
- Never expose the TV, remote control or batteries to excessive heat. Never place them near burning candles, naked flames or other heat sources, including direct sunlight.
- Never insert objects into the ventilation slots or other openings on the TV.
- Never place heavy objects on the power cord.

• Avoid force coming onto power plugs. Loose power plugs can cause arcing or fire. Ensure that no strain is exerted on the power cord when you swivel the TV screen.
• To disconnect the TV from the mains power, the power plug of the TV must be disconnected. When disconnecting the power, always pull the power plug, never the cord. Ensure that you have full access to the power plug, power cord and outlet socket at all times.

Risk of injury or damage to the TV!

• Two people are required to lift and carry a TV that weighs more than 25 kg or 55 lbs.
• If you mount the TV on a stand, only use the supplied stand. Secure the stand to the TV tightly. Place the TV on a flat, level surface that can support the weight of the TV and the stand.
• When wall mounted, ensure that the wall mount can safely bear the weight of the TV set. TP Vision Netherlands B.V. bears no responsibility for improper wall mounting that results in accident, injury or damage.
• Parts of this product are made of glass. Handle with care to avoid injury or damage.

Risk of damage to the TV!
Before you connect the TV to the power outlet, ensure that the power voltage matches the value printed on the back of the TV. Never connect the TV to the power outlet if the voltage is different.

Risk of injury to children!

Follow these precautions to prevent the TV from toppling over and causing injury to children:
• Never place the TV on a surface covered by a cloth or other material that can be pulled away.
• Ensure that no part of the TV hangs over the edge of the mounting surface.
• Never place the TV on tall furniture, such as a bookcase, without anchoring both the furniture and TV to the wall or a suitable support.
• Teach children about the dangers of climbing on furniture to reach the TV.

Risk of swallowing batteries!
The remote control may contain coin-type batteries which can easily be swallowed by small children. Keep these batteries out of reach of children at all times.

Risk of overheating!

Never install the TV in a confined space. Always leave a space of at least 10 cm or 4 inches around the TV for ventilation. Ensure curtains or other objects never cover the ventilation slots on the TV.

Lightning storms
Disconnect the TV from the power outlet and antenna before lightning storms. During lightning storms, never touch any part of the TV, power cord or antenna cable.

Risk of hearing damage!
Avoid using earphones or headphones at high volumes or for prolonged periods of time.

Low temperatures
If the TV is transported in temperatures below 5°C or 41°F, unpack the TV and wait until the TV temperature reaches room temperature before connecting the TV to the power outlet.

Lightning storms

Disconnect the TV from the power outlet and antenna before lightning storms. During lightning storms, never touch any part of the TV, power cord or antenna cable.

Risk of hearing damage!

Avoid using earphones or headphones at high volumes or for prolonged periods of time.

Low temperatures

If the TV is transported in temperatures below 5°C or 41°F, unpack the TV and wait until the TV temperature reaches room temperature before connecting the TV to the power outlet.

Screen care

• Never touch, push, rub or strike the screen with any object.
• Unplug the TV before cleaning.
• Clean the TV and frame with a soft damp cloth and wipe gently. Avoid touching the Ambilight LEDs on the backside of the TV. Never use substances such as alcohol, chemicals or household cleaners on the TV.
• To avoid deformations and colour fading, wipe off water drops as quickly as possible.
• Avoid stationary images as much as possible. Stationary images are images that remain onscreen for extended periods of time. Stationary images include onscreen menus, black bars, time displays, etc. If you must use stationary images, reduce screen contrast and brightness to avoid screen damage.

Temperature and humidity

In rare occasions, depending on temperature and humidity, minor condensation can occur on the inside of the TV glass front (on some models). To prevent this, do not expose the TV to direct sunlight, heat or extreme humidity. If condensation occurs, it will disappear spontaneously while the TV is playing for a few hours. The condensation moisture will not harm the TV or cause malfunction.

3

TV

3.1

Switch on

Switch on and off

Make sure you plugged in the mains power on the back of the TV before you switch on the TV.
If the red indicator light is off, press the small key ⏻ on the right side of the back of the TV to put the TV in standby - the red indicator will light up.

With the TV in standby, press ⏻ on the remote control to switch the TV on. Alternatively, you can use the **CH+**, **CH-** and ⌂ key to switch the TV on.

Quick start
To switch on the TV faster than usual, you can set the TV in **Quick start** mode.
In **Help**, press ▬ **List** and look up **Quick start** for more information.

Switch to standby
To switch the TV to standby, press ⏻ on the remote control.

Switch off
To switch the TV off, press the small key ⏻ on the right of the TV on the back. There is no red indicator light. The TV is still connected to the mains power but consumes a minimum of energy. To switch off the TV completely, disconnect the power plug.
When disconnecting the power plug, always pull the power plug, never the cord. Ensure that you have full access to the power plug, power cord and outlet socket at all times.

Quick start

With Quick start, the TV can start up faster than usual. When you switch the TV on from standby the TV picture already appears after a few seconds, if Quick start is activated.

The TV can remember your daily habit of watching TV. Some time before you usually switch on the TV, Quick start will activate automatically, allowing you to switch on quickly. Alternatively, you can select up to 3 fixed time frames a day during which the TV is ready to switch on quickly.

When you switch the TV back to standby, Quick start remains active until the set time frame ends.

Activate
To set the Quick start activation, press ⌂ and select ⚙ **Setup** and press **OK** to open the Setup menu.
Select **TV settings** > **General settings** > **Quick start** > **Activation**. You can select Automatic or Manual.

- **Automatic**
Select **Automatic** to activate Quick start automatically. The TV remembers your watching habit and activates Quick start during these time frames. With Automatic, the TV can set up to 4 time frames of 1 hour.

- **Manual**
Select **Manual** to activate Quick start during 3 fixed time frames a day. As an example, you can set a time frame in the morning, one at noon and one in the evening. For each time frame, you can set the time span yourself.
If Quick start is set to Manual, you can also select a **Standby delay**. With Standby delay, you can set the TV to keep Quick start active for some time after you switched the TV to standby. You can set the delay to up to 1 hour in steps of 15 minutes.

Specifics
The TV clock has to work properly to activate Quick start.
Quick start activation cannot be longer than a 4 hour time frame.
Quick start increases the energy consumption during standby.

3.2

Remote control

Top



1 - ⏻ **Standby**
To switch the TV on or back to standby.
2 - Playback and record keys
• Play ▶, to playback
• Pause ❚❚, to pause playback
• Stop ■, to stop playback
• Rewind ◀◀, to rewind
• Fast Forward ▶▶,to wind fast forward
• Record ●, to record now
3 - GUIDE
To open or close the TV guide.
4 - SOURCE
To open or close the list of connections.
5 - 3D
To open or close the 3D menu.
6 - AMBILIGHT
To switch Ambilight on or off and to switch Ambilight on in standby.
7 - FORMAT
To open or close the Format menu.
8 - TV
To switch back to watching channels.

Middle

1 - Home
To open or close the home menu.
2 - LIST
To open or close the channel list or your list of photos, music or videos.
3 - EXIT
To quit an interactive TV application, like Hbb TV.
4 - Back
To switch back to the previous channel you selected. To close a menu without changing a setting. To go back to the previous Smart TV Internet page.
5 - SMART TV
To open the Smart TV start page.
6 - INFO
To open or close Info.
7 - OK key
To confirm a selection.
8 - Arrow keys
To navigate up, down, left or right.
8 - OPTIONS
To open or close the Options menu.

Bottom



1 - CH-, Channel - / Previous page
To switch to the previous channel in the channel list, the previous page in Text or the previous chapter on a disc.
2 - CH+, Channel + / Next page
To switch to the next channel in the channel list, the next page in Text or the next chapter on a disc.
3 - Volume - and **+**
To adjust the volume level.
4 - Colour keys
Direct selection of options. Blue key information on what is selected and direct link to Help.
5 - Number keys and **text keypad**
To select a TV channel directly or to enter text.
6 - SUBTITLE
To switch subtitles on, off or on during mute.
7 - TEXT
To open or close Text.
8 - , Mute
To mute the sound or to restore it.

Keyboard

Overview

Qwerty and Azerty

Overview of a Qwerty / Azerty keyboard.*



1 - Fn key - To type a number or punctuation character.
2 - aA **Shift** - To type uppercase letters.
3 - ␣ **Spacebar**
4 - Arrows for navigation.

5 - Enter - To confirm the text you entered.
6 - Backspace - Deletes the character in front of the text cursor.
7 - Ω Special character - To open the onscreen keyboard to select accented letters or symbols.
8 - Azerty letter - Letters available if the keyboard layout is set to Azerty in the Setup menu.

* Your remote control has a Qwerty / Azerty or a Qwerty / Cyrillic keyboard, depending on your region.

Qwerty and Cyrillic

Overview of a Qwerty / Cyrillic keyboard.*



1 - Fn key - To type a number or punctuation character.
2 - ⬆aA Shift - To type uppercase letters.
3 - ␣ Spacebar
4 - Arrows for navigation.
5 - Enter - To confirm the text you entered.
6 - Backspace - Deletes the character in front of the text cursor.
7 - Ω Special character - To open the onscreen keyboard to select accented letters or symbols.
8 - Cyrillic keyboard switch - To switch to the Cyrillic keyboard or back to Qwerty.
9 - Cyrillic letter - Letters available if the keyboard is switched to Cyrillic.

* Your remote control has a Qwerty / Azerty or a Qwerty / Cyrillic keyboard, depending on your region.

Writing text

With the keyboard on the back of the remote control, you can write text in any text field on screen. Turn the keyboard facing upwards to activate the keyboard keys. Hold the remote control with two hands and type with both thumbs.



Enter text

To enter text in a text field on screen, select the text field and start typing.
Press **Enter** to confirm the text.

Uppercase and lowercase

To type an uppercase letter, press the **⬆aA** (Shift) key just before you type the letter.
To type several uppercase letters consecutively, press and hold the **⬆aA** key while typing. To type uppercase constantly, press the **⬆aA** key for 2 seconds to switch the keyboard in uppercase mode.
To switch out of uppercase mode, press the **⬆aA** key again. If no keys are pressed for 20 seconds, the uppercase mode switches off automatically. Also, if you press another modifier key, like **Fn** or **Ω**, you switch out of uppercase mode.

Numbers and punctuation characters

To type a number or punctuation character, press the **Fn** key just before you type the number or punctuation character you need. You can switch the Fn mode on or off as you do for the uppercase mode.

Internet

You can use the **Fn** key to enter **www.** or **.com**.

Accented letters and symbols

Accented letters and symbols are not available on the remote control keyboard. To type such a character, you can open the onscreen keyboard.

To open the onscreen keyboard, press **Ω**. In the onscreen keyboard, you can navigate to the character you need. Switch the keyboard layout with the colour keys. Press **OK** to enter a character. The onscreen keyboard disappears when you press a character on the remote control keyboard.

Alternatively, you can enter special characters with the remote control SMS/text keypad on the front of the remote control.

Qwerty, Azerty and Cyrillic keyboard

The standard layout of the remote control keyboard is Qwerty.

Azerty keyboard

Depending on your region, the remote control keyboard can be set to Azerty. The Azerty characters are shown at the top right of the relevant keys.
To set the keyboard layout to Azerty, . . .
1 - Press ⌂ and select ⚙ Setup and press **OK** to open the Setup menu.
2 - Select **TV settings** > **General settings** > **Remote control keyboard**.
3 - Select **QWERTY** or **AZERTY**.

Cyrillic keyboard

Depending on your region, the remote control keyboard can be switched to Cyrillic characters.
The Cyrillic characters are shown at the top right of the keyboard keys.
To write Cyrillic characters, press on the remote control.
Press again to switch back to Qwerty.

Pointer

About pointer

Instead of navigating the screen with the arrow keys, you can use the pointer. You can move the pointer - a small circle - over the TV screen by moving the remote control. Just like you move the cursor on a computer screen with a mouse.

You can use the pointer to navigate **Smart TV Apps*** and **Internet pages** on TV. Some Smart TV Apps might not support the use of the pointer. When the pointer is not available, you can use the arrow keys to navigate the screen. You can adjust the speed of the pointer or if you never want to use the pointer, you can switch it off.

*Gradually more Smart TV Apps will become available for use with the pointer.

Using the pointer

When you open the Smart TV start page, the pointer is shown in the middle of the TV screen.

Put your thumb on the **OK** key - do not press it - and move the remote control from the wrist, no need to move your arm. You can let go of the OK key and leave the pointer where it is. You can move the remote control and pick up the pointer again when you put your thumb back on the OK key.

When you press an arrow key to navigate, the pointer disappears. To recall the pointer, put your thumb on the OK key and briefly jiggle the remote control.

When you hover the pointer over a link . . .
1 - The pointer gets a dot inside the circle.
2 - Press **OK** to open the link.

When you hover the pointer over a text field . . .
Press **OK** to enter text.

Speed

You can adjust the speed of the pointer, the speed at which the pointer moves on screen.

To adjust the speed . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** and press **OK**.
3 - Select **General settings** > **Pointer and mouse speed** and press **OK**.
4 - Press the arrows ▲ (Up) or ▼ (Down) to increase or lower the speed.
5 - Press the arrow ► (Right) to test the speed you set.
6 - Press the arrow ◄ (Left) to return to the setting. You can adjust the setting again.
7 - Press **OK** to store and close the setting.

Switch off

If you want to navigate the Smart TV and Internet pages with the arrow keys only, you can switch off the pointer.

To switch off the pointer . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** and press **OK**.
3 - Select **General settings** > **Remote control pointer** and select **Off**.
4 - Press ⮌, repeatedly if necessary, to close the menu.

IR Sensor

The remote control of the TV uses RF (radio frequency) to send its commands to the TV. With RF, you do not need to point the remote control at the TV.

However, the TV can also receive commands from a remote control that uses IR (infrared) to send commands. If you use such a remote control, always make sure you point the remote control at the infrared sensor on the front of the TV.

Pairing

This remote control uses radio frequency (RF) to send its commands to the TV. Contrary to remote controls using infrared signals, with this remote control you can send commands without pointing at the TV.

With no need to point the remote control, using the keyboard on the back or sending commands from another room - changing the volume or switching channels - is easy. Additionally, the TV can notify you when the battery power of the remote control is low.

Pairing the remote control

For the remote control to communicate with the TV, both TV and remote control should be paired with each other. Once paired, you cannot use the remote control to control another TV.
When you started the initial TV installation, the TV invited you to press the **OK** key, and by doing so, the pairing was done.
When you switch off the TV, the pairing is stored. You can pair up to 5 remote controls with this TV.

Pairing again
You can pair another remote control with this TV.
The method to pair a remote control is different for a remote control already paired with another TV compared with a remote control that is not paired yet.
• **The remote control is paired with another TV**
To pair, hold the Remote control close to the Philips logo (about 10cm) and press the Red and Blue key at the same time. A message will appear if pairing is successful.
• **The remote control is not paired yet**
To pair, hold the Remote control close to the Philips logo (about 10cm) and press **OK**. A message will appear if pairing is successful.

For retail
To pair a new - not yet paired - TV with a remote control which is already paired with another TV, hold the Remote control close to the Philips logo (about 10cm) and press the Red and Blue key at the same time. A message will appear if pairing is successful.

Batteries

The TV will notify you when the battery power of the remote control is low.

To replace the batteries, open the battery compartment on the keyboard side of the remote control.

1 - Use a toothpick or other small, blunt object and press the small, square shaped release button to open the lid.
2 - Press the small lever next to the blue clip to release the clip.
3 - Replace the old batteries with 2 type AAA-LR03-1.5V alkaline batteries. Make sure the + and the - ends of the batteries line up correctly.
4 - Press the blue clip down until it clicks.
5 - Reposition the battery cover and press it until it clicks.

Put the remote control down for about 15 seconds to calibrate the pointer.



Remove the batteries if you are not using the remote control for a long time.
Dispose of batteries according to the end of use directives.
In **Help**, press **List** and look up **End of use** for more information.

Cleaning

Your remote control is treated with a scratch-resistant coating.

To clean the remote control, use a soft damp cloth. Never use substances such as alcohol, chemicals or household cleaners on the remote control.

3.3
TV channels

Watching TV channels

Switch channels

To watch TV channels, press **TV**. The TV tunes to the TV channel you last watched.

Alternatively, press to open the Home menu and select **Watch TV** and press **OK**.

Switch channels
To switch channels, press **CH+** or **CH-**. If you know the channel number, type in the number with the number keys. Press **OK** after you entered the number to switch channel.
To switch back to the previously tuned channel, press .

To switch to a channel from a channel list
While watching a TV channel, press **LIST** to open the channel lists.
Select a list in the row of tabs.

In a channel list, navigate to a TV channel or radio station. With the highlight on its icon, press **OK** to switch to the TV channel or listen to the radio station.
The channel list can have several pages with channels. To view the next or previous page, press **CH-** or **CH+**.
To close the channel lists without switching channel, press **LIST** again.

Radio channels
If digital broadcasting is available, digital radio stations are installed during installation. Switch to a radio channel just like you switch to a TV channel. A Cable (DVB-C) channel installation usually places radio stations from channel number 1001 onwards.

Options on channels

While watching a channel, depending on the type of channel (analogue or digital) you are watching or depending on the TV settings you made, some options are available.

Open the options
While watching a channel, press **OPTIONS** and select the **Options** tab in the menu bar.

Universal access
With Universal access switched on, you can set some options for hearing impaired and visually impaired people.
In **Help**, press **List** and look up **Universal access** for more information.

Video selection
Digital TV channels can offer multi video signals (multi-feed broadcasts), different camera viewpoints or angles of the same event or different programmes on one TV channel. The TV shows a message if any such TV channels are available.

Subtitles
Switch **Subtitles on** or **Subtitles off** with this option. Select **On during mute** to show subtitles only when the sound is muted with .

Subtitle language
For digital broadcast, you can select an available subtitle language temporarily if none of your preferred languages are available.
In **Help**, press **List** and look up **Subtitles** for more information.

Audio languages
For digital broadcast, you can select an available audio language temporarily if none of your preferred languages are available.
In **Help**, press **List** and look up **Audio languages** for more information.

Dual I-II
If an audio signal contains two audio languages but one language - or both - has no language indication, this option is available.

Common interface
If prepaid premium content is available from a CAM, you can set the provider settings with this option.

HbbTV on this channel
You can block the HbbTV pages from a channel that offers HbbTV.
In **Help**, press **List** and look up **HbbTV** for more information.

Status
Select **Status** to view technical information on the channel (if it is analogue or digital) or a connected device you are watching.

Channel lists

The channel lists

In the channel lists, you can find all installed TV and radio channels.

Next to the channel list **All**, which holds all installed channels, you can set up a list of **Favourites**, view the installed **Radio** stations separately or discover the newly added channels in **New**.

To switch to a channel from a channel list
While watching a TV channel, press **LIST** to open the channel lists.
Select one of the channel lists.

In a channel list, navigate to a channel or radio station. With the highlight on its icon, press **OK** to switch to the channel or listen to the radio station.
The channel list can have several pages with channels. To view the next or previous page, press **CH-** or **CH+**.
To close the channel lists without switching channel, press **LIST** again.

Mark as favourite
In the channel list **All**, you can set any channel as a favourite channel.
Navigate to the channel in the list and press **Mark as favourite**. The channel is added to the Favourite channel list.

Channel list options
According to the channel list on screen, press **OPTIONS** to select the following options:
- Digital / Analogue
- Free / Scrambled
- Lock or Unlock

Channel logos

In some countries, the TV can show the channel logos. If you do not want these logos to appear, you can switch them off.
To switch off **Channel logos** . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **General settings** > **Channel logos** and press **OK**.
3 - Select **Off** and press **OK**.
4 - Press ⮌, repeatedly if necessary, to close the menu.

Rename channels

You can rename channels in the channel list.
1 - Select the channel you want to rename in one of the channel lists - **All**, **Favourites**, **Radio** or **New**.
2 - Press ▬ **Rename**. You can enter text with the remote control keyboard or open the on-screen keyboard.

With the remote control keyboard

To delete a character, position the cursor behind the character and press **# del**.
To enter a character, press the character on the keyboard.
When you are ready, press **Enter** to select **Done**. Press **Enter** again to finish renaming.
For more information on using the keyboard, press ▬ **LIST** and look up **Remote control, keyboard**.



With the on-screen keyboard.

To open the on-screen keyboard, place the cursor in the name text field and press **OK**.
To delete the character in front of the cursor, press ▬ **Backspace**.
To enter a character, select the character with the arrow keys and press **OK**.
To select uppercase letters, press ▬.
To select numbers or special characters, press ▬.
When you are ready, press ⮌ to close the on-screen keyboard.
To finish renaming, select **Done** and press **OK**.

Reorder channels

You can reorder -reposition- channels in the Favourite channel list.

In **Help**, press ▬ **List** and look up **Favourite channels** for more information.

Favourite channels

You can create a favourite channel list that only holds the channels you want to watch. With the Favourite channel list selected, you will only see your favourite channels when you switch through channels.

Create your Favourite channel list

1 - While watching a TV channel, press ☰ **LIST** to open the channel lists.
2 - Select **Favourites**.
3 - If the list is empty, the TV asks you to start adding channels right now. Press **OK**.
4 - Use the arrow keys to select a channel and press **OK** to make that channel a favourite channel. The order in which channels appear in the favourite list depends on the sequence in which you add them.
5 - Press ▬ **Done** to finish selecting favourite channels.

Add or remove favourites

To add or remove favourite channels from the Favourite channel list, open the list and press ⫶⫶ **OPTIONS**, select **Add / remove favourites** and press **OK**.
Use the arrow keys to select a channel and press **OK** to add or remove it from the favourites list.

Reorder

You can reorder -reposition- channels in the Favourite channels list.
1 - In the channel list **Favourites**, highlight the channel you want to reposition.
2 - Press ▬ **Move**.
3 - With the arrow keys, reposition the channel where you want it. Alternatively, you can enter the new position directly with the number keys.
4 - Press **OK** to confirm the position. Or, to cancel the repositioning, press ▬ **Cancel**.
You can highlight another channel and do the same.

Add or remove favourites in other channel lists

You can mark channels and radio stations as favourites from the **All**, **Radio** and **New** channel list.
In these lists, highlight a channel you want to add to the favourite list and press ▬ **Mark as favourite**. The channel is marked with a star ★ and added to the Favourite channel list.
To unmark a favourite channel, highlight the channel in any channel list and press ▬ **Unmark as favourite**. The channel is removed from the Favourite channels list.

Child lock

To prevent children from watching a channel or a programme, you can lock channels or lock age rated programmes.

Lock a channel

You can lock a channel to prevent children from watching it. To watch a locked channel you need to enter the Child lock code.
To lock a channel, while watching a TV channel, press ☰ **LIST** to open the **Channel lists**. In any list, select the channel you want to lock, press **OPTIONS** and select **Lock channel**. In a channel list, a locked channel is marked with a lock.
To unlock a channel, select the locked channel in the channel list and select the **Unlock channel** option. You will need to enter the Child lock code.

You cannot lock programmes from connected devices.

Parental rating

Some digital broadcasters have rated their programmes. When the rating is equal or higher than the rating you have set for your child's age, the programme will be locked.
To watch a locked programme you must enter the child lock code. The parental age rating is set for all channels.

Set an age rating

Press **Home** and select **Setup** and press **OK**.
Select **Channel settings** > **Child lock** > **Parental rating**.
To select an age rating, you must first enter your 4-digit child lock code. If no child lock code is set, you can set the code now.
When the code is entered, you can select the age rating.
When the rating of a programme is equal or higher than the rating you have set for your child's age, the programme will be locked. The TV will ask for the code to unlock the programme.
For some operators, the TV only locks programmes with a higher rating.

Set or change the code

To set the code or to change the current Child lock code, press **Home**, select **Setup** and press **OK**.
Select **Channel settings** > **Child lock** > **Change code**.
Enter the current code and then enter the new code twice.
The new code is set.

Forgotten your code?

If you have forgotten your code to unlock, call Consumer Care in your country. Find the telephone number on the documentation that came with the TV or go to www.philips.com/support.

Channel installation

Update channels

Automatic update

If you receive digital channels, you can set the TV to automatically update the list with new channels.
Alternatively, you can start a channel update yourself.

Automatic channel update

Once a day, at 6 AM, the TV updates the channels and stores new channels. New channels are stored in the All channels list but also in the New channels list. Empty channels are removed.
If new channels are found or if channels are updated or removed, a message is shown at TV start up. The TV must be in standby to automatically update channels.

To switch off the message at start up, press **Home**, select **Setup** and press **OK**.
Select **Channel settings** and press **OK**.
Select **Channel installation** > **Channel update message** > **Off**.

To switch off the Automatic channel update, press **Home**, select **Setup** and press **OK**.
Select **Channel settings** and press **OK**. Select **Channel installation** > **Automatic channel update** > **Off**.

Start an update

To start an update yourself, press **Home**, select **Setup** and press **OK**.
Select **Search for channels** and press **OK**.
Select **Update channels** and follow the instructions on screen.
The update may take a few minutes.

In certain countries, the Automatic channel update is done while watching TV or any moment when the TV is in standby.

New channels

New channels added with the automatic channel update are easy to find in the channel list **New**. The same new channels are also stored in the **All** or **Radio** channel list.

New channels are kept in the channel list New as long as you don't mark them as a favourite or tune to them.

In **Help**, press **List** and look up **Favourite channels** for marking channels as favourites.

Reinstall channels

You can search for and reinstall channels and leave all other TV settings untouched. Alternatively, you can do a full new TV installation.

If a child lock code is set, you will need to enter this code before you can reinstall channels.

Reinstall channels

To reinstall the channels only . . .
1 - Press **Home**, select **Setup** and press **OK**.
2 - Select **Search for channels** > **Reinstall channels** and press **OK**.
3 - Select **Antenna (DVB-T)** or **Cable (DVB-C)**. The channel search may take a few minutes. Follow the instructions on screen.

Full installation

To redo a full TV installation . . .
1 - Press **Home**, select **Setup** and press **OK**.

2 - Select **TV settings** > **General settings** > **Reinstall TV** and press **OK**. The installation may take a few minutes. Follow the instructions on screen.

Factory settings

Factory settings sets the TV back to the original TV settings for picture, sound and Ambilight.
To switch back to the original Factory settings . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **General settings** > **Factory settings** and press **OK**.
3 - Press **OK** to confirm.
4 - Press ↩, repeatedly if necessary, to close the menu.

Channel list copy

Introduction

Channel list copy is intended for dealers and expert users. In some countries, Channel list copy is only availble for copying satellite channels.

With **Channel list copy**, you can copy the channels installed on one TV onto another Philips TV of the same range. With Channel list copy, you avoid the time-consuming channel search by uploading a predefined channel list on a TV. Use a USB flash drive of minimum 1 GB.

Conditions

• Both TVs are from the same year range.
• Both TVs have the same hardware type. Check the hardware type on the TV type plate on the back of the TV. Typically noted as Q . . . LA
• Both TVs have compatible software versions.

Current version

You can check the current version of the TV software with **Current software info** in **Setup** > **Software settings**.

Copy channel list

Copy a channel list

1 - Switch on the TV which has its channels installed. Plug in a USB memory device.
2 - Press ⌂, select ⚙ **Setup** and press **OK**.
3 - Select **TV settings** > **General settings** > **Channel list copy** > **Copy to USB** and press **OK**. To copy the channel list from this TV, you might be asked to enter the Child lock code you entered during the installation.
4 - When copying is done, unplug the USB memory device.

Now you can upload the copied channel list onto another Philips TV.

Upload channel list

Upload a copied channel list

Depending on whether your TV is already installed or not, you must use a different way to upload a channel list.

To a TV that is not yet installed

1 - Plug in the power plug to start the installation and select language and country. You can skip Search for channels. Finish the installation.
2 - Plug in the USB memory device that holds the channel list of the other TV.
3 - To start the channel list upload, press ⌂, select ⚙ **Setup** and press **OK**.
4 - Select **TV settings** > **General settings** > **Channel list copy** > **Copy to TV** and press **OK**. You might be asked to enter the Child lock code of this TV.
5 - The TV notifies you if the channel list is copied to the TV successfully. Unplug the USB memory device.

To an already installed TV

1 - Verify the country setting of the TV. (To verify this setting, press ⌂, select ⚙ **Setup** and press **OK**. Select **Search for channels** > **Reinstall channels** and press **OK**. Press ↩ and later **Cancel** to leave the Search for channels.)
If the country is correct continue with step 2.
If the country is not correct, you need to start a reinstallation. To start the reinstallation, press ⌂, select ⚙ **Setup** and press **OK**. Select **TV settings** > **General settings** > **Reinstall TV** > **OK**. Select the correct country and skip the Search for channels. Finish the installation. When done, continue with step 2.
2 - Plug in the USB memory device that holds the channel list of the other TV.
3 - To start the channel list upload, press ⌂, select ⚙ **Setup** and press **OK**.
4 - Select **TV settings** > **General settings** > **Channel list copy** > **Copy to TV** and press **OK**. You might be asked to enter the Child lock code of this TV.
5 - The TV notifies you if the channel list is copied to the TV successfully. Unplug the USB memory device.

DVB-T or DVB-C

DVB-T or DVB-C reception

If both DVB-T and DVB-C reception is available in your country and if this TV is ready to receive DVB-T and DVB-C for your country, you have selected one or the other during the channel installation.

If you want to change the DVB setting to start a new channel installation, press ⌂, select ⚙ **Setup** and press **OK**.
Select **Channel settings** and press **OK**.
Select **Channel installation** > **Antenna connection** > **Antenna (DVB-T)** or **Cable (DVB-C)** and press **OK**. Select the DVB setting you want.

DVB-C channel installation

For ease of use, all DVB-C settings are set to automatic.
If your DVB-C provider gave you specific DVB-C values, the network ID or network frequency, enter these values when the TV asks for them during installation.
It might be necessary to adjust the scanning (full or quick scan) or enter a specific symbol rate in the **Settings** menu while installing. To set a **Symbol rate**, first set the Symbol rate to **Manual**.

Channel number conflicts

In some countries, different TV channels (broadcasters) might have the same channel number. While installing, the TV shows the list with channel number conflicts. You need to select which TV channel you want to install on a channel number with multiple TV channels.

DVB-T + DVB-C
If you can use a DVB-T antenna input but also a DVB-C input, you can set up your TV for both DVB-T and DVB-C. Install one system followed by the other with the necessary settings.
Once each system is installed, you need to switch the antenna input signal on the **Antenna** connection on the back of the TV and set the TV in the appropriate system to view the installed channels on TV.
To select the DVB-T or DVB-C setting, see above.

DVB settings

Symbol rate mode

If your cable provider did not give you a specific **symbol rate** value to install the TV channels, leave the **Symbol rate mode** setting on **Automatic**.
If you received a specific symbol rate value, select **Manual**. However, the value you received could be in the predefined list of symbol rates already. Select **Predefined symbol rates** to check if your value is available automatically.

Predefined symbol rates

With the **Symbol rate mode** set to **Automatic**, the TV will use 1 of the predefined symbol rates as used by most cable providers in your country.

Symbol rate 1

With the **Symbol rate mode** set to **Manual**, you can enter the symbol rate value you received from your cable provider. To enter the value, use the number keys.

Symbol rate 2

With the **Symbol rate mode** set to **Manual**, you can enter a second symbol rate value you received from your cable provider. To enter the value, use the number keys.

Network frequency mode

If you intent to use the fast **Quick scan** method in **Frequency scan** to search for channels, select **Automatic**. The TV will use 1 of the predefined network frequencies (or HC - homing channel) as used by most cable providers in your country.
If you received a specific network frequency value to search for channels, select **Manual**.

Network frequency

With the **Network frequency mode** set to **Manual**, you can enter here the network frequency value received from your cable provider. To enter the value, use the number keys.

Frequency scan

Select the method of searching for channels. You can select the faster **Quick scan** method and use the predefined settings used by most cable providers in your country.
If this results in having no channels installed or if some channels are missing, you can select the extended **Full scan** method. This method will take more time to search for and install channels.

Frequency step size

The TV searches for channels in steps of **8MHz**.
If this results in having no channels installed or if some channels are missing, you can search in smaller steps of **1MHz**. Using the 1MHz steps will take more time to search for and install channels.

Digital channels

If you know your cable provider is not offering digital channels, you can skip searching for digital channels.
Select **Off**.

Analogue channels

If you know your cable provider is not offering analogue channels, you can skip searching for analogue channels.
Select **Off**.

Free / Scrambled

If you have a subscription and a CAM - Conditional Access Module for pay TV services, select **Free + scrambled**. If you did not subscribe to pay TV channels or services, you can select **Free channels** only.

In **Help**, press **List** and look up **CAM - Conditional Acces Module** for more information.

Reception quality

If you receive digital channels, you can check the quality and signal strength of a channel.

If you have your own antenna, you can reposition the antenna to try and improve the reception.
To check the reception quality of a digital channel, switch to the channel.
Press **Home**, select **Setup** and press **OK**.
Select **Channel settings** and press **OK**. Select **Channel installation** > **Digital : reception test** and press **OK**.

The digital frequency is shown for this channel. If the reception is poor, you can reposition your antenna. To check the signal quality of this frequency again, select **Search** and press **OK**.
To enter a specific digital frequency yourself, use the remote control digit keys. Alternatively, select the frequency, position the arrows on a number with ◄ and ► and change the number with ▲ and ▼. To check the frequency, select **Search** and press **OK**.

If you use DVB-C to receive channels, the options **Symbol rate mode** and **Predefined symbol rates** are available. For Symbol rate mode, select **Automatic**, unless your cable provider gave you a specific symbol rate value. To enter the symbol rate value, use the number keys.

Manual installation

Analogue TV channels can be manually installed, channel by channel.

To install analogue channels manually, press ⌂, select ⚙ **Setup** and press **OK**.
Select **Channel settings** and press **OK**.
Select **Channel installation** > **Analogue : manual installation** and press **OK**.

1 - System
To set up the TV system, select **System** and press **OK**.
Select your country or the part of the world where you are now.
2 - Find channel
To find a channel, select **Find channel** and press **OK**. Select **Search** and press **OK**. You can also enter a frequency yourself. If the reception is poor, press **Search** again. If you want to store the channel, select **Done** and press **OK**.
3 - Fine tune
To fine tune a channel, select **Fine tune** and press **OK**. You can fine tune the channel with ▲ or ▼.
If you want to store the channel found, select **Done** and press **OK**.
4 - Store
You can store the channel on the current channel number or as a new channel number.
Select **Store current channel** or **Store as new channel**.

You can redo these steps until you found all available analogue TV channels.

Picture format

If black bars appear on top and bottom or on both sides of the picture, you can adjust the picture format to a format that fills the screen.

While watching a TV channel, press ⧉ **FORMAT** to open the **Picture format** menu.
Select a format from the list and press **OK**.

Picture formats

The following formats are available according to the picture on screen:

• **Auto fill**
Automatically enlarges the picture to fill the screen. Picture distortion is minimal, subtitles remain visible. Not suitable for PC input. Some extreme picture formats can still show black bars.

• **Auto zoom**
Automatically zooms in the picture to fill the screen as much as possible without distortion. Black bars may be visible. Not suitable for PC input.

• **Super zoom**
Removes the black bars on the side of 4:3 broadcasts. The picture is adjusted to fit the screen.

• **Movie expand 16:9**
Scales the picture to a 16:9 format.

• **Wide screen**
Stretches the picture to a 16:9 format.

• **Unscaled**
Expert mode for HD or PC input. Pixel for pixel display. Black bars may appear with pictures from a computer.

Text

Text pages

Open Text
To open Text while you are watching TV channels, press **TEXT**.
To close Text, press **TEXT** again.

Select a Text page
To select a page …
• Enter the page number with the number keys.
• Press ◄ or ►
• Press ▲ or ▼.
• Press a colour key to select a colour-coded subject at the bottom of the screen.

Text sub-pages
A Text page number can hold several subpages. The subpage numbers are shown on a bar next to the main page number. To select a subpage, press ◄ or ►.

T.O.P. Text pages
Some broadcasters offer T.O.P. Text.
To open T.O.P. Text pages within Text, press ⚙ **OPTIONS** and select **T.O.P. overview**.

Favourite pages

The TV makes a list of the last 10 Text pages you opened. You can easily reopen them again in the Favourite Text pages column.
1 - In Text, select the star in the top left corner of the screen to show the column of favourite pages.
2 - Press ▼ or ▲ to select a page number and press **OK** to open the page.
You can clear the list with the option **Clear favourite pages**.

Search Text
You can select a word and scan Text for all occurrences of this word.
Open a Text page and press **OK**.
Select a word or number with the arrow keys.
Now press **OK** again to jump immediately to the next occurrence of this word or number.
Press **OK** again to jump to the subsequent occurrence.
To stop the search, press ▲ until nothing is selected.

Text from a connected device
Some connected devices that receive TV channels can also offer Text.
To open Text from a connected device, press ⌂, select the device and press **OK**.
While watching a channel on the device, press **OPTIONS**, select Show device keys and select the ☰ key and press **OK**.
Press ⮌ to hide the device keys.
To close Text, press ⮌ again.

Digital Text (UK only)
Some digital TV broadcasters offer dedicated Digital Text or interactive TV on their digital TV channels. This includes normal Text using the number, colour and arrow keys to select and navigate.
To close Digital Text, press ⮌.

Text options

In Text, press **OPTIONS** to select the following:
- Freeze page
- Dual screen
- T.O.P. overview
- Enlarge
- Reveal
- Cycle subpages
- Hide favourite pages
- Clear favourite pages
- Language

Freeze page
To stop the automatic rotation of subpages, press **OPTIONS** and select **Freeze page**.

Dual screen / Full screen
To show the TV channel and Text alongside each other, press **OPTIONS** and select **Dual screen**.
Select **Full screen** to switch back to full screen view.

T.O.P. overview
To open T.O.P. Text, press **OPTIONS** and select **T.O.P. overview**.

Enlarge
To enlarge the Text page for more comfortable reading, press **OPTIONS** and select **Enlarge**. To scroll down the page, press ▼ or ▲.

Reveal
To unhide hidden information on a page, press **OPTIONS** and select **Reveal**.

Cycle subpages
To cycle subpages when these are available, press **OPTIONS** and select **Cycle subpages**.

Language
To switch the group of characters that Text uses to display text correctly, press **OPTIONS** and select **Language**.

Text setup

Text language
Some digital TV broadcasters have several Text languages available.
To set your primary and secondary Text language, press ⌂, select ⚙ **Setup** and press **OK**.
Select **Channel settings** and select **Primary** or **Secondary Text** and select your preferred Text languages.

Text 2.5
If available, Text 2.5 offers more colours and better graphics. Text 2.5 is activated as a standard factory setting.
To switch it off, press ⌂, select ⚙ **Setup** and press **OK**.
Select **TV settings** > **Preferences** > **Text 2.5.**

Interactive TV

What is iTV?

With interactive TV, some digital broadcasters combine their normal TV programme with information or entertainment pages. On some pages, you can respond to a programme or vote, do online shopping or pay for a video-on-demand programme.

HbbTV, MHEG, . . .
Broadcasters use various interactive TV systems : HbbTV (Hybrid Broadcast Broadband TV) or iTV (Interactive TV - MHEG). Interactive TV is sometimes referred to as Digital Text or Red button. But each system is distinct.
Visit the broadcasters Internet website for more information.

What you need
Interactive TV is only available on digital TV channels. To enjoy the full benefits of Interactive TV, you need a high-speed (broadband) Internet connection to the TV.

---

iTV pages

Open iTV pages
Most channels that offer HbbTV or iTV invite you to press the ▬ (red) key or **OK** key to open their interactive programme.

Navigate iTV pages
You can use the arrow and colour keys, the number keys and the ⮌ key to navigate the iTV pages. You can use the ▶ (Play), ❚❚ (Pause) and ■ (Stop) keys to watch videos within iTV pages.

Digital Text (UK only)
To open Digital Text, press **TEXT**. To close, press ⮌.

Close iTV pages
Most iTV pages inform you which key to use to close.
To force an iTV page to close, switch to the next TV channel and switch back.

3.4
TV guide

Open TV Guide

With the TV guide you can view a list of the current and scheduled TV programmes of your channels. Depending on where the TV guide information (data) is coming from, analogue and digital channels or only digital channels are shown. Not all channels offer TV guide information.

Open TV guide
To open the TV guide, press **GUIDE**.
Press **GUIDE** again to close.

The first time you open the TV guide, the TV scans all TV channels for programme information. This may take several minutes. TV guide data is stored in the TV.

Switch to a programme
From the TV guide, you can switch to a current programme.
To select a programme, use the arrow keys to highlight the programme name.
Navigate to the right to view programmes scheduled later that day.
To switch to the programme (channel), select the programme and press **OK**.

View programme details
To call up the details of the selected programme, press [i] **INFO**.

Change day
The TV guide can show scheduled programmes for the upcoming days (maximum up to 8 days).
If the TV guide information comes from the broadcaster, you can press **CH+** to view the schedule of one of the next days.
Press **CH-** to go back to the previous day.
Alternatively, you can press **OPTIONS** and select **Change day**.
Select **Previous day**, **Today** or **Next day** and press **OK**, to select the day of the schedule.
If the TV guide information comes from the Internet, press **Select day**.

Set a reminder
You can set reminders that alert you of the start of a programme with a message on screen.
To set a reminder, select the programme in the schedule and press the colour key of **Set reminder**. The programme is marked with a clock.
To cancel the reminder, press the colour key of **Clear reminder**.
To view a list of all reminders you have set, press the colour key of **Scheduled reminders**.

Search by genre
If the information is available, you can look up scheduled programmes by genre like movies, sports, etc.
To search for programmes by genre, press **OPTIONS** and select **Search by genre**.
Select a genre and press **OK**. A list with the found programmes appears.

Recordings

From the TV guide, you can instantly record or schedule a recording of a TV programme. To store the recordings, connect a USB Hard Drive to the TV.

For more information on Recording, press **List** and look up **Recording**.

Receiving TV guide info

The TV guide receives information (data) from broadcasters or from the Internet. In some regions and for some channels, TV guide information might not be available.

The TV comes with the information set to **From the broadcaster**.

If TV guide information comes from the Internet, the TV guide can also list analogue channels next to the digital channels. In the TV guide menu, you can view the current channel you are watching in a small screen.

Set the TV guide information
If the TV is connected to the Internet, you can set the TV to receive the TV guide information from the broadcaster.
To set the TV guide information, press **Setup** and press **OK**.
Select **TV settings** > **General settings** > **TV guide**.
Select **From the broadcaster** or **From the Internet**.

Missing recordings

When some recordings seem to have disappeared from the list of recordings, the TV guide info (data) might have changed. Recordings made with the setting **From the broadcaster** become invisible in the list if you switch the setting to **From the Internet** or vice versa. The TV might have switched to **From the Internet** automatically.
To make the recordings available in the list of recordings, switch to the setting that was selected when the recordings were made.

3.5
Switch to devices

Source list

In the list of connections - the Source menu - you can find the devices connected to the TV.
From this Source menu, you can switch to a device.

Source menu

To open the Source menu, press SOURCE.
To switch to a connected device, select the device with the arrows ◄ (left) or ► (right) and press **OK**.
For some devices (HDMI-CEC devices), you can select an activity directly in the list underneath the device icon.
Select the device and select an activity and press **OK**.
To close the Source menu without switching to a device, press again.

Automatic detection

When you connect a new device to the TV, the device is detected automatically and put in the Source menu. The device is shown as an icon (the device type) and has a name. If the device type does not correspond with the device, e.g. the TV says it is a player but it is not, you can change the type.
To change the type of the device, press **Device type** and select a type that fits the device and press **OK**.
If the name does not fit the device or you want to give the device a name of your own, press **Rename**. Use the remote control keypad to enter a new name.

An appropriate device type helps you in using the device. The device type determines picture and sound styles, resolution values, specific settings or the position within the Source menu.

When you connect a new device to the TV, the icon of the device jumps to the front of the Source menu.

If the TV does not detect the device automatically, select the connection you used to connected the device and adjust the Device type and name.

Original name and icon

To restore the device icon to its original name and type icon, press **OPTIONS**, select the **Options** tab in the menu bar and select **Original name and icon** and press **OK**.

Scan connections

To rescan all TV connections and update the Source menu, press **OPTIONS**, select the **Options** tab in the menu bar, select **Scan connections** and press **OK**.

From standby

With the TV in standby, you can switch on a connected device with your TV remote control.

Play

To switch on both disc player and TV from standby and start playing the disc or programme immediately, press ► (play) on the TV remote control.
The device should be connected with an HDMI cable and both TV and device must have HDMI CEC switched on.

Home Theatre System

You can switch on your Home Theatre System to listen to an audio disc or a radio channel and leave the TV in standby.
To only switch on the HTS, with the TV in standby, press **SOURCE** on the TV remote control.

EasyLink

With **EasyLink** you can operate a connected device with the TV remote control. EasyLink uses HDMI CEC to communicate with the connected devices. Devices must support HDMI CEC and must be connected with an HDMI connection.

In **Help**, press **List** and look up **EasyLink** for more information.

3.6
Subtitles and languages

Subtitles

Switch subtitles on
To open the Subtitle menu, press **SUBTITLE**.
You can switch subtitles**On** or **Off**.
To show subtitles when the broadcasted programme is not in your language - the language you set for the TV, select **Automatic**. Also, this setting will show subtitles when you mute the sound with .
For analogue channels, subtitles must be made available in **Text**.

Subtitles for analogue channels
For analogue channels, you need to make subtitles available for each channel manually.
1 - Switch to a channel and press **Text** to open Text.
2 - Enter the page number for subtitles, usually 888.
3 - Press **Text** again to close Text.
If you select On in the Subtitle menu when watching this analogue channel, subtitles will be shown if available.
To know if a channel is analogue or digital, switch to the channel and open **Status** in the **Options** menu.

Subtitles for digital channels
There is no need to set subtitles in Text for digital channels. Digital channels can offer several subtitle languages for a programme. You can set a preferred primary and secondary subtitle language. If subtitles in one of these languages are available, the TV will show them.
If none of the preferred subtitle languages are available, you can select another subtitle language which is available.

To set the primary and secondary subtitle language . . .
1 - Press , select **Setup** and press **OK**.
2 - Select **Channel settings** and select **Languages** > **Primary subtitles** or **Secondary subtitles** and press **OK**.
3 - Select a language and press **OK**.
4 - Press , repeatedly if necessary, to close the menu.

To select a subtitle language when none of your preferred languages are available . . .
1 - Press **OPTIONS**
2 - Select **Subtitle language** and select a language you want temporarily and press **OK**.

Audio language

Digital TV channels can broadcast audio with several spoken languages for a programme. You can set a preferred primary and secondary audio language. If audio in one of these languages is available, the TV will switch to this audio.
If none of the preferred audio languages is available, you can select another audio language which is available.

To set the primary and secondary audio language . . .
1 - Press , select **Setup** and press **OK**.
2 - Select **Channel settings** and select **Languages** > **Primary audio** or **Secondary audio** and press **OK**.
3 - Select a language and press **OK**.
4 - Press , repeatedly if necessary, to close the menu.

To select an audio language when none of your preferred audio language is available . . .
1 - Press **OPTIONS**
2 - Select **Audio language** and select an audio language you want temporarily and press **OK**.

Original language
If the digital channel holds the original language of a programme or movie, you can set the TV to automatically switch to that audio language. Set Original language to On to watch a dubbed movie in its original language (if the original language is available).
To set **Original language** . . .
1 - Press , select **Setup** and press **OK**.
2 - Select **Channel settings** and select **Languages** > **Original language** and press **OK**.
3 - Select **On** or **Off** and press **OK**.
4 - Press , repeatedly if necessary, to close the menu.

Audio languages for the hearing and visually impaired
Some digital TV channels broadcast special audio and subtitles adapted for people who are hearing or visually impaired.
In **Help**, press **List** and look up **Universal access** for more information.

Menu language

To change the language of the TV menus and messages . . .
1 - Press , select **Setup** and press **OK**.
2 - Select **TV settings** > **General settings** > **Menu language** and press **OK**.
3 - Select the language you want and press **OK**.
4 - Press , repeatedly if necessary, to close the menu.

3.7
Timers and clock

Sleeptimer

With the sleep timer, you can set the TV to switch to standby automatically after a preset time.

To set the sleep timer, press ⌂, select ⚙ **Setup** and press **OK**.
Select **TV settings** > **General settings** > **Sleep timer**. With the slider bar you can set the time to up to 180 minutes in increments of 5 minutes. If set to 0 minutes, the sleep timer is switched off.

You can always switch off your TV earlier or reset the time during the countdown.

Clock

To know what time it is, press **GUIDE** to find the time in the TV guide.

In some countries, digital broadcasts do not send UTC - Coordinated Universal Time information. The daylight saving change might be ignored and the TV might show an incorrect time.

To correct the TV clock, press ⌂, select ⚙ **Setup** and press **OK**.
Select **TV settings** > **General settings** > **Clock** and select **Country dependent**.
Select **Daylight saving** and select the appropriate setting.
To set the time and date manually, select **Manual**. Then select **Time** or **Date**.

When you record programmes with **Smart TV**, **Recording**, we recommend not to change the time and date manually.

Switch off timer

If you do not press a key on the remote control during a 4 hour period, or if the TV receives no input signal and receives no remote control commands for 10 minutes, the TV switches off automatically to save energy.

If you use the TV as a monitor or use a digital receiver to watch TV (a Set-top box - STB) and you do not use the remote control of the TV, you should deactivate the automatic switch off.

To deactivate, press ⌂, select ⚙ **Setup** and press **OK**.
Select **TV settings** > **General settings** > **Switch off timer** and set the slider bar to **0**.

In **Help**, press ▬ **List** and look up **Saving energy** for more information on environmentally friendly TV settings.

3.8
Picture settings

Picture style

For easy picture adjustment, you can select a preset setting with **Picture style**.

1 - While watching a TV channel, press **OPTIONS** to open the Options menu
2 - Select **Picture and sound** in the menu bar and select **Picture style**.
3 - Select a style and press **OK**.

Additionally, you can adjust a specific setting of a chosen Picture style, like Brightness or Contrast. The TV remembers the adjustments you made.

Adjust a Picture style

To adjust a Picture style . . .
1 - Select the style and press **OK**.
2 - Press ⌂, select ⚙ **Setup** and press **OK**.
3 - Select **TV settings**, navigate to the individual setting and adjust it.
4 - Press ↩ to close the menu to store your setting.

To return to the original Picture style values . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Picture** > **Picture style** and select the style you want to reset.
3 - Press ▬ **Reset**. The style is reset.

In **Help**, press ▬ **List** and look up **Picture** for adjusting separate picture settings.

The available Picture styles are . . .
- **Personal** - Your preferences made in Quick picture settings
- **Vivid** - Ideal for daylight viewing
- **Natural** - Natural picture settings
- **Movie** - Ideal for watching movies
- **Energy saving** - Energy-efficient settings
- **Standard** - Factory standard settings
- **Photo** - Ideal for viewing photos

Vivid

If the Picture style is switched back to **Vivid** every time you switch on the TV, the TV location is set to **Shop**. A setting meant for in-store promotion.
To set the TV for Home use . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **General settings** > **Location** and press **OK**.
3 - Select **Home** and press **OK**.
4 - Press ↩, repeatedly if necessary, to close the menu.

Backlight contrast

With **Backlight contrast**, you can adjust the contrast of the picture. If you are watching 3D pictures, this setting is switched to **3D backlight contrast**.

To adjust the contrast . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Picture** > **Backlight contrast**.
3 - Press ▶ (right) and adjust the value with ▲ (up) or ▼ (down).
4 - Press ⮌, repeatedly if necessary, to close the menu.

Colour

With **Colour**, you can adjust the colour saturation of the picture.

To adjust the colour . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Picture** > **Colour**.
3 - Press ▶ (right) and adjust the value with ▲ (up) or ▼ (down).
4 - Press ⮌, repeatedly if necessary, to close the menu.

Sharpness

With **Sharpness**, you can adjust the level of sharpness in fine detail of the picture.

To adjust the sharpness . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Picture** > **Sharpness**.
3 - Press ▶ (right) and adjust the value with ▲ (up) or ▼ (down).
4 - Press ⮌, repeatedly if necessary, to close the menu.

Noise reduction

With **Noise reduction**, you can filter out and reduce the level of image noise.

To adjust the noise reduction . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Picture** > **Noise reduction**.
3 - Press ▶ (right) and select **Maximum**, **Medium**, **Minimum** or **Off**.
4 - Press ⮌, repeatedly if necessary, to close the menu.

MPEG artefact reduction

With **MPEG artefact reduction**, you can smoothen the digital transitions in the picture. MPEG artefacts are mostly visible as small blocks or jagged edges in images.

To reduce the MPEG artefacts . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Picture** > **MPEG artefact reduction**.
3 - Press ▶ (right) and select **Maximum**, **Medium**, **Minimum** or **Off**.
4 - Press ⮌, repeatedly if necessary, to close the menu.

Pixel Precise HD

Perfect Natural Motion

With **Perfect Natural Motion**, you can reduce the motion judder, visible in movies on TV. Perfect Natural Motion makes any movement smooth and fluent.

To adjust the motion judder . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Picture** > **Pixel Precise HD** > **Perfect Natural Motion**.
3 - Press ▶ (right) and select **Maximum**, **Medium**, **Minimum** or **Off**.
4 - Press ⮌, repeatedly if necessary, to close the menu.

Clear LCD

With **Clear LCD**, you switch on a superior motion sharpness, better black level, high contrast with a flicker-free, quiet image and a larger viewing angle.

To switch on or off . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Picture** > **Pixel Precise HD** > **Clear LCD**.
3 - Press ▶ (right) and select **On** or **Off**.
4 - Press ⮌, repeatedly if necessary, to close the menu.

Advanced sharpness

With **Advanced sharpness**, you switch on a superior sharpness in line edges and contours.

To switch on or off . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Picture** > **Pixel Precise HD** > **Advanced sharpness**.
3 - Press ▶ (right) and select **On** or **Off**.
4 - Press ⮌, repeatedly if necessary, to close the menu.

Dynamic contrast

With **Dynamic contrast**, you can set the level at which the TV automatically enhances the details in the dark, middle and light areas of the picture.

To adjust the level . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Picture** > **Pixel Precise HD** > **Dynamic contrast**.
3 - Press ▶ (right) and select **Maximum**, **Medium**, **Minimum** or **Off**.
4 - Press ⮌, repeatedly if necessary, to close the menu.

Dynamic backlight

With **Dynamic backlight**, you can set the level at which power consumption can be reduced by dimming the intensity of the screen. Choose for the best power consumption or for the picture with the best intensity.

To adjust the level . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Picture** > **Pixel Precise HD** > **Dynamic backlight**.
3 - Press ▶ (right) and select **Best picture**, **Best power**, **Standard** or **Off**.
4 - Press ⮌, repeatedly if necessary, to close the menu.

Colour enhancement

With **Colour enhancement**, you can enhance the colour intensity and the details in bright colours.

To adjust the level . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Picture** > **Pixel Precise HD** > **Colour enhancement**.
3 - Press ▶ (right) and select **Maximum**, **Medium**, **Minimum** or **Off**.
4 - Press ⮌, repeatedly if necessary, to close the menu.

Advanced picture settings

Light sensor

The **Light sensor** adjusts the picture and Ambilight settings automatically to the lighting conditions of the room. You can switch Light sensor on or off.

To switch on or off . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Picture** > **Advanced** > **Light sensor**.
3 - Press ▶ (right) and select **On** or **Off**.
4 - Press ⮌, repeatedly if necessary, to close the menu.

Gamma

With **Gamma**, you can set a non-linear setting for picture luminance and contrast. Gamma is a setting intended for expert users.

To adjust the level . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Picture** > **Advanced** > **Gamma**.
3 - Press ▶ (right) and adjust the value with ▲ (up) or ▼ (down).
4 - Press ⮌, repeatedly if necessary, to close the menu.

Colour temperature

With **Colour temperature**, you can set the picture to a preset colour temperature or select **Custom** to set a temperature setting yourself with **Custom colour temperature**. Colour temperature and Custom colour temperature are settings intended for expert users.

To select a preset . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Picture** > **Advanced** > **Colour temperature**.
3 - Press ▶ (right) and select **Normal**, **Warm** or **Cool**. Select **Custom** if you want to set a colour temperature yourself.
4 - Press ⮌, repeatedly if necessary, to close the menu.

Custom colour temperature

With **Custom colour temperature**, you can set a colour temperature yourself. To set a Custom colour temperature, first select **Custom** in the **Colour temperature** setting to make the Custom colour temperature menu available. Custom colour temperature is a setting intended for expert users.

To set a custom colour temperature . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Picture** > **Advanced** > **Custom colour temperature**.
3 - Press ▶ (right).
4 - Select a setting with the arrow keys. (WP is white point and BL is black level.)
5 - Press **OK** to confirm a setting. You can also select one of the presets in this menu.
6 - Press ⮌, repeatedly if necessary, to close the menu.

Video contrast

With **Video contrast**, you can decrease the range of the video contrast. If you are watching 3D pictures, this setting is switched to **3D video contrast**. Video contrast and 3D video contrast are settings intended for expert users.

To adjust the level . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Picture** > **Advanced** > **Video contrast**.
3 - Press ▶ (right) and adjust the value with ▲ (up) or ▼ (down).
4 - Press ⮌, repeatedly if necessary, to close the menu.

Brightness

With **Brightness**, you can set the level of brightness of the picture signal. Brightness is a setting intended for expert users. We recommend non-expert users to adjust the brightness with the **Backlight contrast** setting.

To adjust the level . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Picture** > **Advanced** > **Brightness**.
3 - Press ▶ (right) and adjust the value with ▲ (up) or ▼ (down).

4 - Press ⮌, repeatedly if necessary, to close the menu.

Game or computer

You can switch the TV to the ideal picture setting for gaming or for using the TV as a computer monitor. There is a different setting for **Game** or **Computer**. If a device has a correct type set in the Source menu - Game console or Computer - the TV switches automatically to the ideal setting when you switch to the device. If you switch the setting manually, do not forget to switch it off when you switch to watching TV or another connected device.

To switch the setting manually . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Picture** > **Game or computer**.
3 - Select **Game**, **Computer** or **Off**. The setting **Off** returns to the picture settings for watching TV.
4 - Press ⮌, repeatedly if necessary, to close the menu.

Format and edges

Picture format

For more information on Picture format, press ■ **LIST** and look up **Picture format**.

Screen edges

With **Screen edges**, you can slightly enlarge the picture to hide distorted edges.

To adjust the edges . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Picture** > **Format and edges** > **Screen edges**.
3 - Press ▶ (right) and adjust the value with ▲ (up) or ▼ (down).
4 - Press ⮌, repeatedly if necessary, to close the menu.

Picture shift

With **Picture shift**, you can shift the picture slightly up or down the screen. If subtitles are only half visible, you can shift the picture up to make them completely visible.

To shift the picture . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Picture** > **Format and edges** > **Picture shift**.
3 - Press ▶ (right) and adjust the value with ▲ (up) or ▼ (down).
4 - Press ⮌, repeatedly if necessary, to close the menu.

Location

If the TV is located in a shop, you can set the TV to display an in store promotion banner. The **Picture style** is set to **Vivid** automatically. The automatic **Switch off timer** is switched off.

To set the TV to Shop location . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **General settings** > **Location** and press **OK**.
3 - Select **Shop** and press **OK**.
4 - Press ⮌, repeatedly if necessary, to close the menu.

3.9
Sound settings

Sound style

For easy sound adjustment, you can select a preset setting with **Sound style**.
While watching a TV channel, press ⫶⫶ **OPTIONS** to open the Options menu and select **Sound style**. Select a Sound style and press **OK**.

Sound styles
With Sound styles, you can switch easily to ideal settings for speech (News) or watching movies.
Additionally, you can adjust a specific setting of a chosen Sound style, like Bass or Treble. The TV remembers the adjustments you made.

Adjust a Sound style
To adjust a Sound style . . .
1 - Select the style and press **OK**.
2 - Press ⌂, select ⚙ **Setup** and press **OK**.
3 - Select **TV settings**, navigate to the individual setting and adjust it.
4 - Press ⮌ to close the menu to store your setting.

To return to the original Sound style values . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Sound** > **Sound style** and select the style you want to reset.
3 - Press ■ **Reset**. The style is reset.

In **Help**, press ■ **List** and look up **Sound** for adjusting separate sound settings.

The different Sound styles are . . .
• **Personal** - Your personal choices made in Personalise picture and sound
• **Original** - Factory standard
• **News** - Ideal for speech
• **Movie** - Ideal for watching movies
• **Game** - Ideal for gaming
• **Music** - Ideal for listening to music

Sound settings

Bass

With **Bass**, you can adjust the level of low tones in the sound.

To adjust the level . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Sound** > **Bass**.
3 - Press ▶ (right) and adjust the value with ▲ (up) or ▼ (down).
4 - Press ⮌, repeatedly if necessary, to close the menu.

Treble

With **Treble**, you can adjust the level of high tones in the sound.

To adjust the level . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Sound** > **Treble**.
3 - Press ▶ (right) and adjust the value with ▲ (up) or ▼ (down).
4 - Press ⮌, repeatedly if necessary, to close the menu.

Surround mode

With **Surround mode**, you can set the sound effect of the TV speakers. If you select **Incredible surround** for 2D viewing, the TV will switch to **Incredible surround 3D** automatically when you start watching 3D. If you do not want the TV to switch automatically, select **Off** in **Auto incredible surround 3D**.

To set the surround mode . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Sound** > **Surround mode**.
3 - Press ▶ (right) and select **Stereo**, **Incredible surround** or **Incredible surround 3D**.
4 - Press ⮌, repeatedly if necessary, to close the menu.

Auto incredible surround 3D

With **Auto incredible surround 3D**, you can block the TV to automatically switch to Incredible surround 3D when the TV is switched to 3D viewing.

To switch on or off . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Sound** > **Auto incredible surround 3D**.
3 - Press ▶ (right) and select **On** or **Off**.
4 - Press ⮌, repeatedly if necessary, to close the menu.

Headphones volume

With **Headphones volume**, you can set the volume of a connected headphones separately.

To adjust the volume . . .
1 - Press **OPTIONS** and select **Picture and sound** in the menu bar.
2 - Press ▼ (down) and select **Headphones volume** and press **OK**.
3 - Press ▲ (up) or ▼ (down) to adjust the volume.
4 - Press ⮌, repeatedly if necessary, to close the menu.

Mono/Stereo

With **Mono/Stereo**, you can switch the sound to mono or stereo. This setting is only available when you watch an analogue channel. You might want to switch the sound to mono if a digital stereo signal that comes with the analogue signal, is of bad quality.

To switch the sound to mono or stereo . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **Channel settings** > **Mono/Stereo**.
3 - Press ▶ (right) and select **Mono** or **Stereo**.
4 - Press ⮌, repeatedly if necessary, to close the menu.

If the TV has a built-in satellite tuner and you are watching an analogue channel from a satellite, select **Satellite settings** in the **Setup** menu.

Advanced sound settings

Auto volume leveling

With **Auto volume leveling**, you can set the TV to automatically level out sudden volume differences. Typically at the beginning of adverts or when you are switching channels.

To switch on or off . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Sound** > **Advanced** > **Auto volume leveling**.
3 - Press ▶ (right) and select **On** or **Off**.
4 - Press ⮌, repeatedly if necessary, to close the menu.

TV speakers

You can send the TV sound to a connected audio device - a Home Theatre System or audio amplifier. With **TV speakers**, you select where you want to hear the TV sound and how you want to control it.
If you select **Off**, you permanently switch off the TV speakers.
If you select **On**, the TV speakers are always on.
With an audio device connected with HDMI CEC, you can use one of the EasyLink settings.
If you select **EasyLink**, the TV sends the TV sound to the audio device. The TV will switch off the TV speakers when the device is playing the sound.
If you select **EasyLink autostart**, the TV will switch on the audio device, send the TV sound to the device and switch off the TV speakers.
With EasyLink or EasyLink autostart selected, you can still switch to TV speakers or device speakers in the Picture and sound menu.

To set the TV speakers . . .

1 - Press , select Setup and press OK.
2 - Select TV settings > Sound > Advanced > TV speakers.
3 - Press ▶ (right) and select On, Off, EasyLink or EasyLink autostart.
4 - Press , repeatedly if necessary, to close the menu.

To switch speakers in the Picture and sound menu . . .
1 - While watching TV, press OPTIONS and select Picture and sound.
2 - Select Speakers and select TV or Amplifier (audio device).
3 - Press , repeatedly if necessary, to close the menu.

Clear sound

With Clear sound, you improve the sound for speech. Ideal for news programmes. You can switch the speech improvement on or off.

To switch on or off . . .
1 - Press , select Setup and press OK.
2 - Select TV settings > Sound > Advanced > Clear sound.
3 - Press ▶ (right) and select On or Off.
4 - Press , repeatedly if necessary, to close the menu.

Audio Out format

With Audio Out format you can set the audio out signal of the TV to fit the sound processing capabilities of your Home Theatre System.
For more information, press LIST and look up Audio Out format.

Audio Out leveling

With Audio Out leveling you can level the sound volume of the Home Theatre System with the volume of the TV when you switch over from one to another.
For more information, press LIST and look up Audio Out leveling.

HDMI ARC

If you do not need an Audio Return Channel (ARC) on any of the HDMI connections, you can switch the ARC signal off.
For more information, press LIST and look up HDMI ARC.

Audio Out delay

If you set an Audio sync delay on your Home Theatre System, to synchronise the sound with the picture, you must switch off Audio Out delay on the TV.
For more information, press LIST and look up Audio Out delay.

Audio Out offset

If you cannot set a delay on the Home Theatre System, you can set a delay on the TV with Audio Out offset.

For more information, press LIST and look up Audio Out offset.

TV placement

As part of the first installation, this setting is set to either On a TV stand or Wall mounted.
If you have changed the placement of the TV since then, adjust this setting accordingly for best sound reproduction.
1 - Press , select Setup and press OK.
2 - Select TV settings > General settings > TV placement and press OK.
3 - Select On a TV stand or Wall mounted and press OK.
4 - Press , repeatedly if necessary, to close the menu.

3.10
Ambilight settings

Ambilight on or off

Press AMBILIGHT on the remote control to open the Ambilight mode menu. You can switch Ambilight On or Off. Alternatively, you can select the Ambilight mode you prefer, Dynamic or Static.

Ambilight brightness

With Brightness, you can set the level of brightness of the Ambilight.

To adjust the level . . .
1 - Press , select Setup and press OK.
2 - Select TV settings > Ambilight > Brightness.
3 - Press ▶ (right) and adjust the value with ▲ (up) or ▼ (down).
4 - Press , repeatedly if necessary, to close the menu.

Ambilight mode

Ambilight can have a dynamic or a static mode. With Dynamic, the TV follows the colours of the image on screen. You can adjust the speed at which Ambilight responds.
With Static, Ambilight has a constant static colour. You can create an Ambilight static colour yourself. First, select the Ambilight mode you prefer.

To select an Ambilight mode . . .

1 - Press ⌂, select ⚙ Setup and press OK.
2 - Select TV settings > Ambilight > Mode.
3 - Select Dynamic, Static or Off.
4 - Press ↩, repeatedly if necessary, to close the menu.

Dynamic speed

With Dynamic, you can set the speed at which Ambilight responds to the images on screen. Adjust the speed between Relaxed or Dynamic. The Ambilight mode must be set to Dynamic before you can adjust Dynamic speed.

To adjust the speed . . .
1 - Press ⌂, select ⚙ Setup and press OK.
2 - Select TV settings > Ambilight > Dynamic.
3 - Press ▶ (right) and adjust the value with ▲ (up) or ▼ (down).
4 - Press ↩, repeatedly if necessary, to close the menu.

Static colour

With Static, you can set the static Ambilight colour. You can create a colour yourself or select one of the two white light presets. The Ambilight mode must be set to Static before you can create a static colour.

To create a colour yourself . . .
1 - Press ⌂, select ⚙ Setup and press OK.
2 - Select TV settings > Ambilight > Static and press OK.
3 - Select Palette to adjust the colour. Select Saturation to adjust the intensity of the colour. Use the arrows to select and adjust. Press OK to confirm.
4 - If you prefer to select one of the preset colours, select Warm white or Cool white and press OK.
5 - Select Close and press OK.
6 - Press ↩, repeatedly if necessary, to close the menu.

Advanced Ambilight settings

Wall colour

With Wall colour, you can neutralise the influence of a coloured wall on the Ambilight colours. Select the colour of the wall behind the TV and the TV will adapt the Ambilight colours to appear as they are intended.

To select the colour of the wall . . .
1 - Press ⌂, select ⚙ Setup and press OK.
2 - Select TV settings > Ambilight > Advanced > Wall colour.
3 - Select the colour sample that matches the colour of the wall behind the TV and press OK.
4 - Press ↩, repeatedly if necessary, to close the menu.

TV switch off

With TV switch off, you can set Ambilight to switch off immediately or slowly fade out when you switch off the TV. The slow fade out gives you some time to switch on the normal lighting.

To select the TV switch off . . .
1 - Press ⌂, select ⚙ Setup and press OK.
2 - Select TV settings > Ambilight > Advanced > TV switch off.
3 - Select Fade out to off or Immediate switch off.
4 - Press ↩, repeatedly if necessary, to close the menu.

Lounge light mood

When the TV is on standby, you can switch Ambilight on and create a Lounge light effect in your room. The Lounge light effect is not available when Quick start is activated.

To switch Ambilight on while the TV is on standby, press AMBILIGHT.

To change the Lounge light colour scheme, press AMBILIGHT again.

To switch off Lounge light, press and hold AMBILIGHT for a few seconds.

You can also set up the colour scheme in the TV settings menu.
With the TV switched on, press ⌂, select ⚙Setup and press OK.
Select TV settings > Ambilight > Advanced > Lounge light mood. Select the colour scheme with which Lounge light will start up.

3.11
Universal access

Switch on

With Universal access switched on, the TV is set for use for hearing and visually impaired people.

Switch on

If you did not switch on Universal access during the installation, you can still switch it on in Setup.
To switch on Universal access, press ⌂, select ⚙Setup and press OK.
Select TV settings > General settings > Universal access.
Select On and press OK.

With Universal access switched on in Setup, the Universal access option is added in the Options menu.

Hearing impaired

Some digital TV channels broadcast special audio and subtitles adapted for hearing impaired people. With Hearing impaired switched on, the TV automatically switches to the adapted audio and subtitles, if available. Before you can switch on Hearing impaired, you have to switch on **Universal access**.

Switch on

To switch on Hearing impaired, press **OPTIONS**, select **Universal access** and press **OK**.
Select **Hearing impaired**, select **On** and press **OK**.

To check whether a hearing impaired audio language is available, press **OPTIONS**, select **Audio language** and look for an audio language marked with a .

If Universal access does not appear in the Options menu, switch on **Universal access** in Setup.
In **Help**, press **List** and look up **Universal access** for more information.

Visually impaired

Switch on

Digital TV channels can broadcast special audio commentary describing what is happening on screen. To be able to set the visually impaired audio and effects, you have to switch on Visually impaired first. Also, before you can switch on Visually impaired, you have to switch on **Universal access**.

Visually impaired

With **Visually impaired**, a narrator's commentary is added to the normal audio.
To switch on the commentary (if available) . . .
1 - With **Universal access** switched on, press **OPTIONS** and select the **Options** tab in the menu bar.
2 - Select **Visually impaired** and press **OK**.
3 - Select **On** and press **OK**.
You can check if a visually impaired audio commentary is available.
In the Options menu, select **Audio language** and look for an audio language marked with a .

Speakers / Headphones

You can select where you want to hear the audio commentary. On the TV speakers only, on the headphones only or on both.

To set **Speakers / Headphones** . . .
1 - Press , select **Setup** and press **OK**.
2 - Select **Channel settings** > **Languages** > **Visually impaired** > **Speakers / Headphones** and press **OK**.
3 - Select **Speakers**, **Headphones** or **Speakers + headphones** and press **OK**.
4 - Press , repeatedly if necessary, to close the menu.

Mixed volume

You can mix the volume of the normal audio with the audio commentary.

To mix the volume . . .
1 - Press **OPTIONS** and select the **Options** tab in the menu bar.
2 - Select **Mixed volume** and press **OK**.
3 - Use the arrows up and down to set the slider bar.
4 - Press **OK** to confirm.

Audio effect

Some audio commentary can hold extra audio effects, like stereo or fading sound.

To switch on **Audio effects** (if available) . . .
1 - Press , select **Setup** and press **OK**.
2 - Select **Channel settings** > **Languages** > **Visually impaired** > **Audio effects** and press **OK**.
3 - Select **On** or **Off** and press **OK**.
4 - Press , repeatedly if necessary, to close the menu.

Speech

The audio commentary can also hold subtitles for the words which are spoken.

To switch on these subtitles (if available) . . .
1 - Press , select **Setup** and press **OK**.
2 - Select **Channel settings** > **Languages** > **Visually impaired** > **Speech** and press **OK**.
3 - Select **Descriptive** (audio) or **Subtitles** and press **OK**.
4 - Press , repeatedly if necessary, to close the menu.

Key beep

Key beep gives an audio feedback each time you press a key on the remote control. The volume of the beep is fixed.

Switch on

To switch on Key beep, press **OPTIONS**, select **Universal access** and press **OK**.
Select **Key beep** and select **On**.

If Universal access does not appear in the Options menu, switch on Universal access in Setup.
In **Help**, press **List** and look up **Universal access** for more information.

4

Satellite channels

4.1

Watching satellite channels

To watch satellite channels, press ⌂, select **Satellite** and press **OK**. The TV tunes to the satellite channel you last watched.

Change channel
To change channels, press **CH+** or **CH-**. The TV will tune to the next channel in the selected channel list. If you know the channel number, you can use the number keys on the remote control. To change back to the previously tuned channel, press ⮌.

You can also tune to a channel directly from the Satellite channel list.

4.2

Satellite channel list

About the channel list

When the satellite installation is completed, all satellite channels are put in the channel list. You can view the list of all channels or filter the list down to show the favourite channels only or the radio stations only. Or, after a channel update, you can find the newly added channels in the list of new channels. From any list, you can directly tune to a channel. The list you select in the channel list, determines the channels you tune to with the CH+ and CH- keys.
You can only reorder channels in the list of favourite channels.

Select a channel list

The list you select in the channel list, determines the channels you tune to with the CH+ and CH- keys.

To select a channel list . . .
1 - Press ⌂, select **Satellite** and press **OK**.
2 - Press ☰ **LIST** to open the channel list. The list appears with the current channel selected.
3 - Navigate up to select **All** or a list filter **Favourites**, **Radio**, **TV** or **New**.
The lists Radio or New are only shown when radio stations are available or new channels were found with a channel update.

Tune from the channel list

To tune to a channel from the channel list . . .
1 - In the channel list, select 🖵 or 📡 in the menu bar to select the TV or Satellite channel list.
2 - Select a list - **All**, **Favourites**, **Radio** or **New**.
3 - Select a channel in any of the lists and press **OK**. The TV will tune to the selected channel.

Channel list options

To view the channel list options on the current channel . . .
1 - With the All channels list on screen, select a channel and press ⫶⫶ **OPTIONS**.
2 - Select the option you want and press **OK**.

Available options for satellite channels . . .
• **Satellite**
Filter the channel list to only show the channels of a specific satellite or show the channels of all satellites.
• **Free/Scrambled**
Filter the channel list to only show the free-to-air channels, only the scrambled channels or both. Scrambled channels are marked with a key ≣.
• **Lock**
You can lock a channel. First select a channel in the list, press ⫶⫶ **OPTIONS** and select **Lock**. You will have to enter the 4-digit child lock code. A locked channel is marked with a lock 🔒.
• **Unlock**
To unlock a locked channel. Select a locked channel in the list, press ⫶⫶ **OPTIONS** and and select **Unlock**. You will have to enter the 4-digit child lock code.

Channel list copy

Channel list copy is intended for dealers and expert users. With Channel list copy, you can copy the channels installed on one TV onto another Philips TV of the same range. Channel list copy will copy both terrestrial and satellite channels.
For more information on Channel list copy, press ▬ **LIST** and look up **Channel list copy**.

4.3

Favourite satellite channels

Favourite channels

You can mark channels as favourite channels. Your favourite satellite channels are collected in the **Favourites** list of the satellite channel list.

Watching favourite channels
Set up a favourite channel list to easily switch between the channels you want to watch. Only in this list, you can reorder channels according to your preference.
To only switch between your favourite channels with CH+ and CH-, select the Favourites list in the channel list and close the channel list again.

There are two favourite lists, one for TV channels and one for satellite channels.

Set up your favourites list

To compose a list of your favourite channels . . .
1 - While watching a channel, press ☰ **LIST** to open the channel list.
2 - In the menu bar, select for TV or for satellite channels.
3 - Select the **Favourites** list.
4 - The TV will ask you to start adding channels immediately. Press **OK**. To avoid a lot of reordering later, select the channels in the order you want them in the list.
5 - To add a channel to the Favourites list, select the channel and press **OK**. You can then select another channel to add as a favourite.
6 - To finish, press **Done**.

Add or remove favourite channels

Once you composed your favourites list, you can add or remove channels one by one. Or you can use the Add/remove favourites menu to easily add or remove several channels in one go.

Add or remove one channel
With the **All**, **Radio** or **New** channel list on screen, select a channel and press to mark or unmark as favourite. The channel is added or removed from the Favourites list.

Add or remove several channels
To open the Add/remove favourites menu . . .
1 - With the Favourites list on screen, select a channel.
2 - Press **OPTIONS** and select **Add/remove favourites** and press **OK**. In this list with all channels, select a channel and press **OK** to mark or unmark this channel as a favourite channel. You do not need to use the colour keys. Select a next channel to mark or unmark.
3 - To finish, press **Done**. The channels are added or removed from the Favourites list.

Reorder favourite channels

You can only reorder channels in the Favourites list.

To reorder channels . . .
1 - In the Favourites list, select the channel you want to move in the list.
2 - Press **Move**.
3 - With the arrow keys, position the channel where you want it. Alternatively, you can enter the new position directly with the number keys.
4 - Press **OK** to confirm the position or press **Cancel**. You can now select another channel to move.

4.4
Lock satellite channels

Lock a channel

To prevent children from watching a channel, you can lock a channel. To watch a locked channel, you must enter the 4-digit Child lock code.

To lock a channel . . .
1 - While watching a channel, press ☰ **LIST** to open the channel list.
2 - In any channel list, select the channel you want to lock, press **OPTIONS** and select **Lock channel**. In the channel list, a locked channel is marked with a lock.

To unlock a channel, select a locked channel in the channel list and select the **Unlock channel** option. You will need to enter the Child lock code. You cannot lock a programme from a connected device - e.g. a connected digital receiver.

Use an age rating

To prevent children from watching a programme not suitable for their age, you can use an age rating.
Some digital broadcasters have age rated their programmes. When the age rating of a programme is equal to or higher than the age you have set as age rating for your child, the programme will be locked. For some operators, the TV locks programmes with a higher rating only.
To watch a locked programme, you have to enter the 4-digit Child lock code. The age rating is set for all channels.

To set an age . . .
1 - Press , select **Setup** and press **OK**.
2 - Select **Satellite settings** > **Child lock** > **Parental rating** and press **OK**.
3 - Enter a 4-digit Child lock code. If you did not set a code yet, select **Set code** and press **OK**. Enter a 4-digit Child lock code and confirm. Now you can set an age rating.
4 - Set an age for your child and press **OK**.
5 - Press , repeatedly if necessary, to close the menu.

To switch off the parental age rating, select **None** as age setting.

Child lock code

You can set or change the Child lock code.

To set or change the code . . .
1 - Press , select **Setup** and press **OK**.
2 - Select **Satellite settings** > **Child lock** > **Set code** or **Change code** and press **OK**.
3 - If a code is set already, enter the current Child lock code and then enter the new code twice.
The new code is set.

Forgotten your Child lock code?
If you forgot your code, you can override the current code and enter a new code.
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **Satellite settings** > **Child lock** > **Change code** and press **OK**.
3 - Enter the overriding code **8888**.
4 - Now enter a new Child lock code and enter it again to confirm.

4.5
Satellite installation

About satellite installation

This TV has a built-in satellite DVB-S/DVB-S2 receiver. Connect the cable from your satellite dish directly to the TV. Use a coaxial cable fit for connecting a satellite antenna dish. Make sure your satellite dish is perfectly aligned before you start the installation.

Up to 4 satellites
You can install up to 4 satellites (4 LNBs) on this TV. Select the exact number of satellites you wish to install at the start of the installation. This will speed up the installation.

Unicable
You can use a Unicable system to connect the antenna dish to the TV. Select if you are installing satellites for a Unicable system, for 1 or for 2 satellites at the start of the installation.

MDU - Multi-Dwelling-Unit
The satellite receiver of this TV supports MDU on the Astra satellites and for Digiturk on the Eutelsat satellite. MDU on Türksat is not supported.

Install satellites

You can install your satellites during the initial TV setup. The satellite installation follows the TV channel installation. If you only watch satellite channels, you can skip the TV channel installation.
You can always start a new satellite installation from the Setup menu.

To install satellite channels . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **Search for satellite** and press **OK**.
3 - Select **Install satellites** and press **OK**.
4 - The TV shows the current installation setting. If the current setting corresponds with the satellite installation you want, you can start searching for satellites. Select **Search** and press **OK**. Go to step 5. If the current setting is not the setting you want, select **Settings** and press **OK**. Go to step 4b.
4b - In the Settings menu, select the exact number of satellites you want to install. Or, if you use a Unicable setup, select **Unicable for 1 satellite** or **Unicable for 2 satellites** according the number of satellites you want to install for Unicable. Select the setting you want and press **OK**.
4c - If the exact number of satellites is set or you completed the Unicable settings, select **Search** and press **OK**.
5 - The TV will search for satellites available on the alignment of your antenna dish. This may take a few minutes. If a satellite is found, its name and reception strength are shown on screen.
6 - If a channel package is available for any of the satellites found, you can select the package you want.
7 - To install the channels of the satellites found, select **Install** and press **OK**. The TV shows the number of channels and radio stations found.
8 - To store the satellite settings, all satellite channels and satellite radio stations, select **Finish** and press **OK**.

Channel packages

About channel packages

Satellites can offer channel packages that bundle free channels (free-to-air) and offer a sorting that suits a country. Some satellites offer subscription packages - a collection of channels you pay for.

If you choose a subscription package, the TV might ask you to select a Quick or Full installation. Select **Quick** to install the channels of the package only or select **Full** to install the package and all other available channels too. We recommend a Quick installation for subscription packages. If you have additional satellites that are not part of your subscription package, we recommend a Full installation. All installed channels are put in the channels list All.

Update channel package

With **Update channel package**, you can bring back satellite channels that were in the satellite channel list before but are now missing. The missing channels were repositioned on the transponder by the satellite operator. The TV must be updated with the latest version of the channel package.

To download the latest version of the channel package . . .
1 - Go to the Philips support website **www.philips.com/support** and enter the type number of your TV.
2 - Click on **Software and drivers** and look for the file : **satellite_channel_package.upg** (or .zip).
3 - Download the file on your computer and copy the file on the root directory of a USB flash drive, not in a folder (if necessary, unzip the file first).
4 - Plug the USB flash drive into the TV and press ⌂, select ⚙ **Setup** and press **OK**.
5 - Select **Satellite settings** > **Channel installation** > **Update channel package** and press **OK**.
6 - The TV will copy the file and ask you to start a channel update immediately. Select **Yes** and press **OK**. This may take a few minutes. If you want to postpone the channel update, you can do it later with **Setup** > **Search for satellite** > **Update channels**.
7 - After the channel update is done, the missing channels should be back on their former position in the satellite channel list.

Unicable setup

The Unicable system

You can use a Unicable system to connect the antenna dish to the TV.
A Unicable system uses one cable to connect the satellite dish to all satellite receivers in its system. Unicable is typically used in apartment buildings. If you use a Unicable system, the TV will ask you to assign a user band number and corresponding frequency during the installation. You can install 1 or 2 satellites with Unicable on this TV.

If you notice some missing channels after a Unicable installation, another installation might have been done at the same moment on the Unicable system. Do the installation again to install the missing channels.



User band number

In a Unicable system, each connected satellite receiver must be numbered (e.g. 0, 1, 2 or 3 etc.). You can find the available user bands and their number on the Unicable switchbox. User band is sometimes shortened as UB. There are Unicable switchboxes that offer 4 or 8 user bands. If you select Unicable in the settings, the TV will ask you to assign the unique user band number for its built-in satellite receiver. A satellite receiver cannot have the same user band number as another satellite receiver in the Unicable system.

User band frequency

Next to the unique user band number, the built-in satellite receiver needs the frequency of the selected user band number. These frequencies are mostly shown next to the user band number on a Unicable switchbox.

Add a satellite

You can add an additional satellite to your current satellite installation. The installed satellites and their channels stay untouched. However, some satellite operators do not allow adding a satellite.

The additional satellite should be seen as an extra, it is not your main satellite subscription or not the main satellite of which you use its channel package. Typically, you would add a 4th satellite when you have 3 satellites already installed. If you have 4 satellites installed, you might consider removing one first to be able to add a new satellite.

Settings

If you currently have only 1 or 2 satellites installed, the current installation settings might not allow adding an extra satellite. If you need to change the installation settings, you must redo the complete satellite installation. You cannot use **Add satellite** if a change of settings is needed.

To add a satellite . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **Search for satellite** and press **OK**.
3 - Select **Add satellite** and press **OK**. The current satellites are shown.
4 - Select **Add** and press **OK**. The TV will search for new satellites.
5 - If the TV has found one or more satellites, select **Install** and press **OK**. The TV installs the channels of the found satellites.
6 - To store the channels and radio stations, select **Finish** and press **OK**.

Remove a satellite

You can remove one or more satellites from your current satellite installation. You remove the satellite and its channels. However, some satellite operators do not allow removing a satellite.

To remove satellites . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **Search for satellite** and press **OK**.
3 - Select **Remove satellite** and press **OK**. The current satellites are shown.
4 - Use the arrows keys to select the satellite you want to remove.
5 - Press **OK** to mark a satellite to remove. Press **OK** again to unmark.
6 - Select **Remove**, press **OK** and confirm. The satellites are removed.
7 - Select **Exit** and press **OK** to close Remove satellite.

Reorder and rename channels

You can reorder and rename satellite channels.

Reorder

You can only reorder channels in the Favourites list. For more information on Reordering satellite channels, press ▬ **LIST** and look up **Satellite, reorder channels**.

Rename channels

You can rename channels in the channel list.
1 - Select the channel you want to rename in one of the channel lists - **All**, **Favourites**, **Radio** or **New**.

2 - Press Rename. You can enter text with the remote control keyboard or open the on-screen keyboard.

With the remote control keyboard
To delete a character, position the cursor behind the character and press # del.
To enter a character, press the character on the keyboard.
When you are ready, press Enter to select Done. Press Enter again to finish renaming.
For more information on using the keyboard, press LIST and look up Remote control, keyboard.



With the on-screen keyboard.
To open the on-screen keyboard, place the cursor in the name text field and press OK.
To delete the character in front of the cursor, press Backspace.
To enter a character, select the character with the arrow keys and press OK.
To select uppercase letters, press .
To select numbers or special characters, press .
When you are ready, press to close the on-screen keyboard.
To finish renaming, select Done and press OK.

Update satellite channels

Once a day, at 4 AM, the TV automatically updates the satellite channels. A channel update looks for new channels and adds them to the channel list. No longer available channels are removed and if a provider reorders its channel package, the channel list of the TV will be updated. The TV must be on standby to automatically update the satellite channels. Alternatively, you can do a channel update yourself at any moment.
New channels, found with the channel update, are marked with the letter N and collected in the channel list New. New channels are also added in the All channel list. New channels stay in the channel list New as long as you do not tune to them or mark them as a favourite.

Switch off the automatic channel update
You can completely switch off the TV at night to avoid a channel update. Alternatively, you can switch off the automatic update in the setup menu.
1 - Press , select Setup and press OK.
2 - Select Satellite settings > Channel installation > Automatic channel update and select Off.

Switch off the update for a specific satellite
1 - Press , select Setup and press OK.
2 - Select Satellite settings > Channel installation > Automatic update option.
3 - With the arrow keys, select the satellite you do not wish to update. Press OK to unmark the satellite.
4 - Select Done and press OK to close the menu.
The TV will not update the channels from satellite you marked.

Start an update yourself
1 - Press , select Setup and press OK.
2 - Select Search for satellite and press OK.
3 - Select Update channels and press OK.
4 - If you want to check which satellites are set for updating, select Settings and press OK.
5 - With the arrow keys, mark or unmark the satellites for updating. Select Done and press OK.
6 - Select Update and press OK. The update may take a few minutes.
7 - Select Finish and press OK.

Extras

Channel installation extras

In the next chapters, you can find more information on . . .
- Programme language and subtitle language preferences
- Universal access settings for the hearing and visually impaired
- Manual installation - satellite transponder installation

Preferred languages and subtitles

Satellite channels can hold different audio languages, subtitle languages or Text languages. You can set the TV to automatically switch to the language, subtitle language or Text language you prefer, if this language is available on the channel or Text pages.

To set the your preferred language . . .
1 - Press , select Setup and press OK.
2 - Select Satellite settings and press OK.
3 - Select Languages and press OK. Select the setting you want.
4 - Press , repeatedly if necessary, to close the menu.

Hearing impaired

Some digital TV channels broadcast special audio and subtitles adapted for hearing impaired people. With Hearing impaired switched on, the TV automatically switches to the adapted audio and subtitles, if available. Before you can switch on Hearing impaired, you have to switch on Universal access.

Switch on
To switch on Hearing impaired, press OPTIONS, select Universal access and press OK.
Select Hearing impaired, select On and press OK.

To check whether a hearing impaired audio language is available, press OPTIONS, select Audio language and look for an audio language marked with a .

If Universal access does not appear in the Options menu, switch on **Universal access** in Setup.
In **Help**, press **List** and look up **Universal access** for more information.

Visually impaired

Switch on

Digital TV channels can broadcast special audio commentary describing what is happening on screen. To be able to set the Visually impaired audio and effects, you have to switch on visually impaired first. Also, before you can switch on Visually impaired, you have to switch on **Universal access**.

Visually impaired
With **Visually impaired**, a narrator's commentary is added to the normal audio.
To switch on the commentary (if available) . . .
1 - With **Universal access** switched on, press **OPTIONS** and select the **Options** tab in the menu bar.
2 - Select **Visually impaired** and press **OK**.
3 - Select **On** and press **OK**.
You can check if a visually impaired audio commentary is available.
In the Options menu, select **Audio language** and look for an audio language marked with a .

Speakers / Headphones

You can select where you want to hear the audio commentary. On the TV speakers only, on the headphones only or on both.

To set **Speakers / Headphones** . . .
1 - Press , select **Setup** and press **OK**.
2 - Select **Satellite settings** > **Languages** > **Visually impaired** > **Speakers / Headphones** and press **OK**.
3 - Select **Speakers**, **Headphones** or **Speakers + headphones** and press **OK**.
4 - Press , repeatedly if necessary, to close the menu.

Mixed volume

You can mix the volume of the normal audio with the audio commentary.
To mix the volume . . .
1 - Press **OPTIONS** and select the **Options** tab in the menu bar.
2 - Select **Universal access** > **Mixed volume** and press **OK**.
3 - Use the arrows up and down to set the slider bar.
4 - Press **OK** to confirm.

Audio effect

Some audio commentary can hold extra audio effects, like stereo or fading sound.
To switch on **Audio effects** (if available) . . .
1 - Press , select **Setup** and press **OK**.
2 - Select **Satellite settings** > **Languages** > **Visually impaired** > **Audio effects** and press **OK**.
3 - Select **On** or **Off** and press **OK**.
4 - Press , repeatedly if necessary, to close the menu.

Speech

The audio commentary can also hold subtitles for the words which are spoken.
To switch on these subtitles (if available) . . .
1 - Press , select **Setup** and press **OK**.
2 - Select **Satellite settings** > **Languages** > **Visually impaired** > **Speech** and press **OK**.
3 - Select **Descriptive** (audio) or **Subtitles** and press **OK**.
4 - Press , repeatedly if necessary, to close the menu.

Manual installation

Manual installation is intended for expert users.
You can use Manual installation to quickly add new channels from a satellite transponder. You need to know the frequency and polarization of the transponder. The TV will install all channels of that transponder. If the transponder was installed before, all its channels - the former and the new ones - are moved to the end of the channel list All.
You cannot use Manual installation if you need to change the number of satellites. If this is needed, you have to do a complete installation with Install satellites.

To install a transponder . . .
1 - Press , select **Setup** and press **OK**.
2 - Select **Satellite settings** and press **OK**.
3 - Select **Channel installation** and press **OK**.
4 - Select **Manual installation** and press **OK**.
5 - If you have more than 1 satellite installed, select the satellite/LNB for which you want to add channels.
6 - Set the **Polarization** you need. If you set the **Symbol rate mode** to **Manual**, you can enter the symbol rate in **Symbol rate** manually. Enter the **Frequency** and start searching for the transponder.
7 - If a transponder is found, select **Store** and press **OK** to store the new transponder on the selected LNB.
8 - Select **Exit** to leave the manual installation.

Troubleshooting

The TV cannot find the satellites I want or the TV installs the same satellite twice
• Make sure that the correct number of satellites is set in Settings at the start of the installation. You can set the TV to search for One, Two or 3/4 satellites.

A dual head LNB cannot find a second satellite
• If the TV finds one satellite but cannot find a second one, turn the dish a few degrees. Align the dish to get the strongest signal on the first satellite. Check the signal strength indicator of the first satellite on screen. With the first satellite set at the strongest signal, select **Search again** to find the second satellite.
• Make sure the settings are set to **Two satellites**.

Changing the installation settings did not solve my problem
• All settings, satellites and channels are only stored at the end of the installation when you finish.

All satellite channels are gone.
• If you use a Unicable system, make sure you assigned a unique user band number to the satellite receiver in the Unicable settings. It might be that another satellite receiver is using the same user band number.

Some satellite channels seem to have disappeared from the channel list.
If some channels seem to be gone or displaced, the broadcaster might have changed the transponder location of these channels. To restore the channel positions in the channel list, you can try an update of the channel package.

I cannot remove a satellite
• Subscription packages do not allow removing a satellite. To remove the satellite, you have to do a complete installation again and select another package.

Sometimes the reception is poor
• Check if the satellite dish is solidly mounted. Strong winds can move the dish.
• Snow and rain can degrade the reception.

5

3D

5.1 What you need

This is an Easy 3D TV.

To watch 3D you need to :
• tune to a TV channel that broadcasts programmes in 3D
• rent a movie in 3D from an online video store with Smart TV
• watch a movie in 3D from a 3D Blu-ray Disc, a USB device or computer

For an extra pair of glasses order the Philips Passive 3D glasses PTA417 or PTA426 (sold separately). Other 3D glasses might not be supported.

5.2 Your passive 3D glasses

Passieve 3D glasses PTA417
To watch a 3D picture on TV, simply put on the 3D glasses.

Recommended viewing height
For best picture quality, when watching passieve 3D, your eyes should be level with the centre of the screen.

5.3 Watch 3D

3D switching
The first time a 3D signal is detected, you can set your preference on how to start 3D in the future.
To switch to 3D automatically, select **Automatic**.
To show a notification first, select **Notify**.
To never switch to 3D, select **No 3D**.

You can still change this preference in the **Setup** menu > **TV settings** > **3D** > **Switch to 3D**.

Start 3D
When the TV switches to 3D or when a notification is shown that 3D is available, put on your 3D glasses.

If the TV cannot detect the 3D signal (the 3D signal tag is missing), the 3D programme is shown as a double image on screen. To switch to 3D, press **3D** and select **Side by side** or **Top / bottom** according to the double image positions.

Stop 3D
To stop watching 3D, press **OPTIONS**, select **3D depth** and select **Off**.
3D is switched to 2D when you switch to another channel or connected device.

2D to 3D conversion
You can convert any 2D programme to watch it in 3D.
To convert a 2D programme to 3D, press **3D**, select **2D to 3D conversion** and confirm with **OK**.
To stop the 2D to 3D conversion, press **3D** and select **2D** and press **OK** or switch to another activity in the Home menu.
The conversion will not stop if you switch between TV channels.

You can change the depth of 3D for a weaker or stronger 3D effect in the 2D to 3D conversion.
To change the 3D depth, press **OPTIONS** and select **3D depth**. Select **Off** (no 3D), **Less** (less 3D depth), **Normal** (optimal 3D quality) or **More** (more 3D depth).

5.4 Optimal 3D viewing

For an optimal 3D viewing experience, we recommend that you:
• sit at least 3 times the height of the TV screen away from the TV, but no further than 6 meters away.
• avoid fluorescent lighting (such as TL lighting or certain energy saving light bulbs which operate on a low frequency) and direct sunlight as they may interfere with the 3D experience.



5.5 Health warning

• If you or your family have a history of epilepsy or photosensitive seizures, consult a medical professional before exposing yourself to flashing light sources, rapid image sequences or 3D viewing.
• To avoid discomfort such as dizziness, headache or disorientation, we recommend not watching 3D for extended periods of time.

If you experience any discomfort, stop watching 3D and do not immediately engage in any potentially hazardous activity (for example driving a car) until your symptoms have disappeared. If symptoms persist, do not resume watching 3D without consulting a medical professional first.

• Parents should monitor their children during 3D viewing and ensure they do not experience any discomfort as mentioned above. Watching 3D is not recommended for children under 6 years of age as their visual system is not fully developed yet.
• Do not use the 3D glasses for any purpose other than watching 3D TV.

5.6

Care of the 3D glasses

• Do not expose the 3D glasses to direct sunlight, heat, fire or water. This may result in a product malfunction or fire.
• Use a clean soft cloth (microfiber or cotton flannel) to clean the lenses to avoid scratching them. Never spray cleaner directly onto the 3D glasses. This may damage the electronics.
• Do not drop, bend or apply force to the lenses of the 3D glasses.
• Do not use cleaning chemicals containing alcohol, solvent, surfactant, or wax, benzene, thinner, mosquito repellent or lubricant. Using these chemicals can cause discoloration or cracks.

6

Smart TV

6.1

Home menu

From the Home menu, you can start any activity you can do with the TV.

Open the Home menu to start watching TV or start watching a disc on your Home Theatre System. Also in the Home menu, you can open Smart TV to surf the Internet, start Skype or open Help if you need information on using the TV.

Open the Home menu
To open the Home menu, press ⌂.
Select an activity using the arrow keys and press **OK** to start the activity.
To close the Home menu without changing the current activity, press ⮌.

- **TV**
Select **TV** and press **OK** to watch TV channels.

- **Satellite**
Select **Satellite** and press **OK** to watch satellite channels (only for TVs with a built-in satellite tuner).

- **Smart TV**
Select **Smart TV** and press **OK** to open the Smart TV start page.

- **Source**
Select **Source** and select a connected device in the list underneath the icon. Press **OK** to switch to the selected device.

- **TV guide**
Select **TV guide** and press **OK** to open a list of the current and scheduled TV programmes of your channels.

- **Recordings**
Select **Recordings** and press **OK** to open the list of your recordings.

- **Skype**
Select **Skype** to make video calls for free.

- **Setup**
Select **Setup** to install channels or adjust all TV settings.

- **Help**
Select **Help** and press **OK** to open the on screen Help. You can look up a topic in an alphabetical list.

6.2

Smart TV Apps

What you need

To enjoy Smart TV Apps you must connect the TV to a router with a high-speed (broadband) connection to the Internet. You can use a home network connected to the Internet. You do not need a computer.
In **Help**, press ■ **List** and look up **Network** for more information.

Tip
To enter text or to navigate an Internet page more easily, you can consider to connect a USB keyboard and a USB mouse to the TV.
In **Help**, press ■ **List** and look up **USB keyboard** or **USB mouse** for more information.

Configure

The first time you open Smart TV, you need to configure your connection. Read and agree to the terms and conditions to continue. To leave Smart TV, press ⮌.

Register
Register with Club Philips.
Select **Register** and press **OK**.
Enter your email address, select **Continue** and press **OK**.
Confirm the email address.

Parental control
To lock Adult 18+ rated apps, switch on Smart TV parental control by selecting **Enable** and then press **OK**.
Enter an unlock PIN code of your choice.
Confirm your PIN code. Adult 18+ rated apps are now locked.

To open a locked app, select the app and press **OK**. The TV will ask you to enter your 4-digit code.

Reconfigure
To reconfigure your connection with Smart TV, clear the Internet memory on the TV.
To clear the Internet memory, press ⌂ and select ⚙ **Setup** and press **OK**.
Select **Network settings** > **Clear Internet memory** and press **OK**.

Smart TV start page

The Smart TV start page is your link to the Internet. You can rent movies online, read newspapers, watch videos and listen to music, also shop online, open your social network page (Facebook, Twitter, . . .) or watch TV programmes when it suits you with Online TV. To do this, you open Apps - Internet sites which are tailored for TV. With your TV connected to the Internet, you can open Smart TV.

Open Smart TV

To open the Smart TV start page, press **Smart TV**.
Alternatively, you can press , select **Smart TV** and press **OK**.

The TV connects to the Internet and opens the Smart TV start page. This may take a few seconds.

1 - Now on your TV
2 - Your Apps
3 - App gallery
4 - Internet
5 - Recommended Apps
6 - Search
7 - Colour keys for control

Your Apps

You start Apps from the Smart TV start page. If the start page does not hold any Apps yet, you can add Apps from the App gallery.
The list of your Apps can be several pages long. Use the arrow keys to go to the next or previous page. Alternatively, press **CH+** (Next page) or **CH-** (Previous page).

App gallery

In the App gallery you find all available Apps.

Internet

The **Internet** App opens the World Wide Web on your TV. On your TV, you can view any Internet website but most of them are not tailored for a TV screen.
- Some plug-ins (e.g. to view pages or videos) are not available on your TV.
- Internet pages are shown one page at a time and full screen.

Recommended Apps

In this window, Philips presents a range of recommended Apps for your country, Apps for Online TV or a selection of rental movies from Video stores. You can select and open them from the Recommended Apps window.

Search

With Search, you can search the App gallery for relevant Apps.

Enter a keyword in the text field, select and press **OK** to start searching. You can enter names, titles, genres and description keywords to search.
Alternatively, you can leave the text field empty and search for the most popular searches/keywords for a range of categories.
In the list of found keywords, select a keyword and press **OK** to search for items with that keyword.

In the list of Apps on the Smart TV start page you can . . .

Remove an App

To remove an App from the Smart TV start page, select the App icon and press **Remove**.

Move an App

To reposition an App in the list, select the App icon, press **Move** and use the arrow keys to reposition the App.
Press **OK** to confirm the position.

Lock an App

To lock an App, select the App icon and press **Lock**.
When you lock an App, you must enter the 4 digit PIN code you set for Parental control when you configured Smart TV. In the list, a locked App is marked with a lock .
To unlock an App, select the App icon and press **Unlock**.
You must enter the 4 digit PIN code to unlock.

Feedback on an App

Select the App and press **Feedback** to select a 'like' or 'don't like' button and send a suggestion or remark to us. You can also report an App malfunction.

Close Smart TV

To close the Smart TV start page, press and select another activity.

TP Vision Netherlands B.V. bears no responsibility regarding the content and the quality of the content provided by the content service providers.

Using Apps

To start an App, you must add it to your list of Apps in the Smart TV start page first.
You can add Apps to your list from the App gallery.

App gallery

In the App gallery you find all available Apps. The App gallery shows Apps in lists per country.
To open the App gallery, select the App gallery icon on the Smart TV start page and press **OK**.
In the App gallery, use the arrow keys to select items in the page.
To view the Apps ordered by category, press **All Apps**, select a category and press **OK**.
To view the Apps from another country, press **Country**, select a country and press **OK**.
To lock an App, select the App icon and press **Lock**.
When you lock an App, you must enter the 4 digit PIN code you set for Parental control when you configured Smart TV. In the list, a locked App is marked with a lock .
To unlock an App, select the App icon and press **Unlock**.
You must enter the 4 digit PIN code to unlock.

To return to the Smart TV start page, press ☰ **LIST** or ⮌.

Add an App to your list
In the App gallery, select the App icon and press **OK**.
Select **Add** and press **OK**.
Alternatively, select **Add and move** to add it and immediately position the App where you want it in your list.

Start an App
To start an App, press ⌂ and select **Smart TV**.
On the start page, select an App icon and press **OK**.
In an App, press ⮌ to go back 1 step or page.

Reload an App page
If an App page did not load properly, press ⫶⫶ **OPTIONS** and select **Reload** to reload the page.

Zoom
You can zoom in on an App page.
To zoom a page, press ⫶⫶ **OPTIONS** and select **Zoom page**.
Use the slider bar to set the zoom level.
Return to normal view by resetting the slider bar.

View security info
You can check the security level of an App page.
On an App page, press ⫶⫶ **OPTIONS** and select **Security info**. If a lock 🔒 is shown next to the loading animation on the bottom of the screen while loading a page, the transfer is secured.

Close an App
To close an App and return to the Smart TV start page, press **Smart TV**.

Rental video Apps

With the video store Apps in Smart TV, you can rent your favourite movie from an online rental video store. You can pay securely with your credit card.

Rent a movie
1 - Open a Video store App in your list of Apps or select a recommended video on the Smart TV start page.
2 - Select a movie.
3 - Make the online payment.
4 - Download the video.
5 - Start watching. You can use the ▶ (Play) and ❚❚ (Pause) keys.

Most Video stores ask you to create a log in account.

Streaming video
With this TV, you can watch rental movies sent as a streaming video format. You can almost instantly watch the movie. When the rental video store uses video streaming, you might need a USB Hard Drive to store some video buffer. You can pause or restart a rental movie send with streaming video.
If you have a USB Hard Drive connected, you can also download rental movies from video stores that offer movie downloading only. You can pause or restart a downloaded rental movie.

Consult the video store regarding the rental duration of rental movies.

Internet traffic
Streaming or downloading many videos may exceed your monthly Internet traffic limit.

Online TV

With the Online TV App on the Smart TV start page*, you can watch TV programmes you missed or watch programmes whenever it suits you best.

Open Online TV
To open the Online TV App, press ⌂ and select **Smart TV**.
On the start page, select the **Online TV** icon and press **OK**.
Select a programme on the page and press **OK** to start watching.
You can use the ▶ (Play) and ❚❚ (Pause) keys.

List per broadcaster
To view the Online TV programmes ordered by broadcaster, press **All broadcasters**.
Select a broadcaster and press **OK**.

* If available in your region.

6.3
Videos, photos or music

With USB or Network computer

What you need

You can view your photos or play your music and videos from a connected USB flash drive or USB Hard Drive. If you have a computer in your home network, you can view and play your files from your computer on the TV.

From a USB device
With the TV switched on, plug in a USB flash drive or USB Hard Drive to one of the USB connections. The TV detects the device and lists your files.
If the list does not appear automatically, press **SOURCE**, select **Browse USB** and press **OK**.

Warning

If you try to pause or record a programme with a USB Hard Drive connected, the TV will ask you to format the USB Hard Drive. This formatting will delete all current files on the USB Hard Drive.

From a computer

If the TV and the computer are in the same network, the TV can browse and play files stored on your computer.
On your computer, you need to install media server software like Twonky™ to share your files with the TV. The TV shows your files and folders as they are organised on your computer.
To browse the files on your computer, press **SOURCE**, select **Browse network** and press **OK**.

Menu bar and sorting

With a USB device connected, the TV sorts the files by type. Navigate to the menu bar and select the type of file you are looking for.
If you browse files from a computer, you can only browse the files and folders as they are organized on the computer.

The menu bar

Navigate to the menu bar and select the type of file you want to watch or play.
Select **Photos**, **Music** or **Videos**. Alternatively, you can open the **Folders** view and browse your folders to look for a file.

Sorting

To browse your photos by date, month, year or alphabetically by name, press **Sort**.
To browse your music by album, artist, genre or alphabetically by name, press **Sort**.
Videos are sorted alphabetically.

View photos

To view photos, select **Photos** in the menu bar, select a photo thumbnail and press **OK**.
If there are several photos in the same folder, select a photo and press **Slide show** to start a slide show of all photos in this folder.
To jump to the next or previous photo, press **CH+** or **CH-**.
To stop the slide show or close the photo, press **LIST** or ■ (Stop).

You can play music with a slide show.
Start the slide show after you started the music.
1 - Select a song or a folder with songs and press **OK**.
2 - Press **LIST** and select **Photos**.
3 - Select a photo or a folder with photos and press **Slide show**.

Info

To view info on a photo (size, creation date, file path, etc.), select a photo and press **INFO**.
Press again to hide the info.

Options

Press **OPTIONS**.
- Shuffle
Shows your photos randomly.
- Repeat
Plays the slide show continuously.
- Slide show speed
Sets the speed of the slide show.
- Slide show transition
Sets the style of the photo transitions.

To close **Browse USB** or **Browse network**, press and select another activity.

Play music

To play music, select **Music** in the menu bar, select a song and press **OK**.
If there are more songs in the same folder, press **Play all** to play all songs in this folder.
To jump to the next or previous song, press **CH+** or **CH-**.
To pause the music, press **OK**. Press **OK** again to continue.
To make a 10-second jump in a song or 10-second jump back, press ▶ or ◀.
To rewind or fast forward, press ◀◀ or ▶▶. Press the keys several times to speed up - 2x, 4x, 8x, 16x, 32x.
To stop the music playback, press ■ (Stop).

If you press **LIST** or , the music keeps on playing.

Info

To view song info (title, artist, duration, etc.), select the song and press **INFO**.
Press again to hide the info.

Options

Press **OPTIONS**.
- Shuffle
Plays your music randomly.
- Repeat
Plays the song once or continuously.

Screen off

If you only listen to music, you can switch off the TV screen to save energy.
To switch off the screen, press **OPTIONS**, select **Eco settings** in the menu bar, select **Screen off** and press **OK**. To switch the screen back on, press any key on the remote control.

To close **Browse USB** or **Browse network**, press and select another activity.

Play videos

To play a video, select **Videos** in the menu bar, select a video and press **OK**.
If there are more videos in the same folder, press **Play all** to play all videos in this folder.
To jump to the next or previous video, press **CH+** or **CH-**.
To pause the video, press **OK**. Press **OK** again to continue.
To make a 10-second jump forward or backward in a video, press ▶ or ◀.
To rewind or go fast forward, press ◀◀ or ▶▶. Press the keys several times to speed up - 2x, 4x, 8x, 16x, 32x.
To stop the video playback, press ■ (Stop).

Info

To view info on a video (playhead position, duration, title, date, etc.), select the video and press INFO.
Press again to hide the info.

Options
Press OPTIONS.
- Subtitles
If available, you can switch subtitles **On**, **Off** or **On during mute**.
- Shuffle
Plays your videos randomly.
- Repeat
Plays a video once or continuously.
- DivX® VOD
Opens the DivX registration.

To close **Browse USB** or **Browse network**, press and select another activity.

DivX® VOD

This TV is DivX Certified® and plays high-quality DivX Video-On-Demand videos.

To play DivX VOD videos from a video store or from your computer, you must activate DivX VOD on the TV first. The DivX VOD activation of your TV is free of charge.

Register
If the TV is not yet activated when you start the playback of a rental DivX video, the TV will show you the DivX registration code to activate this TV.

To register follow these steps.

1 - When the TV shows the 8 or 10-digit registration code, write down the code and go to http://vod.divx.com on your computer
2 - Download and install the DivX player software on your computer.
3 - Start the DivX player software and create a DivX Account (VOD > Create a DivX Account . . .)
4 - In the DivX player, register the TV with the registration code of the TV (VOD > Register a DivX Certified Device . . .)
5 - Download and save the registration video when asked.
6 - Transfer the registration video to the TV. You can use a USB flash drive or your network connection.
7 - Play the registration video on your TV. This completes the registration and activates DivX on your TV.

Consult the DivX website for detailed support.

Deregister
You can deregister the TV and deactivate DivX VOD playback.
To deregister, press **SOURCE**, select **Browse USB** and press **OK**.
Press **OPTIONS**, select **DivX® VOD** and press **OK**.

DivX®, DivX Certified® and associated logos are trademarks of Rovi Corporation or its subsidiaries and are used under license.

ABOUT DIVX VIDEO: DivX® is a digital video format created by DivX, LLC, a subsidiary of Rovi Corporation.

This is an official DivX Certified® device that plays DivX video. Visit divx.com for more information and software tools to convert your files into DivX videos.

ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified® device must be registered in order to play purchased DivX Video-on-Demand (VOD) movies. To obtain your registration code, locate the DivX VOD section in your device setup menu. Go to vod.divx.com for more information on how to complete your registration.

With Wi-Fi Miracast

What is Wi-Fi Miracast?

Your TV is a **Wi-Fi Certified Miracast™** device. With Miracast™, you can watch and share the screen of your smartphone, tablet or computer on your TV screen wirelessly. You can stream videos (audio and video), share photos or anything else that's on screen of the device. No need to connect the device to your home network. Both the TV and the device must be Wi-Fi Certified Miracast™ devices and have Miracast switched on.

For more information on Wi-Fi Certified Miracast™ go to www.wi-fi.org

Wi-Fi®, the Wi-Fi CERTIFIED logo, the Wi-Fi logo are registered trademarks of the Wi-Fi Alliance. **Wi-Fi CERTIFIED Miracast™**, **Miracast™** are trademarks of the Wi-Fi Alliance.

Switch on Miracast

The TV comes with Miracast switched **On** and is ready to show the screen of a device with Miracast.

Switch off Miracast
If you do not want the TV to receive requests for screen sharing from other devices, you can switch off Miracast on the TV.
1 - Press , select **Setup** and press **OK**.
2 - Select **Network settings** > **Wi-Fi Miracast** > **Off** and press **OK**.
3 - Press , repeatedly if necessary, to close the menu.

Share a screen on TV

To share the screen of your smartphone, tablet or computer on the TV . . .
1 - Switch on the TV.

2 - On the device, open an application such as Wi-Fi Miracast, Wi-Fi Direct™, Intel®Wireless Display* or similar and start scanning for other Miracast devices.
3 - In the list of found devices, select the TV and connect.
4 - On the TV, agree to the request to connect to the TV. You might be asked to enter a PIN code from the device on the TV - enter the numbers with the digit keys on the remote control. Alternatively, you might be asked by the TV to enter a PIN code on the device. If you connect, the TV will show the screen of the device.
5 - On the device, select the videos, photos or files you want to watch on TV.

* Miracast is supported by WiDi 3.5 onwards.

Stop sharing a screen

From the device
With the application you use to start Miracast, you can disconnect and stop watching the screen of the device on TV. The TV will switch back to the last selected programme.

From the TV
To stop watching the screen of the device on TV, you can . . .
• press **TV** to watch a TV broadcast
• press ⌂ to start another activity on TV
• press **SOURCE** to open the Source menu and select a connected device.

Block a device

The first time you receive a request to connect from a device, you can block the device. This request, and all requests in the future, from this device, will be ignored.
To block a device, select **Block . . .** in the request window and press **OK**.

Unblock all devices
All previously connected and blocked devices are stored in the Wi-Fi Miracast list of connections. If you clear this list, all blocked devices will be unblocked.

To unblock all blocked devices . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **Network settings** > **Wi-Fi Miracast connections** and press **OK**.
3 - Select **Clear all** and press **OK** to clear the list.
4 - Press ↩, repeatedly if necessary, to close the menu.

Blocking a previously connected device
If you want to block a device that you previously connected, you need to clear the Wi-Fi Miracast connections list first. If you clear this list, you will have to confirm or block the connection for every device again.

Screen delay

The normal delay when sharing a screen with Miracast is about 1 second. The delay might be longer if you are using older devices/computers with less processing power.

Specifics

• Miracast on this TV is subject to the HDCP protocol and cannot display copy-protected premium content sent by a device.
• The maximum video resolution supported is 720p.

6.4
Pause TV

You can pause a TV broadcast and resume watching it later. Only digital TV channels can be paused. You must connect a USB Hard Drive to buffer the broadcast. You can pause a broadcast for a maximum time span of 90 minutes.
In **Help**, press ■ **List** and look up **USB Hard Drive, installation** for more information.

Pause or resume a broadcast
To pause a broadcast, press ❚❚ (Pause). A progress bar appears briefly on screen.
To call up the progress bar, press ❚❚ (Pause) again.
To resume watching, press ▶ (Play). The icon on screen indicates you are watching a paused broadcast.

Back to the actual TV broadcast
To switch back to the actual TV broadcast, press ■ (Stop).

The moment you switch to a digital channel, the USB Hard Drive starts buffering the broadcast. When you switch to another digital channel, the broadcast of the new channel is buffered and the broadcast of the former channel is cleared. When you switch to a connected device (a Blu-ray Disc player or digital receiver) the USB Hard Drive stops buffering and the broadcast is cleared. Also when you switch the TV to standby the broadcast is cleared.
Whilst recording a programme on the USB Hard Drive, you cannot pause a broadcast.

Instant replay
Whilst watching a broadcast from a digital TV channel, you can easily instant replay the broadcast.
To replay the last 10 seconds of a broadcast, press ❚❚ (Pause) and press ◀ (Left).
You can press ◀ repeatedly until you reach the start of the broadcast buffer or the maximum time span.

Progress bar
With the progress bar on screen, press ◀◀ (Rewind) or press ▶▶ (Forward) to select from where you want to start viewing the paused broadcast. Press these keys repeatedly to change speed.

Specifics

• The Audio Description audio (commentary) for the visually impaired is not available for playback in Pause TV or Recording.
• You can buffer the digital (DVB) subtitles of a channel. You cannot buffer subtitles that come from Text services. To check if digital (DVB) subtitles are available, tune to the TV channel and press **OPTIONS**, select **Options** in the menu bar and select **Subtitle language** to open the list of Subtitles. You can only buffer a subtitle language preceded with a **DVB** icon.

6.5

Recording

Record a program

What you need

If a USB Hard Drive is connected and formatted and the TV receives electronic TV guide information, you can record a digital TV broadcast.

In **Help**, press **List** and look up **USB Hard Drive, installation** to install a USB Hard Drive.

Record now

To record the programme you are watching, press ● (Record) on the remote control.

If you receive TV guide information from the Internet, you can adjust the end time of the recording in the pop-up window before you confirm the recording.
If you receive TV guide information from the broadcaster, the recording starts immediately. You can adjust the end time of the recording in the list of recordings.
To stop recording, press ■ (Stop).

Schedule a recording

You can schedule a recording of an upcoming programme for today or a few days from today (maximum of 8 days away).

1 - To schedule a recording, press **Guide**.
On the TV guide page, select the channel and programme you wish to record.
You can enter the channel number to jump to the channel in the list.
Press ▶ (Right) or ◀ (Left) to scroll through the programmes of a channel.

To change the date of the list, press **OPTIONS** and select **Select day**. In the list, select the day you want and press **OK**. If the TV guide comes from the Internet, you can select the date at the top of the page and press **OK**.

2 - With the programme highlighted, press **Record** or press **OPTIONS** and select **Record**. The TV adds some time buffer at the end of the program. You can add some extra buffer if needed.

3 - Select **Schedule** and press **OK**. The programme is scheduled for recording. A warning will show automatically when overlapping recordings are scheduled.
If you plan to record a programme in your absence, remember to leave the TV switched to standby and the USB Hard Drive switched on.

List of recordings

To view the list of recordings and scheduled recordings, press ⌂, select **Recordings** and press **OK**.

In this list, you can select a recording to watch, remove recorded programmes, adjust the end time of an ongoing recording or check the free disc space. Also in this list, if the TV guide comes from the Internet, you can schedule a recording for which you set the beginning and end time yourself, as a timed recording not linked to a programme. To set a timed recording, select **Schedule recording** at the top of the page and press **OK**. Set the channel, date and time span. To confirm the recording, select **Schedule** and press **OK**.

Remove a scheduled recording

To remove a scheduled recording, select the upcoming recording in the list and press **OK**. Alternatively, you can select the scheduled recording and press **OPTIONS** and select **Cancel recording**.

Specifics

• While recording a programme, you can watch a previously recorded programme.
• While recording, you cannot switch TV channels.
• While recording, you cannot pause the TV broadcast.
• To Record, broadcasters need a reliable clock setting. If you reset the TV clock manually, recordings may fail.
• The Audio Description audio (commentary) for the visually impaired cannot be recorded.
• You can record the digital (DVB) subtitles of channel. You cannot record subtitles that come from Text services. To check if digital (DVB) subtitles are available, tune to the TV channel and press **OPTIONS**, select **Options** in the menu bar and select **Subtitle language** to open the list of Subtitles. You can only record a subtitle language preceded with a **DVB** icon.

Watch a recording

To watch a recording, press ⌂, select **Recordings** and press **OK**.

In the list, select the recording and press ▶ (Play) to start the playback.

You can use the ▶▶ (Forward), ◀◀ (Rewind), ❚❚ (Pause) or ■ (Stop) keys on the remote control.

Expired recording
Broadcasters can limit the number of days a recording can be viewed. A recording in the list can show the number of days before it expires.

Failed recording
When a scheduled recording was prevented by the broadcaster or when the broadcast was interrupted, a recording is marked as **Failed**.

Delete a recording
To delete a made recording, select the recording in the list, press **OPTIONS** and select **Delete recording**.

In **Help**, press **List** and look up **Record a program** for more information.

6.6
MyRemote App

About MyRemote App

With the **MyRemote App** you can use your smartphone or tablet as a TV remote control for this TV. You can share photos, music and videos on other devices in your home network. You can consult the TV guide, view the schedule and switch the TV to the channel you want. With the Wi-Fi smart screen function, you can watch TV on your smartphone or tablet.
The MyRemote App functions vary according to version and operating system.

It's free
You can download the MyRemote App for free. Except for the Wi-Fi smart screen function, all MyRemote App functions are free of charge.

App versions
The MyRemote App is continually being developed. Future versions will have new functions and will be gradually available. Regularly check the MyRemote App updates on the App stores.

	MyRemote 2.0	MyRemote 3.0
iOS	✓	✓
Android	✓	

App functions
The App functions vary according to version and the device on which you use the App.

	MyRemote 2.0	MyRemote 3.0
SimplyShare	✓	✓
Net TV	✓	
TV guide *	✓	✓
Control	✓	✓
Wi-Fi smart screen **		✓

* Only available on a tablet.
** A small cost applies.

Languages
The following languages are available in the MyRemote App : English, German, French, Italian, Spanish, Portuguese, Dutch and Russian.
If the language set on your mobile device is not one of these languages, the MyRemote App language is switched to English.

MyRemote App with other TVs
You can use the MyRemote App on Philips TV models built from 2009 onwards.
If your TV is a 2009 model, you need to update the TV software and activate **JointSpace**. If you have a 2010 model, you only need to activate JointSpace on the TV. TV models from 2011 and onwards are ready to use the MyRemote App.
To know in what year your TV was built, check the TV type number (E.g. xxPFLxxx4). If the last number is a '4' your TV is a 2009 model. If the last number is a '5' your TV is a 2010 model. A '6' for 2011, a '7' for 2012 and an '8' for 2013.

Your network

Home network
Your TV, smartphone, tablet and computer, must be linked up with your home network to enjoy the MyRemote App.

To connect the TV to your home network . . .
1 - Connect your network router to the Internet, if it was not connected yet (a broadband Internet connection).
2 - Connect the TV to your network router. You can do this wireless or wired.
In **Help**, press **List** and look up **Network, wireless** or **Network, wired** for more information.

Media server software
If you want to view your photos or play your music and videos from your computer on the TV, you have to install media server software on your computer. Setup this media server software to share your files on your home network.
In **Help**, press **List** and look up **Media servers, supported** for the list of media server software that is compatible with the TV.

Digital Media Renderer - DMR
If your media files do not play on your TV, make sure that the **Digitial Media Renderer** is switched on. As a factory setting, DMR is switched on.
To check if DMR is switched On . . .
1 - Press ⌂ and select ⚙ **Setup** and press **OK**.
2 - Select **Network settings** and press **OK**.
3 - Select **Digital Media Renderer - DMR** and press **OK**.
4 - Select **On** and press **OK**.
5 - Press ↩, repeatedly if necessary, to close the menu.

TV network name
If you have more than one TV in your home network, you can rename the TV in Network settings.
To rename your TV . . .
1 - Press ⌂ and select ⚙ **Setup** and press **OK**.
2 - Select **Network settings** and press **OK**.
3 - Select **TV network name** and press **OK** to show the current name. You can use the keyboard on the remote control to change the TV network name.
4 - Select **Done** and press **OK** when ready.
5 - Press ↩, repeatedly if necessary, to close the menu.

App download

To download the MyRemote App on your smartphone or tablet, you can use the QR codes on this page. Select the operating system (or device type) you need and use your QR code reader to go to the download page directly.

Apple iPhone
To download the app on your iPhone, go to the Apple App Store and look for the **Philips MyRemote** App.

Apple iPad
To download the app on your iPad, go to the Apple App Store and look for the **Philips MyRemote HD** App.

Google play
To download the app on your Android device, go to Google play and look for the **Philips MyRemote** App.

Google play

App menu

From the MyRemote **App menu**, you can start the different MyRemote App functions. Simply tap a function to open it.
To go back to the App menu, tap the App menu button at the top of the page.

Select device
In MyRemote App 3.0 you can select the device with which you want to use all the App functions. Tap the button **Select device** at the top right corner of the App menu.
In MyRemote App 2.0, you need to select the device for each function individually.

You can check the compatibility of MyRemote with your other Philips products at the online support page of your product at www.philips.com/support. Also ensure your Philips product has been updated with the latest software.

App functions

SimplyShare

With **SimplyShare**, you can send media files like photos, music or videos from a device in your home network to another device in your network.*

To open SimplyShare in the MyRemote app, tap the **SimplyShare** button in the MyRemote App menu.

Select a device to send media from
1 - Tap the white bar at the top to open the list of available devices in your network.
2 - Tap a device in the list.

Select a device to play the media
1 - Tap the white bar at the bottom to open the list of available devices in your network.
2 - Tap a device in the list.

Select a media file
Some devices that send files offer them by type of media. If so, you can select the type of media you are looking for - **Music**, **Videos** or **Photos**.
1 - Tap the type of media you are looking for.
2 - In the list, tap the song, video or photo to play it on the device you selected.

Compatible media formats
A wide range of media formats can be played on your TV.

In **Help**, press **List** and look up **Playback formats** for the list of compatible file formats for your TV.

* You can check the compatibility of MyRemote with your specific Philips product at the online support page of your product at www.philips.com/support. Also ensure your Philips product has been upgraded with the latest software.

Net TV

With the Net TV button in the MyRemote home menu, you can open Net TV / Smart TV on your TV.

To open Net TV / Smart TV on your TV, tap the **Net TV** button in the MyRemote home menu.

You can use the remote control of the MyRemote app to browse the pages. With the MyRemote app keyboard, you can easily enter text on TV.

TV guide

If you have a tablet, you can call up the TV guide of your TV on your tablet. You can consult the TV schedule and read programme info. You can tap the programme title to switch to the TV channel directly.

To open the TV guide, tap the TV guide button on the MyRemote App menu.
The first time you tap the TV guide button, you will be asked to link up the tablet and TV.

Preparation
Before you link tablet and TV, check if the TV guide is updated from the Internet.
1 - Press and select **Setup** and press **OK**.
2 - Select **TV settings** > **General settings** > **TV guide**.
3 - Select **From the Internet** and press **OK**.
4 - Press , repeatedly if necessary, to close the menu.

Link up with the TV
To link up the tablet with the TV guide of the TV . . .
1 - Press **GUIDE** on the remote control to open the TV guide on TV.
2 - Press the (yellow) key to open the list of detected mobile devices.
3 - Select **Link a mobile device** and press **OK** to view the code to link up.
4 - On the tablet, start the MyRemote App and tap the **Setup** button on the home menu.
5 - Tap the **TV guide** item.
6 - Enter the code to link up.

Control

With the **Control** function on the MyRemote home menu, you turn your smartphone or tablet into a full remote control for your TV.

Tap the **Control** button to select the TV (or Philips Blu-ray Disc player or Home Theatre System) to control.
Tap the device icon to show its remote control.

Wi-Fi smart screen

Downloading and setup

With the **Wi-Fi smart screen** function, you can watch a digital TV channel from your TV on your smartphone or tablet.

What you need

To watch TV on your smartphone or tablet with Wi-Fi smart screen . . .

- you must have digital TV channels installed on your TV
- the TV must be switched on
- your home network must be a secured network. Secure your network with **WEP**, **WPA**, **WPA2** or set it up using **WPS**.
- you must have the setting **Wi-Fi smart screen** switched on. Press ⌂ (home) > **Setup** > **Network settings** > **Wi-Fi smart screen**.

How to buy

Tap **Wi-Fi smart screen** in the **App menu** to open the function. If you did not purchase this function yet, you will be asked to buy it online. After the purchase, **Wi-Fi smart screen** opens automatically and you can start watching TV.

Parental rating

Some digital broadcasters have rated their programmes. When the rating is equal or higher than the rating you have set for your child's age, the programme will be locked. You will need a **PIN code** to unlock and watch the programme.
To switch on **Parental rating**, tap the **Setup** button on the App menu. Switch on **Parental rating**, set your PIN code and set an age. The parental rating in the MyRemote App is set for watching TV on your smartphone or tablet, not the TV.
If you have forgotten your PIN code, you need to reinstall the MyRemote App from the App store. On the purchase page for Wi-Fi smart screen, you can restore your purchase without cost.

Watch a TV channel

To watch a TV channel with the Wi-Fi smart screen function, tap **Wi-Fi smart screen** in the **App menu**. Wi-Fi smart screen will show the TV channel currently on TV. If the TV is switched to a connected device, you need to switch the TV back to **Watch TV** or to **Watch Satellite** (if a built-in satellite tuner is available).

Switch TV channels

To switch TV channels, swipe the touchscreen of your smartphone or tablet. Swipe to the right to watch the previous channel or swipe to the left to watch the next channel. The sequence of channels follows the TV channel list.
You can also use the **Channel bar** to look for and switch to TV channels.

Pause TV and Recording

If you pause the TV broadcast on TV or start recording a broadcast with the TV (on a connected USB Hard Drive), the Wi-Fi smart screen function will stop.

Sound

The sound that comes with the TV channel is mono sound.

Subtitles

Subtitles on Wi-Fi smart screen are not supported.

Channel bar

To switch to a channel further up or down the TV channel list, you can call up the **Channel bar**.
To call up the **Channel bar**, tap the middle of your touchscreen once. The Channel bar appears at the bottom of the screen, together with the **Tool bar** at the top. You can swipe the Channel bar and look for a TV channel.
To switch to a TV channel, tap the channel icon once.
To close the Channel bar and Tool bar, tap the middle of the screen again.

TV guide info

If you have a tablet and you linked up the TV guide of your TV with the MyRemote App, you can view TV guide information. Above each TV channel icon the TV guide shows the current and next programme for that channel.

Tool bar

In the Wi-Fi smart screen tool bar, you can select the picture format, select the TV or Satellite channel list (if available on TV), open the tool tips or switch the TV on standby.
To call up the **Tool bar**, tap the middle of your touchscreen once. The Tool bar appears at the top of the screen, together with the Channel bar.
To close the Tool bar and Channel bar, tap the middle of the screen again.

App menu button

To go back to the MyRemote App menu, tap the **App menu** button.

Scale

To scale the picture to just fit or completely fill the screen, tap the **Scale** button to toggle between fill or fit.

TV or Satellite

If you have a built-in satellite tuner in your TV, you can select the channel list of **Watch TV** or **Watch satellite**. The button shows which channel list is currently selected.
To change the current channel list, tap the button and tap **TV** or **Satellite** to select the channel list you want. If you do not have a built-in satellite tuner, there is no selection button.

Tool tips ⓘ

To read some **Tool tips**, tap the ⓘ icon. The tool tips appear on top of the available buttons.
To close the Tool tips, tap anywhere on the touchscreen.

TV ⏻

With Wi-Fi smart screen you can switch the TV on standby. But with the network connection lost, you cannot start Wi-Fi smart screen again from a TV on standby.
If you activated **Quick start** and the TV is in a Quick start time frame, you can still start Wi-Fi smart screen and watch TV. You can stop and start Wi-Fi smart screen as long as the TV is within the Quick start time frame.
If you stop Wi-Fi smart screen outside a Quick start time frame, the TV stays in Quick start for 5 minutes to allow you to start Wi-Fi smart screen again without having to switch on the TV itself. In **Help**, press ▬ **List** and look up **Quick start** for more information on Quick start.

To switch the TV on standby, tap the **TV** ⏻ button in the tool bar.

7

Skype

7.1

What is Skype?

With **Skype™** you can make video calls on your TV for free. You can call and see your friends from anywhere in the world. Talk to your friends while watching them on the big screen of your TV.

To make a video call on Skype, you need the separately sold **Philips PTA317** TV camera with a built-in microphone and a good connection to the Internet.

The TV needs to be connected to the Internet before you can set up Skype. You can connect your TV either wireless or wired.
In **Help**, press ■ **List** and look up **Network, wireless** to connect the TV to your home network and the Internet.

Skype account
To use Skype, you need to create a Skype account for yourself or for your family. You can create a new account for Skype on your TV or on your computer.

Skype Credit or Skype Subscriptions
With Skype, for a little cost, you can also call phones or mobile phones. Using your computer you can buy Skype Credit or take a Skype subscription at www.skype.com

7.2

Start Skype

Install the camera

Connect the TV camera cable to one of the USB connections on the side or on the back of the TV.
Bend the small clamp as shown in the illustration below and position the camera on the top of the TV.

Point the camera to the position you usually sit at. In the Skype settings, you can test the camera, check its viewpoint or set the zoom level.

You can position the camera anywhere you want but it is recommended to put it away from the speakers of the TV.

If the TV camera is not connected, Skype will not start.

Sign in - New account

With the TV connected to the Internet and the TV camera mounted or built-in, you can start Skype on your TV.

To open the Skype sign-in page, press ⌂ to open the Home menu, select **Skype** and press **OK**.
Enter your **Skype Name** and **Password**, select **Sign in** and press **OK**. The Skype menu opens on screen.

Forgotten your Skype name or password?
Start Skype on your computer to get a temporary password from Skype.

Create a new account
If you do not have a Skype Name and Password yet, you can create a new account on the sign-in page on TV.

1 - On the sign-in page, select **New account** and press **OK**.

2 - Create your new account.
- **Full name**
Enter your full name.
- **Skype name**
Enter a name as your Skype name. Your Skype Name will be shown in the list of contacts of other Skype users. A Skype Name must begin with a letter, upper or lowercase. It must have 6 to 32 characters and can contain numbers. A Skype Name cannot contain a space.
- **Password**
Enter your password. Your password must have 6 to 20 characters and must at least contain one letter or one number. It cannot contain special characters like a trademark, bullet or euro sign. A Skype password cannot contain a space.
- **Email**
Enter your email address.

3 - Read and accept the Skype **Terms of Use**.

4 - If your new account was accepted, you are signed in.

You can edit or complete your **Skype profile** on your computer. Start Skype on your computer, sign in with your Skype Name and Password and open your Skype profile. You can change your profile picture, add a mood message or set the privacy settings.

No emergency calls

No emergency calls - Skype is not a replacement for your telephone and cannot be used for emergency calling.

7.3

Contacts

Contacts page

On the **Contacts** page you can find your list of Skype contacts. The contacts are shown with their Skype Name. On this page, you can add, block or delete contacts. You can view contact details or view the history of calls you had with this contact.

Contact info
To view the details of a contact, select a contact and press **INFO**.

Contact history
To view the calls you had with a contact, press **Contact history**.
When you sign in with another Skype account on this TV, the history of all contacts of your account is cleared.

Online status
To know if a contact is online, check the online status icon next to the Skype Name of your contact. Like all users, your online status is also shown in their contacts page. But also like other users, you can change your online status.
1 - On the Contacts page, press **OPTIONS** and select **Online status**.
2 - In the list, select a status and press **OK**.
Each time you switch the TV on, your status is switched back to **Online**.

- **Online**
This is your usual setting when you sign into Skype. Your contacts can see that you are online and can contact you.

- **Away**
Your contacts can see that you are signed in but not necessarily watching TV. Your contacts can still try to call you.

- **Do not disturb**
Your contacts can see that you are online but you do not wish to be disturbed. They can call you and you will be alerted with sound.

- **Invisible**
You will appear to be offline to all of your contacts, but you can still use Skype as usual. You can use Skype without being disturbed by incoming calls.

- **Offline**
Automatically shown when you are not signed in to Skype. You can also set your status to offline yourself.

Phone or mobile numbers
You can also add a phone number of a landline phone or mobile phone to your list of contacts. Such a contact will be marked with this icon.

Add a contact

If you know the Skype Name or email of a friend, you can easily add them to your list of contacts. If you do not know their Skype Name or email, you can also try to look for them by name.

1 - In the menu bar select the **Contacts** page. You can press **LIST** or to jump to the menu bar.
2 - Press **Add contact**.
3 - In the text field, enter a Skype name, email address or name. Use the key pad on the remote control to enter the text.
4 - Select **Search** and press **OK**.
5 - Skype will find users that match your search. To know if you selected the person you are looking for, press **INFO** for the contact details.
6 - If this is the person you are looking for, select **Add** and press **OK**.

The newly added contact has to accept your request to add his or her name to your list of contacts. Until the contact accepts your request, the new contact appears offline.

Accepting a Contact request
Other Skype users can invite you to be on their contact list. You will be notified of their request, which you can accept or decline.

Block a contact

You can block any Skype user from finding you online. A blocked contact will be unable to contact you with Skype. A blocked contact will not be notified, you will always appear to be offline in the contact list of the blocked contact.

On the **Contacts** page, select a contact and press **Block contact**.

You can always unblock a contact. To unblock, select the contact in the list and press **Unblock contact**.

In the list of contacts a blocked contact has this icon.

To view a list of blocked contacts, press **OPTIONS** and select **Blocked contacts**.
To unblock someone in the list, select the name and press **OK**.

7.4
Calling on Skype

Video and voice call

Make a Video call

With Video call you can call and see your friends on your TV screen, for free.

Make a Video call
On the **Contacts** page, select the person you want to call and then select the **Video call** button and press **OK**.

If your contact has a camera connected and accepts the call, you can see the person on your TV, full screen. When your TV camera is switched on, the blue indicator LED lights up. You can check what your contact can see, in the small screen on your TV.

To mute your microphone while you are making the call, press **Mute**.
To switch off your camera, press **Camera off**.
To zoom and frame the camera, press **Zoom**. Now, you can press **Zoom out** or press **Zoom in**. You can use the arrows to frame the camera. When the zoom and framing is fine for you, press **Set zoom**.

To end a call, select the **End call** button and press **OK**.

Make a Voice call

You can make a Skype call without video, with the camera switched off.

To make a call without video, select the contact, then select the **Voice call** button and press **OK**.
To mute your microphone while you are calling, press **Mute**.
To end the voice call, select the **End call** button and press **OK**.

On a voice call, you can still switch to a Video call. To switch to Video call, press **Camera on**.

A contact can add you to a voice call with more than one participant. You cannot add an extra participant yourself.

Calling phones and mobiles

With Skype you can also call landline phones and mobile phones. To call phones you need to buy Skype Credit on Skype on your computer. You can buy Skype Credit or subscribe to a Skype subscription.

Call a phone
1 - Select **Call phones** in the menu bar. You can press **LIST** to jump to the menu bar.
2 - Enter the telephone number with the remote control keys or select the numbers on the dial pad on screen.
To enter a + (plus), press **+**.
To enter a * (asterisk), press *.
To enter a # (hash), press #.
To delete one digit, press **Backspace**.

3 - When you entered the complete number, select the **Call** button and press **OK** to start calling.
To mute your microphone while you are calling, press **Mute**.

To end a phone call, select the **End call** button and press **OK**.

List of recently called phones
If you have called some phones with Skype earlier, you can select a phone number in the list at the left of the page.
To clear the selected phone number, press **Clear number**.
To add this phone number to your list of contacts, press **Add to contacts**.
To clear all phone numbers, press **Clear all**.

No emergency calls - Skype is not a replacement for your telephone and cannot be used for emergency calling.

Receiving a call

When you are signed in to Skype and watching TV, you are notified of an incoming call with a message on screen. The notification says who is calling and you can accept or decline the call.
To accept the call, select the **Answer** button in the notification and press **OK**.
To decline, select the **Decline** button and press **OK**.

Also, new contact requests will be shown immediately.

Skype during rental movies and Pause TV
While you are watching a rental movie from a broadcaster or video store, or using Pause TV, accepting a Skype call will interrupt the movie or paused programme.
To resume watching the rental movie, you need to go back to the video store or broadcast service. Some video stores and services do not allow you to restart the movie. The Pause TV programme storage is lost.

Skype during recording
While recording a programme on a connected USB Hard Drive, the TV will notify you if there was an incoming call and from who it was. The TV prevents accepting a Skype call during recording. You can easily answer the call from the **Recent** page, after the recording is done.

Contact notifications
Next to normal calls, you can be notified when your contacts come online or go offline. You can switch off these contact notifications on the **Settings** page.

Recent calls

On the **Recent** page, you can view your recent Skype events.
The most recent Skype event is shown first. It shows which contact, the type of event - video call or Phone call and when it occurred.

As on the Contacts page, you can make a Video call, Voice call or Phone call to a selected contact.

History
For how long your Skype events are kept in this history list depends on the amount of contacts you have and how intensively you use Skype.
Also, if you sign in with another Skype account on this TV, the recent history will be cleared.

Voicemail

If someone calls you on Skype and you cannot take the call, he or she can leave a spoken message on your Skype voicemail.

To leave a message on a contacts voicemail, you need to set up Skype voicemail on your computer.
If you did not setup voicemail for yourself but the contact who called has setup voicemail, he or she can leave a voicemail for you.

On the **Voicemail** page, you can play voicemail messages that were left for you. If a number is shown next to the voicemail icon in the menu bar, you have a new voicemail message - **1**.

Play a voicemail

To play a voicemail, select the voicemail icon in the menu bar, select the new voicemail in the list and press **OK**. You can listen to the new voicemail as many times you want. However, when you leave the **Voicemail** page, all played voicemails are removed from the list.

As on the Contacts page, you can make a Video call, Voice call or Phone call to a selected contact.

7.5
Skype Credit

On Skype, you can buy **Skype Credit** or take a **Skype subscription**. With Skype Credit or a Skype subscription available, you can call landline phones and mobile phones with your TV.

Buy Skype Credit
To buy Skype Credit or take a Skype subscription, sign in to Skype on your computer.
The Skype Credit you buy will be available when you sign in to Skype on your TV.

The amount of credit or the subscription information is shown on each page where you can make a phone call.

Skype Credit low
You will be notified if your credit is too low to make a phone call.

7.6
Skype settings

Automatic sign-in

You can set Skype to automatically sign in when you switch on the TV. You do not need to enter your Skype Name or password.

Navigate to the menu bar and select **Settings** to open the Settings page.
Select **Automatic sign-in** and press **OK** to check or uncheck.

Contact notifications

You can receive or block the online status notifications of your contacts while you watch TV.

Navigate to the menu bar and select **Settings** to open the Settings page.
Select **Contact notifications** and press **OK** to check or uncheck.

Online status

You can change your own online status.

Navigate to the menu bar and select **Settings** to open the Settings page.
Select **Online status** and then select the online status you want your contacts to see when you are online and press **OK**.

Ringtone volume

You can adjust the Skype ringtone volume.

Navigate to the menu bar and select **Settings** to open the Settings page.
Select **Ringtone volume** and then adjust the volume with the arrows up and down.

Test camera

You can test if your Skype camera and microphone work. Also you can zoom and frame the picture of your camera to exactly what you want your contacts to see.

Navigate to the menu bar and select **Settings** to open the Settings page.
Select **Test camera**. The picture of the camera should appear and when you talk, the microphone volume should indicate your voice.

Zoom and frame the picture
1 - Press **Zoom**.
2 - Press **Zoom out** or **Zoom in**.
3 - With the picture zoomed in, you can shift the camera frame up, down, left or right to exactly frame the picture. Use the arrows on the remote control to shift.
4 - Press **Set zoom** when done.

The volume of the microphone is adjusted automatically.

Change password

You can change your current Skype password and enter a new password.

1 - Navigate to the menu bar and select **Settings** to open the Settings page.
2 - Select **Change password**.
3 - Select the **Current password** text field to enter your password.
4 - Select the **New password** text field and enter a new password.
5 - Select the **Repeat new password** text field and enter the new password again.
6 - Press **OK** to send the new password for confirmation.

7.7
Sign out

Navigate to the menu bar and select **Settings** to open the Settings page.
Select **Sign out** to quit Skype on your TV.

7.8
Terms of Use

Read the Terms of Use of Skype at **www.skype.com/go/tou**

Also read the Privacy Statement at **www.skype.com/privacy**

8

Games

8.1

Play a game

With a game console connected to the TV, you can play games on TV.

Start a game
Switch on the game console and press ⌂, select the icon you have set for your game console (e.g. Game or Player) and press **OK** to view the game.

Ideal game setting
For some games, where speed and precision is needed, set the TV to the ideal **Game** setting before you start playing.
If your game console is added as a **Game** type of device in the Source menu (list of connections), the TV is set to the ideal **Game** setting automatically.
If the type of your game console is set as **Player** and used as a disc player most of the time, leave the device type set to **Player**.

To set the TV to the ideal setting manually . . .
1 - Press ⌂, select ⚙ **Setup** and press **OK**.
2 - Select **TV settings** > **Picture** > **Game or computer** and press **OK**.
3 - Select **Game** and press **OK**.
4 - Press ↩, repeatedly if necessary, to close the menu.
Remember to set the Game or computer setting back to **Off** when you stop playing the game.

In **Help**, press ■ **List** and look up **Game console, connect** to connect a game console to the TV.

8.2

Two-player games

What is a two-player game

If you play a multi-player game with split screens, you can set the TV to show each screen as a full screen. Each player sees only his part of the game, full screen. The TV uses 3D technology to show both screens.
To view the two different full screen pictures, you need a pair of 3D glasses for each player.

What you need

To play a two-player game with this TV, you need a two-player kit with 2 passive 3D glasses - Philips PTA436 (sold separately).
Also, the game console must be connected with HDMI.

Play a two-player game

To start a two-player game . . .
1 - Press ⇥ **Source**, select the game console and press **OK**.
2 - On the game console, start the game and select the multi or two-player mode. Select the mode for split screen viewing.
3 - On the TV, press ⫶ **OPTIONS**, select **Picture and sound**, select **Two-player game** and press **OK***.
4 - Select the format in which the split screen game is shown on screen, **Side by side** or **Top / bottom** and press **OK**. The TV shows the 2 screens as full screens.
To watch the 2 different screens, each player puts on one of the glasses - player 1 or player 2.

In and out of split screen view
In two-player split screen view, you can switch back and forth from split screen to combined view, to be able to read the game menu or game scores.
To switch views back and forth, press **OK** on the remote control of the TV.

Stop Two-player game
To stop the two-player split screen view, press ⌂ and select another activity.

* If Two-player gaming is unavailable in the menu, press **3D** on the remote control and select **2D** and press **OK**.

9

TV Specifications

9.1

Environmental

Saving energy

Energy saving bundles the TV settings that help the environment.

While you are watching TV channels, press to open **Eco settings**. Active settings are marked with a .
Press again to close.

Energy saving
This Smart picture setting sets the picture, together with Ambilight, in the most ideal energy conscious setting. To switch on, select **Energy saving** in Eco settings and press **OK**. To switch off Energy saving, select another Smart picture setting.

Screen off
If you only listen to music, you can switch off the TV screen to save energy. Select **Screen off** and press **OK**. To switch the screen back on, press any key on the remote control.

Light sensor
To save energy, the built-in ambient light sensor lowers the brightness of the TV screen when the surrounding light darkens. The built-in light sensor automatically adjusts the picture, together with Ambilight, to the lighting conditions of the room. To switch on, select **Light sensor** and press **OK**. To switch off, press **OK** again.

Switch off timer
If you do not press a key on the remote control during a 4 hour period, or if the TV receives no signal for 10 minutes, the TV switches off automatically to save energy. Select **Switch off timer**.
If you use the TV as a monitor or use a digital receiver to watch TV (a Set-top box - STB) and you do not use the remote control of the TV, deactivate the automatic switch off.

In addition to these eco settings, your TV also has environmentally friendly adjustments with regard to power consumption.

Low standby power
The class-leading and highly advanced power circuitry brings down the power consumption of the TV to an extremely low level, without losing out on the constant Standby functionality.

Power management
The advanced power management of this TV ensures the most efficient use of energy. You can check how your personal TV settings, the level of brightness in current onscreen pictures, and the surrounding light conditions determine the relative power consumption.

To check the relative power consumption, press > **Setup** > **Watch demos** > **Active control** and press **OK**. Select a setting to check the corresponding values.

European energy label

The **European Energy Label** informs you on the energy efficiency class of this product. The greener the energy efficiency class of this product is, the lower the energy it consumes.
On the label, you can find the energy efficiency class, the average power consumption of this product in use and the average energy consumption for 1 year. You can also find the power consumption values for this product on the Philips website for your country at **www.philips.com/TV**

Eco-label

Philips continuously focuses on lowering the environmental impact of its innovative consumer products. We aim our efforts towards environmental improvements during manufacturing, reduction of harmful substances, energy-efficient use, end-of-life instructions and product recycling.

Thanks to our environmental effort, this TV has been awarded the **European Ecolabel** – the flower – (www.ecolabel.eu).
You can find detailed information on standby energy consumption, warranty policy, spare parts and recycling of this TV on the Philips website for your country at www.philips.com

End of use

Disposal of your old product and batteries
Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

When this crossed-out wheeled bin symbol is attached to a product it means that the product is covered by the European Directive 2002/96/EC.

Please inform yourself about the local separate collection system for electrical and electronic products.

Please act according to your local rules and do not dispose of your old products with your normal household waste. Correct disposal of your old product helps to prevent potential negative consequences for the environment and human health.

Your product contains batteries covered by the European Directive 2006/66/EC, which cannot be disposed with normal household waste.

Please find out for yourself about the local rules on separate collection of batteries because correct disposal will help to prevent negative consequences for the environment and human health.

9.2
Power

Product specifications are subject to change without notice. For more specification details of this product, see **www.philips.com/support**

Power
- Mains power : AC 220-240V +/-10%
- Ambient temperature : 5°C to 35°C
- Standby power consumption : < 0.1W
- Power saving features : Light sensor, Eco mode, Picture mute (for radio), Auto switch-off timer, Eco settings menu.

The power rating stated on the product typeplate is the power consumption for this product during normal household use (IEC 62087 Ed.2). The maximum power rating, stated between brackets, is used for electrical safety (IEC 60065 Ed. 7.2).

9.3
Reception

- Aerial input : 75 ohm coaxial (IEC75)
- Tuner bands : Hyperband, S-Channel, UHF, VHF
- DVB : DVB-T (terrestrial, antenna) COFDM 2K/8K, DVB-T2 : only for TV types '. . . T/12', DVB-C (cable) QAM
- Analogue video playback : NTSC, SECAM, PAL
- Digital video playback : MPEG2 SD/HD (ISO/IEC 13818-2), MPEG4 SD/HD (ISO/IEC 14496-10)
- Digital audio playback (ISO/IEC 13818-3)
- See selected countries on the TV type plate
- Satellite aerial input : 75 ohm F-type
- Input frequency range : 950 to 2150MHz
- Input level range : 25 to 65 dBm
- DVB-S/S2 QPSK, symbol rate 2 to 45M symbols, SCPC and MCPC
- Supported satellites : Astra 19.2°E, Astra 23.5°E, Astra 28.2°E, Hotbird 13.0°E, TürkSat 42.0°E, Eutelsat 7°W, Thor 1°W
- Astra HD+ support
- LNB : DiSEqC 1.0, 1 to 4 LNBs supported, Polarity selection 14/18V, Band selection 22kHz, Tone burst mode, LNB current 300mA max
- See selected countries on the TV type plate

9.4
Display

Type

- Diagonal screen size :
- 42PFL6008, 6158, 6188, 6198, 6678 : 107 cm / 42 inch
- 47PFL6008, 6158, 6188, 6198, 6678 : 119 cm / 47 inch
- 55PFL6008, 6158, 6188, 6198, 6678 : 140 cm / 55 inch
- 60PFL6008, 6158, 6188, 6198, 6678 : 152 cm / 60 inch
- Panel resolution : 1920x1080p
- 3D : Easy 3D, Two-player Full Screen gaming, Premium 3D Depth, Premium 2D to 3D conversion

Display resolutions

Video formats
Resolution — Refresh rate
- 480i - 60 Hz
- 480p - 60 Hz
- 576i - 50 Hz
- 576p - 50 Hz
- 720p - 50 Hz, 60 Hz
- 1080i - 50 Hz, 60 Hz
- 1080p - 24 Hz, 25 Hz, 30 Hz
- 1080p - 50 Hz, 60 Hz

Computer formats
Resolutions (amongst others)
- 640 x 480p — 60 Hz
- 800 x 600p — 60 Hz
- 1024 x 768p — 60 Hz
- 1280 x 768p — 60 Hz
- 1360 x 765p — 60 Hz
- 1360 x 768p — 60 Hz
- 1280 x 1024p — 60 Hz
- 1920 x 1080i — 60 Hz
- 1920 x 1080p — 60 Hz

9.5
Sound

Smart Stereo 3D wOOx
- Output power (RMS) : 25W
- Sound enhancement : Auto Volume Leveller, Clear Sound, Incredible surround, Incredible Surround 3D

9.6
Multimedia

Connections
- USB 2.0
- Ethernet LAN RJ-45
- Wi-Fi 802.11b/g/n (built-in)

Supported USB file systems
• FAT 16, FAT 32, NTFS

Playback formats
• Containers : 3GP, AVCHD, AVI, DivX®, MPEG-PS, MPEG-TS, MPEG-4, Matroska (MKV), Quicktime (MOV), Windows Media (ASF/WMV/WMA)
• Video Codecs : DivX®, MPEG-1, MPEG-2, MPEG-4 Part 2, MPEG-4 Part 10 AVC (H264), VC-1, WMV9
• Audio Codecs : AAC, HE-AAC (v1/v2), AMR-NB, Dolby Digital, Dolby Digital Plus, MPEG-1/2/2.5 Layer I/II/III (includes MP3), WMA (v2 to v9.2), WMA Pro (v9/v10)
• Subtitles :
– Formats : SAMI, SubRip (SRT), SubViewer, DivX® subtitles
– Character encodings : UTF-8, Central Europe and Eastern Europe (Windows-1250), Cyrillic (Windows-1251), Greek (Windows-1253), Western Europe (Windows-1252)
• Image Codecs : JPEG
• Limitations :
– Maximum supported total bit rate for a media file is 30Mbps.
– Maximum supported video bit rate for a media file is 20Mbps.
– MPEG-4 AVC (H.264) is supported up to High Profile @ L4.1.
– VC-1 is supported up to Advanced Profile @ L3.

DivX®
In **Help**, press **List** and look up **DivX® VOD** for more information.

Supported media server software (DMS)
• PC - Microsoft Windows XP, Vista or Windows 7
– PacketVideo - Twonky Media
– PacketVideo - TwonkyManager
– Microsoft - Windows Media Player
• Mac OS X
– PacketVideo - TwonkyServer
– PacketVideo - TwonkyManager
• Mobile devices
– Philips MyRemote - iOS, Android
– Interoperability and performance may vary, depending on the capabilities of the mobile device and the software used.

ESD regulations
This apparatus meets performance criteria A for ESD. In case the apparatus does not recover in file sharing mode due to electrostatic discharge, user interference is required.

9.7
Connectivity

TV Rear
• SCART (adapter included): Audio L/R, CVBS in, RGB
• YPbPr : Y Pb Pr (adapter included), Audio L/R (stereo mini-jack 3.5mm)
• Audio In (DVI to HDMI) (stereo mini-jack 3.5mm)
• 3x HDMI in with ARC (3D)
• Audio Out L/R — display synchronised (optical)
• Network LAN — (RJ45)

TV Side
• 1x HDMI in with ARC (3D)
• 3x USB 2.0
• Common interface slot (CI+/CAM)
• Headphones (stereo mini-jack 3.5mm)

9.8
Dimensions and weights

42PFL6008 / 6158 / 6188 / 6198 / 6678
Width 953 mm - Height 556 mm - Depth 36 mm - Weight ±13 kg
. . . with TV stand - Height 633 mm - Depth 205 mm - Weight ±15 kg

47PFL6008 / 6158 / 6188 / 6198 / 6678
Width 1064 mm - Height 619 mm - Depth 36 mm - Weight ±15 kg
. . . with TV stand - Height 696 mm - Depth 225 mm - Weight ±17 kg

55PFL6008 / 6158 / 6188 / 6198 / 6678
Width 1235 mm - Height 715 mm - Depth 36 mm - Weight ±19 kg
. . . with TV stand - Height 792 mm - Depth 280 mm - Weight ±21 kg

60PFL6008
Width 1352 mm - Height 780 mm - Depth 36,5 mm - Weight ±25 kg
. . . with TV stand - Height 857 mm - Depth 280 mm - Weight ±27 kg

UMv 3104 327 0082.4 - 130311

10

TV Software

10.1

Software version

To view the current TV software version, press ⌂, select ⚙ **Setup** and press **OK**.
Select **Software settings** and press **OK**.
Select **Current software info** and see **Version: . . . .**

10.2

Software update

Software update from Internet

If the TV is connected to the Internet, you may receive a message from TP Vision to update the TV software. You need a high-speed (broadband) Internet connection.

If you receive this message, we recommend you carry out the update. Select **Update**. Follow the instructions on screen.

You can also look for new updates yourself.
To look for an update, press ⌂, select ⚙**Setup** and press **OK**.
Select **Update software** and press **OK**. Follow the instructions on screen.

When the update is complete, the TV switches off and back on again automatically. Wait for the TV to switch itself back on. Do not use the Power switch ⏻ on the TV.

Software update from USB

It might be necessary to update the TV software. You need a computer with an high-speed Internet connection and a USB memory device to upload the software on the TV. Use a USB memory device with 256MB free space. Make sure that write protection is switched off.

1 - Start the update on TV
To start the software update, press ⌂, select ⚙**Setup** and press **OK**.
Select **Update software** > **USB** and press **OK**.

2 - Identify the TV
Insert the USB memory into the side of the TV, select **Start** and press **OK**. An identification file is written on the USB memory device.

3 - Download the TV software
Insert the USB memory into your computer. On the USB memory device, locate the file **update.htm** and double click it. Click on **Send ID**. If new software is available, download the .zip file. After the download, unzip the file and copy the file **autorun.upg** onto the USB memory device. Do not place this file in a folder.

4 - Update the TV software
Insert the USB memory into the TV again. The update starts automatically. The TV switches itself off for 10 seconds and then back on again. Please wait.
Do not . . .
• use the remote control
• remove the USB memory device from the TV

If a power cut occurs during the update, never remove the USB memory device from the TV. When the power returns, the update will continue.

At the end of the update, the message **Operation successful** appears on screen. Remove the USB memory device and press ⏻ on the remote control.

Do not . . .
• press ⏻ twice
• use the ⏻ switch on the TV
The TV switches itself off (for 10 seconds) and then back on again. Please wait.

The TV software has been updated. You can use the TV again.

To prevent an accidental update of the TV software, delete the autorun.upg file from the USB memory device.

10.3

Open source software

This television contains open source software. TP Vision Netherlands B.V. hereby offers to deliver, upon request, a copy of the complete corresponding source code for the copyrighted open source software packages used in this product for which such offer is requested by the respective licences.

This offer is valid up to three years after product purchase to anyone in receipt of this information. To obtain the source code, please write in English to . . .

Intellectual Property Dept.
TP Vision Netherlands B.V.
P.O. Box 80077
5600 KA Eindhoven
The Netherlands

10.4

Open source license

11
Support

11.1
Register

Register your TV and enjoy a range of benefits including full support (including downloads), privileged access to information about new products, exclusive offers and discounts, the chance to win prizes and even participate in special surveys about new releases.

Go to **www.philips.com/welcome**

11.2
Using help and search

This TV offers help on screen.
You can find the information you are looking for in the list of topics or read the Help as a book with chapters.

Open Help
Press ⌂ to open the Home menu.
Select ? **Help** and press **OK**.

To view an alphabetical list of topics, select the ☰ **List** tab in the menu bar.
To read the Help as a book, select 🕮 **Book** in the menu bar.

Before you execute the Help instructions, close Help.
To close Help, press ↩ or ⌂.

On most settings and options in menus, you can press ▬ (blue key) to read some information on the selected setting or option.
If information on the setting or option is available, you can press ▬ (blue key) again to open the relevant page in Help.

For some activities, like Text, the colour keys have specific functions and cannot open Help.

TV Help on your tablet, smartphone or computer
You can download the TV Help in PDF format to read on your smartphone, tablet or computer.
To carry out extended sequences of instructions more easily, you can print out the relevant Help page from your computer.
To download the Help (user manual) go to www.philips.com/support

11.3
Online help

To solve any Philips TV related problem, you can consult our online support. You can select your language and enter your product model number.

Go **to www.philips.com/support** .

On the support site you can find your country's telephone number to contact us as well as answers to frequently asked questions (FAQs). In some countries, you can chat with one of our colaborators and ask your question directly or send a question by email
You can download new TV software or the manual to read on your computer.

11.4
Consumer Care

For support, you can call the Consumer Care hotline in your country. Find the telephone number in the printed documentation that came with the TV.
Or consult our website **www.philips.com/support** .

TV model number and serial number
You might be asked to provide the TV product model number and serial number. Find these numbers on the packaging label or on the type label on the back or bottom of the TV.

12

Copyrights and licences

12.1

HDMI

HDMI®
The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.

12.2

Dolby

Dolby®
Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.

12.3

Skype

Skype™ is a trademark of Skype™ Limited or its related companies.

12.4

DivX

ABOUT DIVX VIDEO: DivX® is a digital video format created by DivX, LLC, a subsidiary of Rovi Corporation. This is an official DivX Certified® device that plays DivX video. Visit divx.com for more information and software tools to convert your files into DivX videos.
ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified® device must be registered in order to play purchased DivX Video-on-Demand (VOD) movies.
To obtain your registration code, locate the DivX VOD section in your device setup menu. Go to vod.divx.com for more information on how to complete your registration.

12.5

Microsoft

Windows Media
Windows Media is either a registered trademark or trademark of Microsoft Corporation in the United States and/or other countries.

Microsoft PlayReady
Content owners use Microsoft PlayReady™ content access technology to protect their intellectual property, including copyrighted content.
This device uses PlayReady technology to access PlayReady-protected content and/or WMDRM-protected content. If the device fails to properly enforce restrictions on content usage, content owners may require Microsoft to revoke the device's ability to consume PlayReady-protected content. Revocation should not affect unprotected content or content protected by other content access technologies. Content owners may require you to upgrade PlayReady to access their content. If you decline an upgrade, you will not be able to access content that requires the upgrade.

12.6

Wi-Fi Alliance

Wi-Fi®, the Wi-Fi CERTIFIED logo, the Wi-Fi logo are registered trademarks of the Wi-Fi Alliance. **Wi-Fi CERTIFIED Miracast™**, **Miracast™** are trademarks of the Wi-Fi Alliance.

12.7

Other trademarks

All other registered and unregistered trademarks are the property of their respective owners.

Index

3
3D glasses, type 50
3D glasses, use 50
3D, 2D to 3D 50
3D, cleaning glasses 51
3D, health warning 50
3D, optimal viewing 50

A
Active control 18
Ambilight, brightness 40
Ambilight, dynamic speed 41
Ambilight, mode 40
Ambilight, on or off 40
Ambilight, static colour 41
Ambilight, TV placement 6
Ambilight, TV switch off 41
Ambilight, wall colour 41
Amplifier 40
Antenna connection 6
Antenna connection, tips 9
App, feedback 53
App, gallery 53
App, lock 53
App, recommended 53
App, search 53
Audio commentary 42
Audio effect 42
Audio language 34
Audio Out - Optical 10
Audio to video sync 13
Auto incredible surround 3D 39
Auto subtitle shift 11
Auto volume leveling 39
Automatic channel update 27

B
Backlight contrast 36
Bass 39
Black bars 30
Brightness 37

C
CAM - Conditional Acces Module 11
CAM, install 11
Channel list copy 28
Channel list copy, copy 28
Channel list copy, upload 28
Channel list, New 27
Channel lists 25
Channel lock 27
Channel package, update 45
Channel packages 45
Channel update message 27
Channel, favourite 26
Channel, logos 26
Channel, rename 26
Channel, reorder 26
Channel, switch 24
Channels, reinstall 27
Channels, update 27
Child lock code 27
CI+ 11
Clear LCD 36
Clock 35
Colour 36
Colour enhancement 37
Colour temperature 37
Common Interface slot 11
Connections, list 33
Connectivity guide 9
Custom colour temperature 37

D
Device icon 33
Digital Text 31
DivX® VOD 56
DMR - Digital Media Renderer 9
DVB 28
DVB, settings 29
DVI, connect 9
Dynamic backlight 37

E
EasyLink 10
EasyLink, connections 9
EasyLink, settings 11
Eco settings 70
End of use 70
ESD 72
European Ecolabel 70
European Energy Label 70

F
Factory settings 28
Frequency scan 29
Frequency step size 29

G
Game console, connect 14
Game or computer 38
Game or computer, computer 17
Game or computer, game 69
Game, play 69
Game, start two-player 69
Game, two-player 69
Gamma 37

H
HbbTV 31
HDCP, copy protection 9
HDMI ARC 9
HDMI connection, tips 9
Headphones volume 39
Headphones, connect 17
Hearing impaired 42, 47
Help, on a tablet 74
Help, usage 74
Home menu 52
Home Theatre System, multichannel 13
Home Theatre System, volume leveling 13

I
Infrared sensor 23
Interactive TV 31
Internet App 53
Internet memory, clear 9

K
Key beep 42
Keyboard, connect 15

L
Language, menus 34
Light sensor 70
Lounge light 41

M
Manual installation 30
Media server software 8
Media servers, supported 72
Miracast, block/unblock 57
Miracast, share a screen 56
Miracast, stop sharing 57
Miracast™ 56
Mixed volume 42
Mono/Stereo 39
Mouse, connect 15
Mouse, speed 15
MPEG artefact reduction 36
Music files, playback 55
MyRemote App, Control 61
MyRemote App, download 60
MyRemote App, JointSpace 59
MyRemote App, menu 60
MyRemote App, network 59
MyRemote App, SimplyShare 61
MyRemote App, TV guide 61
MyRemote App, versions 59
MyRemote App, Wi-Fi smart screen 61

N
Network frequency 29
Network frequency mode 29
Network router 7
Network, DHCP 8
Network, password 7
Network, settings 8
Network, Static IP 8
Network, wired 8
Network, wireless 7
Noise reduction 36

O
On and off 20
Online support 74
Online TV 54
Open source software 73
Options,on a channel 25
Original language 34

P
Parental rating 27
Perfect contrast 36
Perfect Natural Motion 36
Photo camera, connect 16
Photos, slideshow 55
Picture shift 38
Picture style 35
Pixel Plus link 11
Playback formats 72
Pointer, about 23
Pointer, speed 23
Pointer, switch off 23
Pointer, use 23
Power consumption 70
Power inlet 6
Predefined symbol rates 29
Programme list 32

Q
Quick picture settings 17
Quick start 20

R
Radio channel 25
Reception quality 29
Recording, list of recordings 58
Recording, record now 58
Recording, schedule a recording 58
Recording, what you need 58
Recordings, list 59
Recordings, TV guide data 33
Reinstall TV 27
Reminder, programme 32
Remote control, accents and symbols 22
Remote control, Azerty 22
Remote control, batteries 24
Remote control, Cyrillic 22
Remote control, keyboard 22
Remote control, Keys 21
Remote control, pairing 23
Remote control, pointer 23
Remote control, Uppercase 22
Rental movies 54

S
Safety instructions 18
Satellite, add 46
Satellite, age rating 44
Satellite, channel list 43
Satellite, channel update 47
Satellite, channels 43
Satellite, connection 7
Satellite, favourite channels 43
Satellite, installation 45
Satellite, lock channels 44
Satellite, Multi-Dwelling-Unit 45
Satellite, remove 46
Satellite, rename channels 46
Satellite, reorder channels 44
Satellite, Unicable 46
Saving energy 70
SCART connection, tips 10
Screen care 19
Screen edges 38
Screen off, switch 55
Sharpness 36
Shop location 38
Skype 64
Skype, automatic sign-in 67
Skype, block contact 66
Skype, calling phones 66
Skype, camera test 68
Skype, change password 68
Skype, contacts 65
Skype, Credit 67
Skype, event 67
Skype, history 67
Skype, mute 66
Skype, new account 64

Skype, notifications 67
Skype, online status 65
Skype, receive calls 66
Skype, ringtone 68
Skype, sign in 64
Skype, sign out 68
Skype, video call 66
Skype, voice call 66
Skype, voicemail 67
Sleep timer 35
Smart TV, PIN code 52
Smart TV, register 52
Smart TV, start page 52
Software, current version 73
Software, Internet update 73
Software, USB update 73
Sound style 38
Source menu 33
Speakers/Headphones 42
Speech 42
Standby 20
Standby delay 20
Status 25
Streaming video 54
Subtitles 34
Subtitles, pause TV 58
Subtitles, recording 58
Super resolution 36
Surround sound 39
Switch off timer 70
Symbol rate 29
Symbol rate mode 29
Synchronise audio and video 13

T
Television on Demand 54
Text 30
Text, dual screen 31
Text, freeze 31
Text, options 31
Text, setup 31
Text, T.O.P. overview 31
Treble 39
TV clock 35
TV guide 32
TV guide, information 32
TV network name 9
TV placement 40
TV speakers 39

U
Universal access 41
USB flash drive, connect 16
USB Hard Drive, info 14
USB Hard Drive, installation 14
USB keyboard 15
USB mouse 15

V
Video contrast 37
Video files, playback 55
Video selection 25
Video store 54
Viewing distance 6

W
Wall mounting, VESA 6
Watch TV 24
Wi-Fi smart screen, channel bar 62
Wi-Fi smart screen, tool bar 62
Wi-Fi smart screen, watch TV 62
WPS - Wi-Fi Protected Setup 7
WPS, PIN code 8
WWW. 53

Y
YPbPr connection, tips 10

Contact information

Argentina
0800 444 7749
Buenos Aires 0810 444 7782

België / Belgique
070 700 035 (0,15€/min.)

Bosna i Hercegovina
033 941 251 (Lokalni poziv)

Brazil
0800 701 0245
Sao Paulo 2938 0245

България
02 4916 273 (Национален номер)

Česká republika
228880895 (Místní tarif)

Danmark
3525 8314

Deutchland
0180 501 04 69 (0,14€/Min.)

Ελλάδα
2111983028 (Εθνική κλήση)

España
902 88 10 83 (0,10€ + 0,08€/min.)

Estonia
6683061 (Kohalikud kõned)

France
01 57 32 40 50 (local)

Hrvatska
01 777 66 01 (Lokalni poziv)

Italia
0245 28 70 14 (chiamata nazionale)

Ireland
0818 210 140 (national call)

Northern Ireland
0844 338 04 88 (5p/min BT landline)

Казакстан
8 10 800 2000 00 04 (free)

Latvia
6616 3263 (Vietējais tarifs)

Lithuania
8 5 214 0293 (Vietinais tarifais)

Luxembourg / Luxemburg
2487 1100 (Nationale Ruf / appel national)

Magyarország
06 1 700 8151 (Belföldi hívás)

Nederland
0900 202 08 71 (0,10€/min.)

Norge
22 97 19 14

Österreich
0820 40 11 33 (0,145€/Min.)

Polska
22 397 15 04 (Połączenie lokalne)

Portugal
707 78 02 25 (0,12€/min. - Móvel 0,30€/min.)

Română
031 6300042 (Tarif local)

Россия
8-800-22 00004 (бесплатно)

Suisse / Schweiz / Svizzera
0848 000 291 (0,081 CHF/Min.)

Србија
011 321 6840 (Lokalni poziv)

Slovakia
2 332 154 93 (Vnútroštátny hovor)

Slovenija
1 888 83 12 (Lokalni klic)

Suomi
09 88 62 50 40

Sverige
08 5792 9096 (lokalsamtal)

ประเทศไทย (Thailand)
02 652 7650

Türkiye
444 8 445

United Kingdom
0844 338 04 88 (5p/min BT landline)

Україна
0-800-500-480 (безкоштовно)

www.philips.com/support

Non-contractual images / Images non contractuelles / Außervertragliche Bilder

Specifications are subject to change without notice.
Philips and the Philips' shield emblem are registered trademarks of Koninklijke Philips Electronics N.V.
and are used under license from Koninklijke Philips Electronics N.V.
All registered and unregistered trademarks are property of their respective owners.
2013 © TP Vision Netherlands B.V. All rights reserved.

www.philips.com